



AD-A109 552 NAVAL POSTGRADUATE SCHOOL MONTEREY CA
SASS HARDWARE ARCHITECTURE AND DEVELOPMENTAL MONITOR.(U)
JUN 81 G S BAKER
UNCLASSIFIED NP552-81-016

F/G 9/2

ML

1-3
3





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS 1963-A

LEVEL II

②

NPS52-81-016

NAVAL POSTGRADUATE SCHOOL
Monterey, California

AD A109552



DTIC
SELECTE
JAN 12 1982

E

SASS Hardware Architecture
and
Developmental Monitor

Gary Stewart Baker

June 1981

DTIC FILE COPY

Approved for public release; distribution unlimited

Prepared for:

Naval Postgraduate School
Monterey, CA 93940

82 01 12 046

NAVAL POSTGRADUATE SCHOOL
Monterey, California


Rear Admiral J. J. Ekelund
Superintendent

David A. Schrady
Acting Provost

The work reported here was supported by the Department of Computer Science.


Reproduction of all or part of this report is authorized.

This report was prepared by:


GARY STEWART BAKER
Lieutenant Commander, USNR

Reviewed by:

Released by:


GORDON H. BRADLEY, Chairman
Department of Computer Science


WILLIAM M. TOLLES
Dean of Research

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER NPS52-81-016	2. GOVT ACCESSION NO. AD-109552	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) SASS Hardware Architecture and Development Monitor		5. TYPE OF REPORT & PERIOD COVERED Technical Report
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Gary Stewart Baker		8. CONTRACT OR GRANT NUMBER(s)
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, CA 93940		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Postgraduate School Monterey, CA 93940		12. REPORT DATE June 1981
		13. NUMBER OF PAGES 278
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report) UNCLASSIFIED
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Secure Archival Storage System, Development Monitor, Secure Archival Storage System hardware architecture.		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This report contains the documentation for the Secure Archival Storage System hardware architecture, developmental monitor program, and all necessary support programs to effect programming of the firmware.		

DD FORM 1 JAN 73 1473

EDITION OF 1 NOV 65 IS OBSOLETE
S/N 0102-014-6601

UNCLASSIFIED
SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

TABLE OF CONTENTS

Accession For	X	□	□	□	□	□	□
NTIS	DTIC	DDI	DDP	DDT	DDF	DDG	DDH
Dirt							A

INTRODUCTION.....	6
APPENDIX A - SASS HARDWARE ARCHITECTURE.....	7
A. ZILOG Z8000 MICROPROCESSOR.....	7
1. Register Structure.....	9
2. CPU Control and Status.....	12
3. Addressing Modes.....	17
B. ZILOG Z8010 MEMORY MANAGEMENT UNIT.....	18
C. AMD Am96/4116 MONOBOARD COMPUTER.....	19
D. DEVELOPMENTAL SYSTEM.....	25
1. The Zilog MCZ-1/05 Microcomputer System.....	25
2. Am96/4116 MBC Configuration.....	28
3. Am96/4116 Modifications.....	29
4. Am96/1064 Memory Board Configuration.....	33
E. SUMMARY.....	34
APPENDIX B - DEVELOPMENTAL MONITOR LISTING.....	35
A. COMMAND SYNTAX.....	35
1. DISPLAY COMMAND.....	36
2. REGISTER COMMAND.....	37
3. MOVE COMMAND.....	37
4. FILL COMMAND.....	37
5. GO COMMAND.....	38
6. JUMP COMMAND.....	38
7. BREAK COMMAND.....	38

8.	NEXT COMMAND.....	39
9.	QUIT COMMAND.....	39
10.	LOAD COMMAND.....	39
11.	SEND COMMAND.....	40
12.	ALERTS.....	40
B.	MONITOR PROGRAM LISTING.....	41
1.	EXECUTIVE MODULE.....	41
2.	INTERRUPT MODULE.....	51
3.	LOAD MODULE.....	64
4.	REGISTER MODULE.....	84
5.	DISPLAY MODULE.....	93
6.	BRK_QUIT MODULE.....	106
7.	DEBUG MODULE.....	115
8.	SEND MODULE.....	125
APPENDIX C - BOOTLOAD PROGRAM LISTING.....		132
A.	PROM PROGRAMMING.....	132
B.	BOOTLOAD PROGRAM LISTING.....	135
1.	BOOTLOAD1 MODULE.....	135
2.	BOOTLOAD2 MODULE.....	150
3.	SUPPORT1 MODULE.....	165
4.	SUPPORT2 MODULE.....	180
5.	SUPPORT3 MODULE.....	191
APPENDIX D - BOOTSTRAP PROGRAM LISTING.....		211
A.	BOOTSTRAP PROGRAM LISTING.....	211
1.	BOOTSTRAP MODULE.....	211
2.	SUPPORT1 MODULE.....	233

3. SUPPORT2 MODULE.....	233
4. SUPPORT3A MODULE.....	233
APPENDIX E - SUPPORT PROGRAMS.....	252
A. TEXT FILE TRANSFERS.....	252
B. Z8XFER PROGRAM LISTING.....	253
1. Z8XFER MODULE.....	253
2. TTXFER MODULE.....	255
3. OBJXFR MODULE.....	259
4. Z8LIB MODULE.....	268
C. CPMXFR PROGRAM LISTING.....	270
1. Z8000 TRANSFER MODULE.....	270
LIST OF REFERENCES.....	272
INITIAL DISTRIBUTION LIST.....	275

LIST OF FIGURES

A-1	Z8000 General Registers.....	11
A-2	Program Status (PS) Register.....	13
A-3	Program Status Area.....	14
A-4	CPU Status Lines.....	16
A-5	MMU Address Relocation.....	20
A-6	AMD Am96/4116 MonoBoard Computer.....	22
A-7	Z8000 Development System.....	26
A-8	Am96/4116 MBC Wire-Wrap Options.....	30
A-9	Address Bit Truth Table.....	31
A-10	Address Bit Modification.....	31
A-11	Interrupt Truth Table.....	32
A-12	Interrupt Modification.....	33

INTRODUCTION

This report contains the documentation for the Secure Archival Storage System hardware architecture, developmental monitor program, and all necessary support programs to effect programming of the firmware. The hardware architecture described in Appendix A provides the single board computer wire-wrap options and security modifications required to establish the hardware configuration. Appendix B presents

a command syntax tutorial for the monitor program and the program listing. The bootload program which comprises the current firmware is listed in Appendix C, with the support program and methodology for changing the firmware provided in Appendix E. The Bootstrap program, which loads and runs the SASS demonstration module, is presented in Appendix D.

The bootload program (firmware) has been tested in a single processor environment. The monitor program is currently being tested and debugged, but is considered usable as presented herein. The bootstrap program has not been sufficiently tested and will require further development.

APPENDIX A - Hardware Architecture

Presented in this appendix is an hardware resource description meant to acquaint unfamiliar readers with the basic architectural devices and organization referred to in this thesis effort. The information necessary to reproduce the same hardware architecture is also contained in this appendix. Hardware familiarization includes the Zilog Z8000 microprocessor, the Zilog Z8010 Memory Management Unit (MMU), and the Advance Micro Computer Am96/4116 MonoBoard Computer. What follows is then a detailed description of the SASS Developmental Architecture built as a part of this thesis effort, to support the implementation of the initialization design presented in this thesis, and to support follow on work in the SASS. The intent was to make this appendix the hardware reference manual in support of future research efforts. Readers requiring more specific information on the hardware are referred to the appropriate literature listed in the references.

A. ZILOG Z8000 MICROPROCESSOR

The Z8000 is manufactured in two versions, the 48-pin Z8001 and the 40-pin Z8002, which differ only in the manner and range of memory addressing. Except for this feature, called memory segmentation, they are functionally identical. The Z8001 contains seven output lines for segment number

selection and one input line as a segment trap to support memory segmentation. Without segmentation, the Z8002 can address up to six distinct, external memory spaces of 64K bytes each, while the segmented Z8001 can access 128 addressable segments that are each 64K bytes in size. A total of 8 Megabytes can be addressed in this way with segmentation.

The CPU operates in one of two domains: system or normal mode. In the system mode all features of the processor are available to the running program, while in the normal mode the running program is isolated from potentially dangerous activities, such as instructions for basic I/O and changing system parameters.

Multiprogramming is supported by the concomitant Test-and-Set instruction and hardware context switching. Test-and-Set instructions allow single or block memory transactions without interruption, thus accommodating conventional spin-lock synchronization and concurrent read/write access to shared memory in a single processor environment. Changing the running environment or context of a process requires the reloading of the execution point which is defined in the Z8000 by two unique registers, the Program Counter (PC) and the Flag-and Control Word (FCW). The PC holds the address of the next instruction to be executed and the FCW contains the mode in which it is to be executed. Multiprocessing is facilitated by a combination of

instruction and hardware features. Bus control signals (BUSREQ and BUSAK pins) arbitrate the use of the multiplexed address and data bus by external devices, i.e. a DMA or disk controller. The Multi-Micro control signals (Micro-In and Micro-Out lines) when used in conjunction with certain special purpose instructions, allow a more general form of resource sharing among multiple processors.

In addition to the above required attributes, the 28000 offers several very flexible architectural features that can be classified as: CPU control and status, register structure, and addressing modes.


1. Register Structure

The 28000 CPU is a register-oriented machine that provides a regular register structure for manipulating bytes (8-bits), words (16-bits), and long-word (32-bits) values. The instruction set provides for bit and nibble (4-bit) access to the various register contents. The sixteen 16-bit registers in the architecture can be referenced as sixteen 8-bit, sixteen 16-bit, eight 32-bit, or four quad-word 64-bit registers. All word or long-word registers (with the exception of R0 and RR0) may be used as general purpose stack registers and manipulated with the PUSH and POP instructions. The R15 and RR14 registers are the stack pointers used by the 28002 and 28001 respectfully, when executing CALL and RETURN instructions, and when processing interrupts and traps. Figure A-1 shows the register

structure of the Z8002 processors. The Z8001 requires a 314' register for segmentation.

Additional special registers also comprise the register architecture. As described previously, the execution point of a process is contained in two unique registers, the Program Counter (PC) and the Flag-and Control Word (FCW). The high byte of the FCW sets the mode of operation of the processor by selecting normal/system, segmented/non-segmented, and by enabling or disabling vectored interrupts (VI) and non-vectored interrupt (NVI). The lower byte of the FCW contains flags that may be used by any program to make conditional jumps or other control decisions affecting program flow of control. These flags are set or reset depending on the results of preceding instructions. Figure A-2 illustrates the organization of the program status registers.

Exception processing is directed through the use of another special register, the Program Status Area Pointer (PSAP). At initialization a table in memory must be allocated which contains all the FCW and PC values needed for each of the possible internal (traps) and external (interrupts) events. The organization of this Program Status Area pointed to by the PSAP is shown in Figure A-3. Interrupts are external asynchronous events requiring CPU attention, generally by external devices. Traps are synchronous events resulting from the execution of certain



Z8002 General Registers

FIGURE A-1

instructions. Both are processed in a similar manner by the CPU. The processor supports three types of interrupts: non-maskable, vectored and non-vectored; and four system traps: system call, unimplemented instruction, privileged instruction and segmentation trap. The vectored and non-vectored interrupts are internally maskable within the CPU. When an exception occurs, the current program status is automatically pushed onto the system stack. The program status in this instance refers to the processor status (PC and FCW) and a 16-bit identifier containing the reason or source of the exception.


The last special register in the register structure is the REFRESH register, which is designed to provide dynamic memory refreshing on an estimated demand basis. The upper byte is loaded with a refresh rate count and bit-15 is set to enable the memory refresh activity.

2. CPU Control and Status

The Z8000 CPU incorporates three control input lines and four status output lines. Input control lines change CPU states, while the status output lines may be decoded to indicate internal CPU status (e.g., instruction fetches, I/O references or interrupt acknowledges).

The RESET control line interrupts normal CPU operations and causes the CPU to clear itself completely (even of interrupt and bus requests). Two consecutive read cycles are executed in the system mode that load the FCW


Flag-and Control Word



Program Counter

A D D R E S S

28002 Program Status (PS) Registers
FIGURE A-2



Program Status Area (PSA)
FIGURE A-3

with the contents of memory location 0002 and load the contents of location 0004 into the PC. In the case of the segmented Z8001, location 0004 contains the PC segment number and 0006 contains the offset within the segment. In either case, after loading of the initialized system execution point, the following first instruction fetch (IF1) starts the CPU running. This first PC must, of course, point into executable code, typically in firmware.

For special purposes, external devices can control the execution of the CPU by activating the STOP control line. This freezes the next instruction without loss of memory refresh as occurs with bus requests. This control line can be used to synchronize the interactions of a Z8000 and extended-processor units (EPU's), which can, for example perform floating point operations.

The WAIT signal input will allow slower external devices to stretch the number of clock cycles between the address strobe (AS) and data strobe (DS) within a machine cycle, for as long as necessary to receive or assemble the data. In this way, a 16-bit address directs a 16-bit data transfer that is essentially independent of the processor's clock and is thus asynchronous.

Internal CPU status indications can be obtained by decoding the four output status lines from the processor. Figure A-4 lists the decoded signals. Decoded status, for example can be used to segregate program, data and stack

ST 3:0	CPU STATUS
0 0 0 0	Internal Operations
0 0 0 1	Memory Refresh
0 0 1 0	I/O Reference
0 0 1 1	MMU I/O Reference
0 1 0 0	Segment Trap Acknowledge
0 1 0 1	Non-Maskable Int Acknowledge
0 1 1 0	Non-Vectored Int Acknowledge
0 1 1 1	Vectored Int Acknowledge
1 0 0 0	Memory Reference - Data
1 0 0 1	Memory Reference - Stack
1 0 1 0	N/A
1 0 1 1	N/A
1 1 0 0	Memory Reference - Code (IFn)
1 1 0 1	Memory Reference - Code (IF1)
1 1 1 0	N/A
1 1 1 1	N/A

CPU Status Lines
FIGURE A-4

memory areas. When used in conjunction with the normal/system output line from the CPU, six distinct physical memory regions can be formed: normal program, data, and stack; and system program, data, and stack. The four status output lines allow the CPU many flexible control options over external devices.

3. Addressing Modes

The addressing mode of a Z8000 instruction defines, either explicitly or implicitly, the address space it references and the method used to compute the address itself. In general, an addressing mode explicitly specifies either register address space or memory address space. Program memory address space and I/O address spaces are usually implied by the instruction. Data may be addressed in eight basic modes: Register (R), Immediate (IM), Direct Address (DA), Indirect Register (IR), Indexed (X), Relative Address (RA), Based Address (BA) and Base Indexed (BX).

In the Immediate mode (IM), the data is part of an instruction itself; in the Register mode (R), the register to which the operand is to be written into or read from is specified. The address of the operand is carried directly with the instruction in the Direct Addressing mode (DA). The IM, R and DA modes all require that the operand's address be static or known at compile time, before the program is run.

The remaining address modes allow dynamic or runtime computation of addresses and/or displacements in registers. The Indirect Register mode assumes the address of the operand to be placed at runtime in the specified register contained in the instruction; the Indexed mode allows a program to calculate a displacement from a fixed base address. This is more commonly used for indexing fixed tables. The Base Address mode is a reflection of the indexed mode in that the base address rather than the displacement is calculated at runtime. A common use of this mode is for accessing identical portions of different instances of a data structure. The Base Indexed mode combines the base address and indexed modes to allow the creation of fully relocatable, reentrant code (relocatable specifies that the code may be moved to any location in memory, and reentrant means that the code does not modify itself). The final addressing mode is the Relative mode, in which the PC is always used as the base address, combined with the specified displacement contained in the instruction, to determine the absolute address.

B. ZILOG Z8010 MEMORY MANAGEMENT UNIT

In the segmented Z8001 processor, the addresses actually manipulated are logical two-dimensional addresses consisting of a 7-bit segment number and a 16-bit offset within the segment. The Zilog Z8010 Memory Management Unit (MMU) takes the 23-bit logical addresses from the CPU and transforms


them into 24-bit absolute addresses for addressing physical memory[22]. This address transformation process is called relocation. A translation table of registers in the MMU associates the 7-bit segment number (SN) with the base address of one of 64 different physical memory segments. The 16-bit offset is added to the physical base address to obtain the actual physical address. Figure A-5 illustrates the relocation process. The base address register file may be dynamically reloaded as processes are created, suspended or changed.

The MMU also provides segment protection and memory management facilities. Each segment can have several attributes associated with it that provide memory access protection (viz. read/write access, normal/system mode only) and memory management data (viz. whether changed or referenced).

MMU defined segments are variable in size ranging from 256 bytes to 64K bytes in increments of 256 bytes. Pairs of 64-segment MMU's are necessary to support the 128 segment numbers available from segment number line decodings.

C. AMD Am96/4116 MONOBOARD COMPUTER

A major factor in the selection of the Zilog Z8000 family of microprocessors was the commercial availability of the Advanced Micro Devices (AMD) Am96/4116 MonoBoard Computer (MBC). The MBC is a complete microcomputer system




MMU Address Relocation
FIGURE A-5

on one 12.0 by 6.75 inch printed, multi-layered circuit board. The MBC version available at the outset of the SASS project contains a 5Mhz Z8002 non-segmented processor, 32K bytes of random-access memory (RAM), up to 8K bytes of electronically programmable read-only memory (EPROM), programmable serial and parallel I/O interfaces, a real-time clock and counter system, a programmable interrupt controller, and five edge connectors providing bus and peripheral interface capability [23]. Figure A-6 depicts the MBC architecture in block diagram form.

Multibus interfacing is through standard edge connector P1, which supports 20-bit addressing, eight bus interrupt lines, and bus arbitration and timing lines. The Am9551 serial I/O components interface offboard to peripheral devices through edge connectors P4 and P5. Serial port 1 (P5) supports all interconnections of a standard RS232C interface, while serial port 2 (P4) does not support synchronous handshaking capabilities. Edge connector P3 interfaces the three 8-bit parallel ports (A,B,C), from the Am8255A parallel I/O integrated circuit. All of the inputs and outputs of the Am9513 Timing Controller chip are available through edge connector P2.

Included on the Am96/4116 is a 32 source interrupt jumper matrix for input to any of the eight interrupt inputs (IRQ0 - IRQ7) of the Am8259A Interrupt Controller. The Jumper matrix contains bi-directional Multibus interrupt



Zilog Am96/4116 MonoBoard Computer

FIGURE A-6

interfacing (INT0* - INT7*) for external device interrupt communications; two parallel port (C) single bit sources for use as software generated interrupts; receive and transmit ready signals from the two serial I/O components for asynchronous communications with peripheral devices; five timer or counter output signals from the Am9513 IC; and several sources from the onboard fault detection circuitry. All interrupt sources are available as a 28000 non-vectored interrupt or non-maskable interrupt as well, through the interrupt jumper matrix.

The Am6255A parallel I/O component provides three 8-bit parallel ports, one of which (C) can be used to program under software control, the function of the other two ports (A and B). In addition, a 4-bit portion of port C can be used as a Multibus address source for the higher address bits (AD10-AD13), under program control. The significance of this will be seen later on. Two bits of the C port, as mentioned previously, also serve as signal sources for software generated interrupts.

The onboard dynamic RAM (32K bytes) is dual ported, with Multibus access controlled by an onboard control logic. This capability is designed for a multi-processor environment where maximum flexibility of available physical memory is desired; however, the SASS design goal of memory segmentation cannot tolerate a single RAM memory space having two addresses and thereby requiring particular care

to disable this option. The MBC can support an optional 2, 4, or 8K byte read-only memory (ROM) in a shadow mode; the ROM is shadowed over existing memory space by CPU direction. The ROM can support the system firmware.

Provided on the MBC is an Am9513 Timing Controller that contains five Counter Logic Groups consisting of a 16-bit general counter with associated control and output logic, a 16-bit Load register, a 16-bit Hold register and a 16-bit Mode register [20]. In addition, counter groups 1 and 2 also include 16-bit comparator and Alarm registers. The Counter Mode Register is used to control all of the individual options available with its associated general counter group. The Load register is used to control the effective length of the general counter, while the Hold register is used to store accumulated counter values for later transfer to the host processor. The Alarm and comparator registers are used to detect and signal specific values in the general counter. Each of the counter groups can serve as independent or cascaded, count-down or count-up counters with gated or nongated count sources. Each provides an output signal to the interrupt jumper matrix and the P2 edge connector for offboard applications.

CPU onboard accessing of the individual IC's is accomplished through a decoding of the addresses contained in the 28000 IN/OUT instructions; components are enabled appropriately. All programmable components must be

initialized to some consistent state as the first step in any initialization mechanism.


D. DEVELOPMENTAL SYSTEM

As stated previously, the primary feature desired in the SASS Developmental Architecture (SDA) is the external bus. To achieve this, the Am96/4116 Monoboard must replace the Zilog Z8000 Development Module (DM) which has previously been the platform for SASS development. Figure A-7 shows the end product after the substitution. The remaining developmental components from the original system consist of the Zilog MCZ-1/05 Microcomputer System (MCZ) and a CRT terminal. A firmware monitor program for the MonoBoard was needed to affect the substitution. The firmware will be discussed under the SDA to follow.

1. The Zilog MCZ-1/05 Microcomputer System

The MCZ-1/05 Microcomputer System is a disk-based microcomputer unit, utilizing the Z80 family of microcomputer cards. The basic system includes two boards: a Z80 microcomputer board (MCB) for performing primary system control, and a Z80 memory disk controller (MDC) for interfacing the dual floppy disk drive. These two cards constitute the basic MCZ system, that provides 60K bytes of RAM memory, 3K bytes of firmware, control of the disk drive module, and communications with the Z8000 MCB through an asynchronous serial RS-232 interface.

Zilog MCZ-1/05
Microcomputer System



Development Console

Z8000 Development System
FIGURE A-7

Supporting software consists of a full-disk operating system (RIO), which includes a macroassembler, linker, text editor, and file utility. Details concerning the MCZ hardware or software can be found in the listed references. The macroassembler provides for assembling relocatable object modules from PLZ/ASM language source code entered with the RIO text editor. Higher level language support, as PLZ/SYS, is currently not available for developmental use. Subsequently relocatable modules can be linked together with the Linker and core images located with the Imager. Object files are then downloaded into the MBC memory for executing and debugging. The ability to upload from the MBC memory into the RIO file structure is also available.

User communication with the RIO operating system is via the development terminal, through the Am96/4116 MonoBoard. The MBC developmental monitor provides for three modes of operation: 1) the Monitor Mode, which is used to enter, debug and execute software residing in MBC RAM; 2) the Transparent Mode, which is used to transmit data between the development terminal and the MCZ system; and 3) the Upload/Download Mode, used for transferring object files between MBC memory and the MCZ microcomputer system. Offboard Am96/4116 MonoBoard communications with the MCZ system and the development terminal is asynchronous through the two MBC serial ports as designated in Figure A-7.

2. Am96/4116 Configuration

The commercial MonoBoard provides wire-wrap options for configuring the MBC for specific applications. The options available include primary memory addressing (both onboard and offboard), interrupt/trap source selection, and various device configuration settings. An appropriate wire-wrap configuration for each of these areas was defined from requirement consideration of the SASS and the developmental system. Figure A-8 lists the finalized MonoBoard wire-wrap configuration. This configuration results in the following interrupt utilization in the SASS Developmental Architecture:

Non-Vectored Interrupt - Hardware PRE-EMPT

Vectored Interrupts:

INT0	-	Console INT
INT1	-	N/A
INT2	-	MCZ INT
INT3	-	Onboard PRE-EMPT
INT4	-	N/A
INT5	-	Real Time Clock
INT6	-	Single Inst. Execution
INT7	-	Illegal Memory Reference

Interrupt handler routines when assigned in this manner, are supported by this wire-wrap configuration.

For compatability with the Am96/4116 RAM Memory Board, address bits ADF and AD10 for offboard addressing were switched. Address bit ADF uses the buffered Normal/System CPU signal as its source. When the secondary storage device (i.e., hard disk) is installed, offboard address bit AD11 should be sourced to the instruction fetch

signal (I-FETCH*) signal by connections of pins 68-69 and 38-39. This will allow code execution only from one of the two memory boards, and data fetches in two domains within the other.

3. Am96/4116 Modifications

Global memory partitioning by domains is accomplished by making use of the processor's Normal/System signal for offboard addresses. Partitioning of onboard local memory is more difficult. Use of available onboard logic gates and wiring modifications were required to achieve the desired segregation. In the SASS design for MMU simulation, a portion of local memory must be accessible in the system mode only, thereby protecting the information contained in this area (i.e., the Kernel). For simplicity the design choice was made to use the address bit ABE to equally divide the local memory space. The desire is to make the lower half (0000-3FFF) accessible in the system mode only and the upper half (4000-7FFF) accessible in both the normal and system mode. Given those two signals, the following truth table was derived:

POWERUP RESET/INIT
Pin 190 - 191

ONBOARD RAM SELECT
Pin 193 - 194
(0000-7FFF)

BUS CLOCK SELECT
Pin 19 - 20

GLOBAL MEMORY SELECT
Pin 36 - 63 (ADF-AD10)
62 - 37 (N/S-ADF)
65 - 66 (N/S)

DAISEY-CHAIN BUS PRIORITY
Pin 184 - 185 (no chain)
21 - 22

PROM SELECTION (2716)
Pin 25 - 27

SERIAL PORTS 4 & 5
Pin 132 - 133 (RTS1-CTS1)
139 - 140 (9600 BAUD)
141 - 143 (9600 BAUD)
179 - 180 (CTS2-GND)

28 - 30
177 - 178
174 - 176
71 - 72

OTHER

Pin 33 - 34
38 - 39
40 - 41
42 - 43
128 - 130

Pin 136 - 137
148 - 162
151 - 150
153 - 154
163 - 164

INTERRUPTS

Vectored Interrupts:

(SSTFP) Pin 130 - 115
(OUT2) 114 - 117
(RXR2) 100 - 127
(RXR1) 101 - 123
(OUT4) 116 - 95
(OUT5) 112 - 121
(Spec Mod) * - 113

(IRE06)
(IRE05)
(IRE00)
(IRE02)
(INT4*)
(IRE03)
(IRE07)

"Next" command
Real time clock
Console Interrupt
MCZ Sys Interrupt
Multibus Preempt
Onboard Preempt
Memory Violation

Non-Maskable Interrupts:

(INT1*) Pin 79 - 128
(Timeout) 157 - 171
(Oddword) 158 - 172

(NMI)
(NMI)
(NMI)

Non-Vectored Interrupt:

(INT4*) Pin 95 - 129

(NVI)

Hardware Preempt

Am96/4116 MBC Wire-Wrap Options
FIGURE A-8


N/S*	ADE	\sim N/S*	\sim ADE	+	NAND	
1	1	0	0		1	NORMAL
1	0	0	1		1	
0	1	1	0		1	SYSTEM
0	0	1	1		0	

Address Bit Truth Table

Figure A-9

The NAND signal becomes the new ABE bit.

A search of available onboard logic gates produced the necessary components to construct the circuitry, and solder connections were made as shown:



wire: Pin66 to P6U21
P14U21 to P5U34
P16U68 to P4U21
P16U21 to P4U34
P6U34 to P13U66
cut: P16U68 to P13U66

Address Bit Modification
Figure A-10


The above modification produced the desired security, however addressing in the normal mode below 4000 HEX produced some undesirable effects. For instance, a write to address 2000 HEX would actually write to address 6000 HEX, unknown to the user. Another design decision was made to prevent this occurrence by providing an interrupt source from this circuitry. The following logic generated the interrupt:

ABE	$\overline{\text{ABE}}$	'NAND'	+	'AND'
1	0	1		0
0	1	1		1
1	0	0		0
0	1	0		0

Interrupt Truth Table

Figure A-11

However, precautions must be taken to preclude the generation of this interrupt when addressing global memory from 8000-C000 HEX. The address bit ABF was used to enable/disable interrupt generation in the following circuitry:



Interrupt Modification
Figure A-12

The additional drivers are supplied to the ABF signal for timing considerations. With this circuitry an interrupt (INT7) is generated only when an access to low local memory (0000-3FFF) is made in the normal mode.

4. Am96/1064 Memory Board Configuration

The Am96/1064 is a single board dynamic random access memory system with 64K bytes of addressable memory and onboard control and refresh logic for maintaining stored data. It is Multibus compatible with a 415nsec access time. Normal installation procedures were adhered to with the following exceptions. On one of two such boards in the system, bus address comparator (U111) is allowed to pass

address bit AD10 (N/S*) to onboard logic for selection of one of two planes of 32K bytes of memory. One addressable in the normal mode and the other addressable in the system mode.

As mentioned earlier, when a suitable secondary storage device is installed the second memory board can be added and the instruction fetch signal (I-FETCH*) can become the source for address bit AD11. For the memory board mentioned above, address bit AD11 will be forced high (Pin connections 60-59 removed) and the second board will have this bit pulled low (I-FETCH*) on the comparator. This provides the read-only function. No additional wiring modifications are required.

C. SUMMARY

This section provided a brief tutorial into the architecture of the Z8000 family of microprocessors. The intent was to provide the reader with the necessary hardware background to understand the content of this thesis, and to reconstruct the hardware architecture used in this effort. In answer to any additional questions that may arise, the reader is encouraged to consult the referenced literature.

APPENDIX B - Developmental Monitor Program Listing

The developmental monitor program is presented in this appendix in two parts, the command syntax description and program listing. The command syntax description is a complete users manual for the monitor program. The program listing contains the eight program modules that comprise the PLZ/ASM program listing. The somewhat unstructured program appearance stems from the requirement to maintain the organizational structure of certain required functions, in particular the MCZ system communication protocol. A conscious effort was made to preserve the original command syntax.

A. COMMAND SYNTAX

The developmental monitor consists of eleven commands: four performing normal development functions for display and setting of processor memory and registers; four operations for debugging of user programs; two providing upload/download capability with the MCZ system; and one command for entering a transparent mode of operation between the MCZ system and the user console. A command line description is presented for each command. Command line representations adhere to the following conventions:

- (1) the use of angle brackets <> denotes a required entry.
- (2) the use of square brackets [] denotes an optional entry.

The command lines serve as a ready reference for command syntax familiarization in the following descriptions.

1. DISPLAY Command

D[isplay] <adr> [no. words]

The display command can be used to perform two operations: the display of a block of memory in word format (16-bits), and to display the contents of a single address with the option to change the contents. Use of the command with a starting HEX address, followed by a hexadecimal number indicating the number of words desired, will display the contents of a block of memory. Use of the command followed by a single address enters a substitution mode. The contents of the single address will be displayed on the console followed by a prompt (*) indicating to the user that he has three options: (1) entering a new value will change the contents of that location, (2) entering a carriage return <CR> sequentially steps through memory leaving the contents unchanged, and (3) entering a 'Q' will terminate the substitution mode of operation and return control to the monitor program.

2. REGISTER Command

R[egister] [register name]

The register command displays the current contents of registers R0-R15, PC and FCW. Use of the command alone will display the current contents of all registers and return to the monitor. Use of the optional register name will enter a substitution mode as described above, and proceed sequentially until either a 'Q' is entered or all registers have been displayed. Control is then returned to the monitor.

3. MOVE Command

M[ove] <old adr> <new adr> <no. bytes>

The move command moves the contents of the specified block of memory to a new location, without altering the contents of the old locations. The old address and number of bytes specifies the block to be moved; and the new address specifies the new starting address.

4. FILL Command

F[ill] <start adr> <end adr> <data>

The fill command changes the memory contents inclusively from the specified starting address to the ending address, with the user supplied hexadecimal data.

5. GO Command

G[o]

The go command starts user program execution at the execution point defined by previously user set PC and FCW registers.

6. JUMP Command

J[ump] <start adr>

The jump command starts execution of a user's program from the address specified, using the current FCW register value.

7. BREAK Command

B[reak] [address] [no. breaks]

The break command is used to set a break point within a user's program. When the break point is encountered during normal execution of the user program, execution is terminated, user registers and program status is saved, and the message 'BREAK AT <address>' is sent to the console. Use of the break command alone will clear any set break points. User has the option of specifying the number of times that the break point must be encountered before program execution is terminated; the default value is 1.

8. NEXT Command

N[ext] [no. instructions]

The next command is used to single step through the execution of a user's program. The contents of the CPU registers after each instruction execution are displayed to the user. Multiple instruction executions can be optionally entered by the user; the default value is 1.

9. QUIT Command

Q[uit]

Use of the quit command places the MonoBoard in a transparent mode where it performs as a communication relay between the MCZ RIO operating system and the user console. To the user the appearance is complete operation within the MCZ system. To exit the transparent mode, the Non-Maskable Interrupt (INTR switch) must be given, which saves user registers and returns control to the monitor.

10. LOAD Command

L[oad] <filename> [load adr]

The load command downloads program files from the MCZ RIO file structure into the Z8000 system for execution. The load address can be optionally specified; default is to the load address passed with the file from RIO. After a

successful download operation, the message 'ENTRY POINT <address>' is sent to the console showing the load address used.

11. SEND Command

S[end] <filename> <start adr> <end adr> [entry adr]

The send command is used to save the contents of a specified block of 28000 memory within the RIO file system. The optional entry address becomes the default load address for downloading with the load command; otherwise the start address becomes the default address.

12. Alerts

Within the hardware architecture are certain interrupts that require user notification on occurrence. The following is a list of the current interrupt messages:

'NMI'	Results from a Non-Maskable interrupt generation by depression of INTR switch.
'ILLEGAL MEMORY REFERENCE'	Results from illegal memory reference in normal mode.
'UNKNOWN TRAP'	Results from interrupt/trap not currently used in the architecture.

What follows in the next section is an annotated source listing for the monitor program.

B. MONITOR PROGRAM LISTING

1. EXECUTIVE MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 EXEC DMONITOR MODULE
\$LISTON \$TTY

CONSTANT

```

RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPORT   := %FFCB
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR    := %(2)0001000000000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %08
LINDEL   := %7F
CR       := %0D
LF       := %0A
TXOFCH   := %13
TXONCH   := %11
INSIZ    := 128      ! INTBUF SIZE !
OUTSIZ   := 128      ! OUTBUF SIZE !
RBSIZ    := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE   := 0
ISTOP    := 1
OSTOP    := 2
SNDMDE   := 3
LDMDE    := 4
ESC      := 5
TXMSK    := %6

```

COMDS := 11

TYPE
SWITCH RECORD [FCW_ WORD
PC WORD]

INTERNAL
\$SECTION DATA_DEC
\$ABS 0

0000	INTBUF	ARRAY [128 BYTE]
0080	OUTBUF	ARRAY [128 BYTE]
0100	RNGBUF	ARRAY [256 BYTE]
0200	MCZBUF	ARRAY [256 BYTE]

0300	BUFADR	WORD
0302	BUFSIZ	WORD

0304	INTPTR	WORD
0306	OUTPTR	WORD

0308	UNIMP	WORD
030A	BRKCNT	WORD

030C	NXTPTR	WORD
030E	GETOUT	WORD
0310	MCZPUT	WORD
0312	MCZGET	WORD
0314	BRKSTR	WORD
0316	BRKADR	WORD
0318	TMPSP	WORD
031A	TMPFCW	WORD

031C	MFLAGS	WORD
------	--------	------

! USER REGISTER STORAGE !

031E	R0_	WORD
0320	R1_	WORD
0322	R2_	WORD
0324	R3_	WORD
0326	R4_	WORD
0328	R5_	WORD
032A	R6_	WORD
032C	R7_	WORD
032E	R8_	WORD
0330	R9_	WORD
0332	R10_	WORD
0334	R11_	WORD
0336	R12_	WORD

0338	R13_	WORD
033A	R14_	WORD
033C	R15_	WORD
033E	RPC_	WORD
0340	RPC_	WORD
0342	RETPY	WORD
0344	ADR_STR	WORD
0346	CMTBL	ARRAY[12 WORD]

INTERNAL
\$SECTION PSA_DATA
\$ABS 0

0000	PSA	RECORD [
		DATA_AREA	WORD
		CODE_AREA	WORD
		UNIMP_INST	SWITCH
		PRIV_INST	SWITCH
		SYSTEM_CALL	SWITCH
		SEG_TRAP	SWITCH
		NMI_INT	SWITCH
		NVI_INT	SWITCH
		VEC_FCW	WORD
		VEC_PC	ARRAY [200 WORD]
]	

INTERNAL
\$SECTION BOOT_DATA
\$ABS 0

0000	BOOT_COM	RECORD [
		TABLE_LOCK	WORD
		SIGNAL	WORD
		MSG1	WORD]

\$SECTION EXEC_PROC
EXTERNAL

GETLNE	PROCEDURE
NMI	PROCEDURE
IMPINT	PROCEDURE
SNDCHR	PROCEDURE
SNDMSG	PROCEDURE
MEMINT	PROCEDURE
FAIL_SAFE	PROCEDURE
CLK_STORE	PROCEDURE
MCZEND	PROCEDURE
CONINT	PROCEDURE
DISPLAY	PROCEDURE
GETBUF	PROCEDURE
FILL	PROCEDURE

MOVE	PROCEDURE
REGISTER	PROCEDURE
GO	LABEL
BREAK	PROCEDURE
JUMP	PROCEDURE
NEXT	PROCEDURE
QUIT	PROCEDURE
SEND	PROCEDURE
LOADFL	PROCEDURE
GETCHR	PROCEDURE

```

GLOBAL EROR LABEL
GLOBAL EXEC LABEL
0000 GLOBAL INITL PROCEDURE
!*****
*      DMONITOR INITIALIZATION      *
*****!

```

```

ENTRY
ORGADR:
0000 F80F JR STARTP
PHYS_ID:
0002 F1F1 WVAL XF1F1 ! UNIQUE PHYS_ID !
LOGO:
0004 0F BVAL %0F
0005 2A BVAL '*'
0006 5341 WVAL 'SA'
0008 5353 WVAL 'SS'
000A 2044 WVAL 'D'
000C 4D4F WVAL 'MO'
000E 4E49 WVAL 'NI'
0010 544F WVAL 'TO'
0012 52 BVAL 'R'
0013 0D BVAL %0D

CMDCHR:
0014 4446 WVAL 'DF'
0016 4D52 WVAL 'MR'
0018 514C WVAL 'QL'
001A 4A4E WVAL 'JN'
001C 4753 WVAL 'GS'
001E 4220 WVAL 'B'

```

! START OF INITIAL ENTRY TO DMONITOR !

STARTP:

!*****

* RESET CODE AREA AND DATA AREA REGS *

*****!

! RESET DATA_AREA AND CODE_AREA REGISTERS !

```
0020 7D25    LDCTL    R2,PSAPOFF
0022 612E    LD      R14,DATA_AREA(R2)
0024 0000
0026 8DE4    TEST     R14
0028 EE02    JR       NZ,SET_OTHERS
002A 210E    LD      R14,#7A00
002C 7A00
```

SET_OTHERS:

```
002E 340C    LDAR     R12,ORGADR
0030 FFCE
0032 6F2C    LD      CODE_AREA(R2),R12  ! SAVE NEW CODE !
0034 0002
                                ! BASE ADDR !
0036 6F2E    LD      DATA_AREA(R2),R14
0038 0000
```

!*****

* *

* SFTW_INIT: INITIALIZES ALL BASIC *

* DATA STRUCTURES FOR THE *

* NORMAL FUNCTIONING OF *

* DMONITOR. *

* *

*****!

! CLEAR DMONITOR RAM AREA !

```
003A 76F2    LDA      R2,BUFADR(R14)  ! CLR DMONITOR RAM !
003C 0300
003E A121    LD      R1,R2
0040 A911    INC     R1,#2
0042 2103    LD      R3,#66
0044 0042
0046 0D25    LD      QF2,#0
0048 0000
004A BB21    LDIR     QR1,QR2,R3
004C 0310
```

! LD FIXED DATA IN RAM !

```
004E 34E7    LDA      R7,R14(#INTBUF)
0050 0000
0052 33E7    LD      R14(#INTPTR),R7
0054 0304
```

```

2056 34E7    LDA    R7,R14(#OUTBUF)
0058 0080
005A 33E7    LD     R14(#CUTPTR),R7
005C 0306
005E 34E3    LDA    R3,R14(#UNIMP)
0060 0308
0062 0D35    LD     @R3,%0E00
0064 0E00
0066 34E3    LDA    R3,R14(#BRKCNT)
0068 030A

006A 4DE8    CLR     GETOUT(R14)
006C 030E
006E 4DE8    CLR     NXTPTR(R14)
0070 030C

```

```

!*****
*   INITIALIZE PROGRAM STATUS AREA   *
*****!

```

```

0072 7D25    LDCTL   R2,PSAPOFF
0074 76C4    LDA     R4,FAIL_SAFE(R12)
0076 0000*
0078 A923    INC     R2,#4
007A 2F24    LD      @R2,R4
007C A123    LD      R3,R2
007E A931    INC     R3,#2      ! FAILSAFE PSA !
0080 2104    LD      R4,#24
0082 0018
0084 BB21    LDIR    @R3,@R2,R4    ! SETUP PSA !
0086 0430

0088 7D25    LDCTL   R2,PSAPCFF
008A 2101    LD      R1,%4000
008C 4000
008E 3423    LDA     R3,R2(#UNIMP_INST)
0090 0004
0092 76C4    LDA     R4,IMPINT(R12)
0094 0000*
0096 3334    LD      R3(#2),R4
0098 0002

009A 8D48    CLR     R4
DO
009C 7331    LD      R3(R4),R1
009E 0400
00A0 A943    INC     R4,#4
00A2 0B04    CP      R4,#28
00A4 001C
00A6 E601    JR      Z,LD_PC

```

```

00A8 E8F9      0D
                LD_PC:

00AA 3423      LDA      R3,R2(#NMI_INT)      ! LOAD NMI HDLR !
00AC 0014
00AE 76C4      LDA      R4,NMI(R12)
00B0 0000*
00E2 3334      LD       R3(#2),R4
00E4 0002

                ! SET INTERRUPT HANDLERS !
00B6 3423      LDA      R3,R2(#VEC_PC) ! BASE OF INT VEC!
00B8 001E
00BA 34C2      LDA      R2,R12(#CONINT) !CONS INPUT!
00BC 0000*
00BE 3332      LD       R3(#0),R2
00C0 0000

                ! MCZ INPUT !
00C2 34C2      LDA      R2,R12(#MCZHND)
00C4 0000*
00C6 3332      LD       R3(#4),R2
00C8 0004

                ! MEMORY ACCESS VIOLATION !
00CA 34C2      LDA      R2,R12(#MEMINT)
00CC 0000*
00CE 3332      LD       R3(#14),R2
00D0 000E

!*****
*          SET STACK POINTER          *
!*****

00D2 A1EF      LD       R15,R14
00D4 010F      ADD      R15,#05F0      ! SET STACK POINTER !
00D6 05F0
00D8 6FEF      LD       R15_(R14),R15
00DA 033C

!*****
*  INITIALIZE COMMAND JUMP TABLE  *
!*****

                ! INIT COMMAND JUMP TABLE !
00DC 34E1      LDA      R1,R14(#CMDTBL) ! BASE ADR !
00DE 0346
00E0 34C2      LDA      R2,R12(#DISPLAY)
00E2 0000*
00E4 3312      LD       R1(#0),R2

```

```

20E6 0000
00E8 34C2    LDA      R2,R12(#FILL)
00EA 0000*
00EC 3312    LD       R1(#2),R2
00EE 0002
00F0 34C2    LDA      R2,R12(#MOVE)
00F2 0000*
00F4 3312    LD       R1(#4),R2
00F6 0004
00F8 34C2    LDA      R2,R12(#REGISTER)
00FA 0000*
00FC 3312    LD       R1(#6),R2
00FE 0006
0100 34C2    LDA      R2,R12(#QUIT)
0102 0000*
0104 3312    LD       R1(#8),R2
0106 0008
0108 34C2    LDA      R2,R12(#LOADFL)
010A 0000*
010C 3312    LD       R1(#10),R2
010E 000A
0110 34C2    LDA      R2,R12(#JUMP)
0112 0000*
0114 3312    LD       R1(#12),R2
0116 000C
0118 34C2    LDA      R2,R12(#NEXT)
011A 0000*
011C 3312    LD       R1(#14),R2
011E 000E
0120 34C2    LDA      R2,R12(#GO)
0122 0000*
0124 3312    LD       R1(#16),R2
0126 0010
0128 34C2    LDA      R2,R12(#SEND)
012A 0000*
012C 3312    LD       R1(#18),R2
012E 0012
0130 34C2    LDA      R2,R12(#BREAK)
0132 0000*
0134 3312    LD       R1(#20),R2
0136 0014

```

! DISPLAY LOGO !

```

0138 3402    LDAR     R2,LOGO
013A FEC8
013C 34CA    LDA      R10,R12(#SNDMSG)
013E 0000*
0140 1FA0    CALL     OR10

```


! R12 = START OF CODE !
! R14 = START OF DATA AREA !
! R15 = STACK POINTER !

!*****!
* BASIC CONTROL OF DMONITOR *
!*****!

EXEC :

0142 340C	LDAR	R12,ORGADR	
0144 FEBA			
0146 7D15	LECTL	R1,PSAPOFF	
0148 211E	LD	R14,QR1	
014A 3401	LDAR	R1,EXEC	
014C FFF4			
014E 93F1	PUSH	QR15,R1	
0150 31E1	LD	R1,R14(#MFLAGS)	! CLR MON FLAGS !
0152 031C			
0154 0701	AND	R1,#TXMSK	! EXCEPT TX BIT !
0156 0006			
0158 33E1	LD	R14(#MFLAGS),R1	
015A 031C			
015C 7C05	EI	VI	
015E C82A	LDB	RL0,#''	
0160 76CA	LDA	R10,SNDCHR(R12)	! CALR SUBSTIT !
0162 0000*			
0164 1FA0	CALL	QR10	
0166 34CA	LDA	R10,R12(#GETLNE)	! CALR SUBSTIT !
0168 0000*			
016A 1FA0	CALL	QR10	
			! GET CMD 1ST CHR !
	! COMMAND LOOKUP ROUTINE !		
016C 3401	LDAR	R1,CMDCHR	! BASE OF LKUP TBLE!
016E FEA4			
0170 BD2B	LDK	R2,#COMDS	! TOTAL # CMDS !
0172 BA14	CPIRB	RL0,QR1,R2,EQ	! FIND CMD !
0174 0286			
0176 EE09	JR	NZ,EROR	! CMD NOT FOUND !
0178 BD1A	LDK	R1,#COMDS - 1	! DETERMINE INDEX !
017A 8321	SUB	R1,R2	
017C B311	SLL	R1,#1	
017E 0001			
0180 34E2	LDA	R2,R14(#CMDTBL)	
0182 0346			
0184 9121	ADD	R1,R2	
0186 2113	LD	R3,QR1	! GET CMD ADR !
0188 1E38	JP	QR3	! GOTO CMD HDLR !

```

!*****
*                               GLOBAL ERROR LABEL                               *
!*****

```

```

ERROR:
0184 C83F      LDB      RL0,#'?'      ! DISP '?' FOR ER !
018C 34CA      LDA      R10,R12(#SNDCHR)  ! CALR SUBSTIT !
018E 0000*
0190 1FA0      CALL     QR10
0192 A1EF      LD       R15,P14
0194 010F      ADD      R15,#%05F0      ! RESET STACK POINTER !
0196 05F0
0198 34E1      LDA      P1,R14(#OUTBUF)
019A 0080
019C 33E1      LD       R14(#OUTPTR),R1
019E 0306
01A0 E8D0      JR       EXEC            ! DELETE CMD !

```

```

01A2      END INITL

```

```

END EXEC_DMONITOR

```

2. INTERRUPT MODULE

Z8003ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 INTERRUPT_HDLR MODULE
\$LISTON \$TTY

```
!*****
*
*      INTERRUPT HANDLER ROUTINES
*
*****!
```

CONSTANT

```
RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3
```

```
IDPORT   := %FFCB
ICPORT   := %FFC9
```

```
TCMD     := %FFD2
TDTA     := %FFD0
```

```
BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF9
VINTR     := %(2)0001000000000000
VIBIT     := 12
ESCAPE    := %1B
BS        := %08
LINDEL    := %7F
CR        := %0D
LF        := %0A
TXOFCH    := %13
TXONCH    := %11
INSIZ     := 128      ! INTBUF SIZE !
OUTSIZ    := 128      ! OUTBUF SIZE !
RBSIZ     := 256      ! RING BUFFER SIZE !
```

! BIT POSITIONS IN MONITOR FLAG WORD !

```
TRPMDE    := 0
ISTOP     := 1
OSTOP     := 2
SNDMDE    := 3
```

```

LDMDE      := 4
ESC        := 5
TXMSK      := %6

```

```

EXTERNAL
EXEC        LABEL
PBUFNC      LABEL
CONVW       PROCEDURE
PRNTBF      PROCEDURE
BPKROU      LABEL
NEWLNE      PROCEDURE

```

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

```

0000      INTBUF  ARRAY [128 BYTE]
0080      OUTBUF  ARRAY [128 BYTE]
0100      RNGBUF  ARRAY [256 BYTE]
0200      MCZBUF  ARRAY [256 BYTE]

```

```

0300      BUFADR  WORD
0302      BUFSIZ  WORD

```

```

0304      INTPTR  WORD
0306      OUTPTR  WORD

```

```

0308      UNIMP   WORD
030A      BRKCNT  WORD

```

```

030C      NXTPTR  WORD
030E      GETOUT  WORD
0310      MCZPUT  WORD
0312      MCZGET  WORD
0314      BRKSTR  WORD
0316      BRKADR  WORD
0318      TMPSP   WORD
031A      TMPFCW  WORD

```

```

031C      MFLAGS  WORD

```

! USER REGISTER STORAGE !

```

031E      R0_     WORD
0320      R1_     WORD
0322      R2_     WORD
0324      R3_     WORD
0326      R4_     WORD
0328      R5_     WORD

```

032A	R6_	WORD
032C	R7_	WORD
032E	R8_	WORD
0330	R9_	WORD
0332	R10_	WORD
0334	R11_	WORD
0336	R12_	WORD
0338	R13_	WORD
033A	R14_	WORD
033C	R15_	WORD
033E	RPC_	WORD
0340	RFC_	WORD
0342	RETRY	WORD
0344	ADR_STR	WORD

```

GLOBAL
$SECTION INTERRUPT_PROC
$REL 0

```

```

0000 2C 49  SECMSG ARRAY [* BYTE] := '%00ILL MEM REF%0D'
0002 4C 4C
0004 20 4D
0006 45 4D
0008 20 52
000A 45 46
000C 0D
000D 09 42  BRKMSG  ARRAY [*  BYTE] := '%09BREAK AT '
000F 52 45
0011 41 4B
0013 20 41
0015 54 20
0017 05 4E  NMIMSG  ARRAY [*  BYTE] := '%05NMI %0D'
0019 4D 49
001B 20 0D
001D 09 55  UNK_INT  ARRAY [*  BYTE] := '%09UNK TRAP%0D'
001F 4E 4B
0021 20 54
0023 52 41
0025 50 0D

```

```

0028      SAVRG      PROCEDURE
          !*****
          *
          *   SAVRG: SAVES USER PROGRAM STATUS   *
          *           AND REGS 1-14 CONTENTS.     *
          *
          !*****!
ENTRY
0028 6FFB      LD      TMPSP(R14),R15      ! RTN ADR !
002A 0318
002C 31F0      LD      R0,R15(#4)      !SAVE:  !
002E 0004
0030 6FE0      LD      RFC_(R14),R0      ! USER FCW !
0032 0340
0034 31F0      LD      R0,R15(#6)
0036 0006
0038 6FE0      LD      RPC_(R14),R0      ! USER PC !
003A 033E
          ! SAVE R1 - R14 !
003C 76EF      LDA      R15,R1_(514)
003E 0320
0040 1CF9      LDM      GR15,R1,#11      ! STORE REGS !
0042 010A
0044 61EF      LD      R15,TMPSP(R14)      ! RESTORE SP !
0046 0318
0048 6FED      LD      R13_(R14),R13
004A 033E
004C 9E08      RET
004E      END SAVRG

GLOBAL
004E      DMON_ENTRY PROCEDURE
          !*****
          *
          *   DMON_ENTRY: RESTORES DMONITOR R12   *
          *           AND R14 (CODE AND DATA)*
          *           REGISTERS FOR INTERRUPT*
          *           ENTRIES.                   *
          *
          !*****!
ENTRY
004E 93F1      PUSH     GR15,R1
0050 93FE      PUSH     GR15,R14
0052 7D15      LDCTL    R1,PSAPOFF      ! GET PSA BASE !
0054 211E      LD      R14,GR1      ! RESTORE DATA BASE !
0056 6FEC      LD      R12_(R14),R12      ! SAVE USER R12 !
0058 0336
005A 311C      LD      R12,R1(#2)      ! RESTORE CODE BASE !
005C 0002
005E 97F1      POP      R1,GR15

```

```

0060 6FF1      LD      R14_(R14),R1
0062 033A
0064 97F1      POP     R1,QR15
0066 9E08      RET

```

```

0068          END DMON_ENTRY

```

```

0068          GLOBAL
MEMINT  PROCEDURE

```

```

!*****
*
*  MEMINT: INTERRUPT HANDLER TO SIGNAL *
*          USER OF ILLEGAL USER MODE *
*          USE OF LOCAL MEMORY, AND *
*          TERMINATE USER PROGRAM EXE- *
*          CUTION WITH RETURN TO DMON. *
*
*****!

```

```

ENTRY

```

```

0068 D00E      CALR    DMON_ENTRY
006A 33EF      LD      R14(#R15_),R15
006C 033C
006E 33E0      LD      R14(#R0_),R0
0070 031E
0072 D026      CALR    SAVRG      ! SAVE USER REGS !
0074 3402      LDAR    R2.SECMSG
0076 FF88
0078 93F2      PUSH    QR15,R2    ! SAVE MSG ADR !
007A E84D      JR      ALERT
007C          END MEMINT

```

```

007C          GLOBAL
IMPINT  PROCEDURE

```

```

!*****
*
*  IMPINT: NON-IMPLEMENTED INSTRUCTION *
*          INTERRUPT HANDLER USED TO *
*          TERMINATE USER PROGRAM EXE- *
*          CUTION AT A PRESET BREAK *
*          POINT. ALL USER REGISTERS *
*          AND PROGRAM STATUS IS SAVED *
*
*****!

```

```

ENTRY

```

```

007C D018      CALR    DMCN_ENTRY
007E 33EF      LD      R14(#R15_),R15
0080 033C
0082 33E0      LD      R14(#R0_),R0
0084 031E
0086 D030      CAL°    SAVRG      ! SAVE REGS !

```

```

0088 6BE1      DEC      RPC_(R14),#2
008A 033E
008C 6BE0      DEC      BRKCNT(R14),#1
008E 030A
0090 EE12      JR        NZ,SSTP      ! NO, EXEC 1 INST !
0092 4DE5      LD        BRKCNT(R14),#%0001
0094 030A
0096 0001

0098 7C05      EI        VI
009A 3402      LDAR      R2,BRKMSG      ! LOAD ADR BRK MSG !
009C FF6F
009E DFB0      CALR      SNDMSG
00A0 31E5      LD        R5,R14(#RPC_)
00A2 033E
00A4 34CA      LDA       P10,R12(#CONVW)
00A6 0000*
00A8 1FA0      CALL      @R10      ! CONVERT BYTE !
00AA 34CA      LDA       R10,R12(#PRNTBF)
00AC 0000*
00AE 1FA0      CALL      @R10      ! OUTPUT TO CONS !
00B0 34CA      LDA       R10,R12(#EXEC)
00B2 0000*
00B4 1EA8      JP        @R10      ! RETURN TO EXEC !

                                SSTP:
00B6 34CA      LDA       R10,R12(#BRKROU)
00B8 0000*
00BA 1EA8      JP        @R10      ! JUMP TO BRK, !
                                ! ROUTINE !
00BC          END IMPINT

                                GLOBAL
00BC          FAIL_SAFE PROCEDURE
!*****!
*
*   FAIL_SAFE: RESTORES PROGRAM TO
*               CONTROL OF DMONITOR ON AN
*               UNKNOWN INTERRUPT OR TRAP
*               SOURCE.
*               RETURNS TO THE BASIC EXEC.
*
!*****!

                                ENTRY
00EC D038      CALR      DMON_ENTRY
00EE 33EF      LD        R14(#R15_),R15
00F0 033C
00F2 33E0      LD        R14(#R0_),R0
00F4 031E
00F6 D050      CALR      SAVRG      ! SAVE USER REGS !

```



```

0708 3402      LDAR      R2,UNK_INT
00CA FF51
00CC 93F2      PUSH      @R15,R2      ! SAVE MSG ADR !
00CE E823      JR        ALERT
00D0          END FAIL_SAFE

00D0          NMI PROCEDURE
!*****
*
*   NMI INT: NCN-MASKABLE INTERRUPT HDR*
*           IN RESPONSE TO MULTIPLE
*           INT SOURCES. IF IN TRANS-
*           PARENT MODE, IT WILL SEND THE
*           ESCAPE CHAR TO MCZ AND RESTORE
*           THE STACK; IF EXECUTING USFR
*           PROGRAM, IT WILL SAVE PROGRAM
*           STATUS AND ALL REGISTERS.
*
*****!
ENTRY
00D0 93FC      PUSH      @R15,R12
00D2 93FE      PUSH      @R15,R14
00D4 93F1      PUSH      @R15,R1
00D6 7D15      LDCTL     R1,PSAPOFF
00D8 211E      LD        R14,@R1      ! LOAD DATA_AREA BASE !
00DA 311C      LD        R12,R1(#2) ! LOAD CODE_AREA BASE !
00DC 0002
00DE 97F1      POP       R1,@R15      ! RESTORE R1 !

00E0 67E0      BIT       MFLAGS(R14),#TRPMDE
00E2 031C
00E4 EE0C      JR        NZ,TQUIT      ! YES, TERMINATE !

! EXECUTING USER PROGRAM !
00E6 97FE      POP       R14,@R15
00E8 97FC      POP       R12,@R15
00EA D04F      CALR      DMON_ENTRY
00EC 33EF      LD        R14(#R15_),R15
00EE 033C
00F0 33E0      LD        R14(#R0_),R0
00F2 031E

00F4 D067      CALR      SAVRG          ! SAVE PS AND REGS !
00F6 3402      LDAR      R2,NMIMSG      ! LOAD ALERT MSG !
00F8 FF1D
00FA 93F2      PUSH      @R15,R2
00FC E80C      JR        ALERT

! IN TRANSPARENT MODE !
TQUIT:

```

```

00FE 63E0      RES      MFLAGS(R14),#TRPMDE
0100 031C
0102 A1EF      LD       R15,R14
0104 010F      ADD      R15,#%05F0      ! SET STACK PTR !
0106 05F0
0108 6FEF      LD       R15_(R14),R15 ! SET USER SP !
010A 033C
010C C81B      LDB      RL0,#ESCAPE
010E DFF1      CALR     SNDMCZ      ! SEND ESCAPE TO MCZ !
0110 3402      LDAR     P2,NMIMSG      ! LOAD ALERT MSG !
0112 FF03
0114 93F2      PUSH     @R15,R2

!OUTPUT NMI ALERT MSG AND RETURN TO EXEC !
ALERT:
0116 7C05      EI       VI
0118 76CA      LDA      R10,NEWLINE(R12)
011A 0000*
011C 1FA0      CALL     @R10

011E 97F2      POP      R2,@R15
0120 DFF1      CALR     SNDMSG
0122 A1EF      LD       R15,R14
0124 010F      ADD      R15,#%05F0      ! RESET STACK POINTER !
0126 05F0
0128 34CA      LDA      R10,R12(#EXEC)
012A 0000*
012C 1EAB      JP       @R10      ! RETURN TO DMONITOR !
012E          END NMI

GLOBAL
012E          SNDMCZ  PROCEDURE
!*****
*
*   SNDMCZ: OUTPUT CHAR TO SERIAL PORT
*           ONE (MCZ SYS).
*
*   REG USE: INPUT  RL0 = CHAR
*               RETURN Z IF CHAR = CR
*
*****!
ENTRY
012E 3A04      INB      RH0,PORTAC      ! GET STATUS !
0130 FFDB
0132 A600      BITB     RH0,#TXR      ! TRANSMIT RDY? !
0134 E6FC      JR       Z,SNDMCZ      ! NOT YET..... !
0136 3A86      OUTB     PORTAD,RL0     ! YES, SND CHR !
0138 FFD9
013A 0A08      CPE      RL0,#CR
013C 0D0D

```

```

013E 9E09      RET
0142      END SNDMCZ

```

```

0140      GLOBAL
          SNDMMSG PROCEDURE
          !*****
          *
          *   SNDMMSG: SEND MSG SPECIFIED TO CONS
          *   (PORT2). FIRST BYTE OF MSG
          *   IS THE DECIMAL LENGTH IN
          *   WORDS.
          *
          *   REG USE: INPUT  R2 = MSG ADDR
          *
          !*****

```

```

          ENTRY
0140 34E1      LDA      R1,R14(#OUTBUF)
0142 0080
0144 0D00      CLR      R0
0146 2028      LDB      R0,R2      ! GET BYTE COUNT !
0148 8101      ADD      R1,R0
014A 33E1      LD       R14(#OUTPTR),R1
014C 0306
014E A920      INC      R2      ! SETUP FOR TRANSFER !
0150 34E1      LDA      R1,R14(#OUTBUF)
0152 0080
0154 BA21      LDIRB     @R1,@R2,R0 ! TRANSFER TO OUTBUF !
0156 0010
0158 34CA      LDA      R10,R12(#PEUFNC)
015A 0000*
015C 1EAS      JP       @R10      ! OUTPUT TO CONS !
015E      END SNDMMSG

```

```

015E      GLOBAL
          CONINT PROCEDURE
          !*****
          *
          *   CONINT: CONS (PORT2) INPUT INT HDLE
          *   ROUTINE, WHICH GETS REC CHR
          *   FROM USART. REC CHR IS CK
          *   FOR TXOFCH OR TXONCH, AND
          *   MFLAGS ADJUSTED ACCORDINGLY
          *   TO SIGNAL PROCEDURES.
          *
          !*****

```

```

          ENTRY
015E 93F0      PUSH     @R15,R0
0160 93F1      PUSH     @R15,R1
0162 93F2      PUSH     @R15,R2      ! SAVE WORK REGS !
0164 93FE      PUSH     @R15,R14

```

```

0166 7D15    LDCTL    R1,PSAPOFF  ! DATA_AREA ADR !
0168 211E    LD      R14,R01

! GET CHAR AND CHECK FOR TXOFCH OR TXONCH !
016A 3A94    INB      RL1,PORTBD  ! GET USART DATA !
016C FFE1
016E A297    RESB     RL1,#PAR    ! CLR PARITY BIT !
0170 67E0    BIT      MFLAGS(R14),#TRPMDE
0172 031C

! TRANSPARENT MODE !
0174 EE18    JR      NZ,PUTCHR    ! YES,.....!
0176 0A09    CPB      RL1,#TXONCH ! NO, CK FOR TXONCH!
0178 1111
017A EE03    JR      NZ,AGAIN     ! NO,.....!
017C 63E2    RES      MFLAGS(R14),#OSTOP ! RESET TC. !
017E 031C

! RESUME OUTPUT !
0180 E818    JR      FINISH
AGAIN:
0182 0A09    CPB      RL1,#TXOFCH ! CK FOR TXOFCH !
0184 1313
0186 EE03    JR      NZ,AGAIN2    ! NO,.....!
0188 65E2    SET      MFLAGS(R14),#OSTOP ! STOP OUTPUT !
018A 031C
018C E812    JR      FINISH

! CHECK FOR ESCAPE CHARACTER !
AGAIN2:
018E 0A09    CPB      RL1,#ESCAPE
0190 1B1B
0192 EE09    JR      NZ,PUTCHR    ! NO,.....!
0194 67E3    BIT      MFLAGS(R14),#SNDMDE ! YES, CK SND MDE!
0196 031C
0198 EE03    JR      NZ,ESCP      ! YES,.....!
019A 67E4    BIT      MFLAGS(R14),#LDMDE ! NO, CK LD MDE !
019C 031C
019E E603    JR      Z,PUTCHR     ! NO !
ESCP:
01A0 65E5    SET      MFLAGS(R14),#ESC  ! SET ESCAPE BIT !
01A2 031C
01A4 E806    JR      FINISH

! PRIMARY SAVE CHARACTER ROUTINE !
PUTCHR:
01A6 31E0    LD      R0,R14(#NXTPTR)
01A8 030C
01AA DFF8    CALR     GETBUF      ! GET RNGBUF ADDR !
01AC 33E0    LD      R14(#NXTPTR),R0
01AE 030C
01B0 2E29    LDB      Q02,RL1     ! PUT CHR IN RNGBUF !

```

```

                                FINISH:
01B2 97FE      POP      R14,GR15
01B4 97F2      POP      R2,GR15
01B6 97F1      POP      R1,GR15
01B8 97F0      POP      R0,GR15      ! RESTORE WORK REGS !
01BA 7B00      IRET
01BC                        END CONINT

```

```

                                GLOBAL
01BC      GETBUF  PROCEDURE
!*****
*
*   GETBUF: DETERMINES POSITION IN
*           RINGBUFFER TO PUT OR GET
*           NEXT CHAR.
*
*   REG USE: INPUT  R0 = CURRENT INDEX
*               RETURN R0 = NEW INDEX
*               R2 = ADR OF RNGBUF
*
*****!

```

```

                                ENTRY
01BC 93FD      PUSH     GR15,R13
01BE A102      LD       R2,R0
01C0 A900      INC      R0,#1      ! INC PTR !
01C2 0B00      CP       R0,#RBSIZ  ! WRAP AROUND !
01C4 0100
01C6 EE01      JR       NZ,GB
01C8 8D08      CLR      R0      ! RESET INDEX !
01CA 34ED      GB:LDA   R13,R14(=PNGBUF) ! NEW ADR !
01CC 0100
01CE 81D2      ADD      R2,R13
01D0 97FD      POP      R13,GR15
01D2 9E08      RET
01D4                        END GETBUF

```

```

GLOBAL
MCZHND PROCEDURE
01D4 !*****
*
* MCZHND: MCZ (SERIAL PORT1) INPUT *
* INTERRUPT HANDLER ROUTINE *
* WHICH GETS RECEIVED CHAR *
* FROM USART, AND STORES IN *
* MCZBUF. *
* *****!
ENTRY
01D4 93F0 PUSH GR15,R0
01D6 93F1 PUSH GR15,R1
01D8 93F2 PUSH GR15,R2 ! SAVE WORK REGS !
01DA 93FE PUSH GR15,R14
01DC 7D15 LDCTL R1,PSAPOFF
01DE 211E LD R14,GR1 ! DATA_AREA ADR !
! GET CHAR FROM MCZ !
01E0 3A94 INB RL1,PORTAD ! GET CHR !
01E2 FFD9
01E4 A297 RESB RL1,#PAR ! RESET PARITY !
01E6 31E0 LD R0,R14(#MCZPUT)
01E8 0310
01EA DFF8 CALR GMCZAD ! GET MCZBUF ADR !
01EC 33E0 LD R14(#MCZPUT),R0
01EE 0310
01F0 2E29 LDB GR2,RL1 ! SAVE CHAR !

!RESTORE WORK REGS !
01F2 97FE POP R14,GR15
01F4 97F2 POP R2,GR15
01F6 97F1 POP R1,GR15
01F8 97F0 POP R0,GR15
01FA 7B00 IRET
01FC END MCZHND

```

```

GLOBAL
01FC GMCZAD PROCEDURE
!*****!
*
* GMCZAD: GET NEXT ADR OF MCZ BUFFER *
*          TC STORE OR GET CHARACTER. *
*
* REG USE: INPUT R0 = PTR IN MCZBUF *
*          RETURN R3 = NEW PTR IN BUF *
*          R2 = BGN OF MCZBUF *
*
*****!
ENTRY
01FC 93FD    PUSH    R15,R13
01FE A102    LD      R2,R0
0200 A900    INC     R0,#1
0202 0B00    CP      R0,#RBSIZ      ! WRAP AROUND? !
0204 0100
0206 EE01    JR      NZ,GBZ
0208 8D08    CLR     R0              ! RESET OFFSET !
GBZ:
020A 34ED    LDA     R13,R14(#MCZBUF) ! GET ADR !
020C 0200
020E 81D2    ADD     R2,R13
0210 97FD    POP     R13,R15
0212 9E08    RET
0214        END GMCZAD

END INTERRUPT_HDLR

```

3. LOAD MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 LOAD_CMD MODULE
\$LISTON \$TTY

```
!*****
*
* LOAD CMD: COMMAND TO DOWNLOAD Z8K
* OBJ CODE FILE FROM RIO/
* MCZ SYSTEM IN TEXTRONIX FORMATTED
* PACKET PASSING PROTOCOL. USER CAN
* SPECIFY LOAD ADDRESS INSTEAD OF
* USING MCZ LOAD ADDRESS.
*
* CAUTION:
* CODE FILES MUST BE RELOCATABLE
* TO EXECUTE PROPERLY.
*
* SYNTAX: LOAD <FILENAME> [<ADR>]
*
*****!
```

CONSTANT

```
RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPORT   := %FFCB
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR    := %(2)0001000000000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %08
LINDEL   := %7F
CR       := %0D
```



```

        LF      := %0A
        TXOFCH  := %13
        TXONCH  := %11
        INSIZ   := 128      ! INTBUF SIZE !
        OUTSIZ  := 128      ! OUTBUF SIZE !
        RBSIZ   := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
        TRPMDE  := 0
        ISTOP   := 1
        OSTOP   := 2
        SNDMDE  := 3
        LDMDE   := 4
        ESC     := 5
        TXMSK   := %6

        COMDS   := 11

```

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

```

0000      INTBUF  ARRAY [128 BYTE]
0080      OUTBUF  ARRAY [128 BYTE]
0100      RNGBUF  ARRAY [256 BYTE]
0200      MCZBUF  ARRAY [256 BYTE]

0300      BUFADR  WORD
0302      BUFSIZ  WORD

0304      INTPTR  WORD
0306      OUTPTR  WORD

0308      UNIMP   WORD
030A      BRKCNT  WORD

030C      NXPTR   WORD
030E      GETOUT  WORD
0310      MCZPUT  WORD
0312      MCZGET  WORD
0314      BRKSTR  WORD
0316      BPKADR  WORD
0318      TMPSP   WORD
031A      TMPFCW  WORD

031C      MFLAGS  WORD

```

```

! USER REGISTER STORAGE !

```

```

031E      R0_     WORD
0320      R1_     WORD
0322      R2_     WORD

```

```

0324      R3_      WORD
0326      R4_      WORD
0328      R5_      WORD
032A      R6_      WORD
032C      R7_      WORD
032E      R8_      WORD
0330      R9_      WORD
0332      R10_     WORD
0334      R11_     WORD
0336      R12_     WORD
0338      R13_     WORD
033A      R14_     WORD
033C      R15_     WORD
033E      RPC_     WORD
0340      PFC_     WORD

0342      RETRY     WORD
0344      ADF_STP   WORD
0346      CMDTBL    ARRAY[12 WORD]

```

```

EXTERNAL  PRNTBF      PROCEDURE
EXTERNAL  GETNXT      PROCEDURE
EXTERNAL  EROR        LABEL
EXTERNAL  SNDCHR      PROCEDURE
EXTERNAL  GETADR      PROCEDURE
EXTERNAL  GMCZAD      PROCEDURE
EXTERNAL  SNDMCZ      PROCEDURE
EXTERNAL  CONVERT     PROCEDURE
EXTERNAL  PBUFNC      LABEL
EXTERNAL  SNDMSG      PROCEDURE
EXTERNAL  CONW        PROCEDURE

```

```

$SECTION LOAD_PROC
$REL 0

```

```

0000      GLOBAL
          FNAME PROCEDURE
          !*****
          *
          *      FNAME: RESETS TWO PTRS TO MCZBUF
          *      AND CHECKS FOR FILENAME.
          *
          !*****!

ENTRY
0000 4DE8      CLR      MCZGET(R14)
0002 0312
0004 4DE8      CLR      MCZPUT(R14)          ! RESET BUFFER !

```

```

0006 0310
0008 34CA      LDA      R10,R12(#GETNXT)
000A 0000*
000C 1FA0      CALL     QR10          ! SKIP CMD ARG !
000E 0A08      CPB       RL0,#'A'
0010 4141
0012 E711      JR        C,DUN
0014 0A08      CPB       RL0,#'Z'+1
0016 5B5B
0018 EF0E      JR        NC,DUN      ! 1ST CHR IN (A..Z) !
001A 76CA      LDA       R10,GETNXT(R12)
001C 0000*
001E 1FA0      CALL     QR10          ! SKIP TO NEXT ARG !
0020 E607      JR        Z,NO_ADR    ! NO NEXT ARG !
0022 76CA      LDA       R10,GETADR(R12)
0024 0000*
0026 1FA0      CALL     QR10          ! GET USER SPECIFIED !
                                ! ADDRESS !
0028 A13B      LD        R11,R3      ! SAVE USER ADR !
002A 6FE3      LD        ADP_STR(R14),P3
002C 0344
002E 9E08      RET

NO_ADR:
0030 210B      LD        R11,#%FFFE  ! SIGNAL TO USE MCZ !
0032 FFFE                                ! ADDRESS !
0034 9E08      RET

DUN:
0036 8D98      CLR       R9
0038 34CA      LDA       R10,R12(#ERROR)
003A 0000*
003C 1EAB      JP        QR10          ! ERROR, RTN TO EXEC !
003E          END FNAME

```

```

003E      GLOBAL
          CMDPAS PROCEDURE
          !*****!
          *
          *   CMDPAS: LOAD CMD PASSING MECHANISM   *
          *           SENDS 'B;' PLUS CONS CMD    *
          *   LINE TO MCZ AND CKS RESPONSES FOR    *
          *   GOOD Z80 PROGRAM LOAD.               *
          *
          *   REG USE:  RETURN    NZ IF Z80 LOADED *
          *                   Z   IF NOT           *
          *
          !*****!

ENTRY
003E 67F5      BIT      MFLAGS,R14) ,#ESC  ! CK FOR ESCAPE !
0040 031C
0042 E602      JR       Z,GCMD
0044 8D41      SETFLG   Z
0046 9E08      RET

          GCMD:
0048 C242      LDB       RH2,#'B'
004A CA3E      LDB       RL2,#';'
004C 6FE2      LD        OUTBUF(R14),R2      ! LOAD INIT 'B;' !
004E 0080
                                ! FOR BRIEF MODE !
0050 76E2      LDA       R2,OUTBUF(R14)
0052 0080
0054 A921      INC       R2,#2
0056 76E1      LDA       R1,INTBUF(R14)
0058 0000
005A 2100      LD        R0,#%40      ! LD CMD IN OUTBUF !
005C 0040
005E BB11      LDIR      GR2,GR1,R0
0060 0020

0062 76E1      LDA       R1,OUTBUF(R14)
0064 0080
0066 0101      ADD       R1,#%80
0068 0080
006A 6FE1      LD        OUTPTR(R14),R1
006C 0306

006E DFB6      CALR      OUTSTM          ! OUTPUT BUFFER !
0070 DFE7      CALR      SKIPLN         ! SKIP MCZ ECHO !
0072 DFD4      CALR      MCZCOM         ! WAIT RESPONSE !
0074 0A09      CPB       RL1,#'B'
0076 4242
0078 EE02      JR        NZ,LDSTAT
007A DFEC      CALR      SKIPLN         ! SKIP MCZ ECHO !

```

007C DFD9 CALR MCZCOM ! WAIT RESPONSE !

! VERIFY LOAD STATUS !

LDSTAT:

007E 0A29 CPB RL1,#'9' ! TEST LEGAL !
 0080 3939
 0082 E60E JR Z,RECACK ! ACKNOWLEDGEMENTS !
 0084 0A09 CPB RL1,#'0'
 0086 3030
 0088 E60E JR Z,RECACK ! REC GOOD ACK !
 008A 0A09 CPB RL1,#'7'
 008C 3737
 008E E608 JR Z,RECACK

! NO ACKNOWLEDGEMENTS RECEIVED !

ERMSG:

0090 DFD9 CALR RECMSG ! GET MCZ MSG !
 0092 34CA LD# R10,R12(#SNDCHR)
 0094 0000*
 0096 1FA0 CALL GR10 ! SEND TO CONS !
 0098 0A08 CPB RL0,#LF
 009A 0A0A
 009C 9E06 RET Z ! DONE !
 009E E8F8 JR ERMSG

! ACKNOWLEDGE RECEIVED !

RECACK:

00A0 8D43 FESFLG Z ! RETURN NZ !
 00A2 9E08 RET
 00A4 END CMDPAS

GLOBAL

SKPB LABEL

00A4

SKIPLN PROCEDURE

!*****!

*
 * SKIPLN: SKIP RECEIVED LINE FROM *
 * MCZ; RETURN FIRST CHAR OF *
 * NEXT LINE. *
 *
 * REG USE: RETURN RL1 = 1ST CHR *
 * AND NZ IF ESC *

*****!

ENTRY

00A4 DFE3 CALR RECMSG ! SKIP OVER LINE !
 00A6 0A08 CPB RL2,#CR ! THRU CR,LF !
 00A8 0D0D
 00AA EEFC JR NZ,SKIPLN

```

SKPB:
00AC 2101    LD      R1,#%3000    ! DELAY FACTOR !
00AE 3000

! MAIN LOOP FOR RECEIVING CHAR !
LOOP1:
00B0 61E0    LD      R0,MCZGET(R14)
00B2 0312
00B4 4BE0    CP      R0,MCZPUT(R14)    ! TEST FOR REC CHR !
00B6 0310
00B8 EE03    JR      NZ,RECHR          ! YES,..... !
00BA AB10    DEC     R1,#1            ! NO, WAIT AWHILE !
00BC EEF9    JR      NZ,LOOP1
00BE 9F06    RET      Z                ! FORCED EOL !

RECHR:
00C0 DFFB    CALR    MCZCOM
00C2 0A09    CPB     RL1,#'          ! CK 1ST=PRNT CHR !
00C4 2020
00C6 9E0D    RET     PL
00C8 DFF5    CALR    RECMSG
00CA E8F0    JR      SKPB
00CC        END SKIPLN

MCZCOM PROCEDURE
*****
*
* MCZCOM: LOOPS WAITING FOR RECEIVE
* CHAR FROM MCZ BY SEEING IF
* MCZBUF GETS CHAR. DOES
* ADVANCE POINTER.
*
* REG USE: RETURN  RL1 = CHR
*
*****!
ENTRY
00CC 61E0    LD      R0,MCZGET(R14)    ! CHECK MCZBUF !
00CF 0312
00D0 4BE0    CP      R0,MCZPUT(R14)    ! POINTERS !
00D2 0310
00D4 E6FB    JR      Z,MCZCOM          ! WAIT.....!
00D6 34CA    LDA     R10,R12(#GMCZAD)
00D8 0000*
00DA 1FA0    CALL    @R10            ! GET CHAR FROM BUF !
00DC 2029    LDB     RL1,@R2
00DE 9E08    RET
00E0        END MCZCOM

```

00E0

RECMSG PROCEDURE

```

*****
*
*   RECMSG:  LOOPS WAITING FOR REC CHR
*             FROM MCZ. GETS CHAR AND
*             DO NOT ADVANCE BUF PTR.
*
*   REG USE:  RETURNS   RLO = CHR
*
*****

```

ENTRY

```

00E0 61E0      LD      R0,MCZGET(R14)
00E2 0312
00E4 4BE0      CP      R0,MCZPUT(R14)      ! CK FOR REC !
00E6 0310
00E8 E6FB      JR      Z,RECMSG      ! WAIT..... !
00EA 34CA      LDA     R10,R12(*GMCZAD)
00EC 0000*
00EE 1FA0      CALL    GR10      ! GET 1ST CHAR !
00F0 6FE0      LD      MCZGET(R14),R0      ! RESTORE PTR !
00F2 0312
00F4 2028      LDB     RLO,GR2      ! RTN CHAR !
00F6 9E08      RET
00F8          END RECMSG

```

GLOBAL

OUTSTM LABEL

00F8

OUTLINE PROCEDURE

```

*****
*
*   OUTLINE:  OUTPUTS A LINE OF CHAR FROM
*             OUTBUF TO MCZ WITH CR AT
*             END.
*
*   OUTSTM:   OUTPUTS A LINE OF CHAR W/CR
*
*****

```

ENTRY

```

00F8 61F2      LD      R2,OUTPTR(R14)
00FA 0306
00FC 0C25      LDB     GR2,#CR      !STORE CR IN BUF !
00FE 0D0D
0100 69E0      INC     OUTPTR(R14),#1      ! INC PTR !
0102 0306

```

! NO CR ENTRY POINT !

OUTSTM:

```

0104 76E1      LDA     R1,OUTBUF(R14)
0106 0080

```

! MAIN LOOP !

```

OVRAIN:
0108 2019      LDB      PL0,QR1
010A A910      INC      R1
010C 34CA      LDA      R10,R12(#SNDMCZ)
010E 0020*
0110 1FA0      CALL     QP10          ! SND CHR TO MCZ !
0112 E603      JR       Z,FINIS
0114 4BE1      CP       R1.OUTPUTR(R14)
0116 0306
0118 E7F7      JR       C,OVRAIN      ! CK IF BUF EMPTY !

! FINISHED. RESET OUTPUTR(R14) AND BLANK OUTBUF !
FINIS:
011A 76E2      LDA      R2.OUTPUTR(R14) ! RESET POINTER !
011C 0080
011E 6FE2      LD       OUTPUTR(R14),R2
0120 0306
0122 2100      LD       R0,#OUTSIZ/2
0124 0040
0126 AB00      DEC      R0,#1          ! SET COUNT !
0128 4DE5      LD       OUTPUTR(R14),# ' ' ! LOAD COUNT !
012A 0080
012C 2020
012E 76E2      LDA      R2.OUTPUTR(R14)
0130 0080
0132 A121      LD       R1,R2
0134 A911      INC      R1,#2
0136 BE21      LDIR     QP1,QR2,R0    ! CLR BUFFER !
0138 0010
013A 9FE8      RET
013C          END OUTLINE

```



```

ABORTM LABEL
GODPAK LABEL
BADPAK PROCEDURE
213C
!*****
*
* BADPAK: SENDS RESFND SIGNAL ('7')
* TO MCZ FOR BAD CKSUM OR REC
* NON-ASCII CHR.
*
* ABORTM: SENDS ABORT SIGNAL ('9')
* WHEN USER SELECTED.
*
* GODPAK: SENDS ACK SIGNAL ('0') FOR
* RECEIPT OF GOOD PACKET.
*
*****!
ENTRY
213C C837 LDB RL0,#'7' ! LD RESEND SIG !
213E F803 JR OUTALL
ABORTM:
2140 C839 LDB RL0,#'9' ! LD ABORT SIG !
2142 F801 JR OUTALL
GODPAK:
2144 C830 LDB RL0,#'0' ! LD REC OK SIG !
OUTALL:
2146 CEE8 LDB OUTBUF(R14),RL0
2148 0090
214A 76ED LDA R13,OUTBUF(R14)
214C 0080
214E A9D0 INC R13,#1
2150 6FFD LD OUTPTR(R14),R13
2152 0306
2154 D02F CALR OUTLNE ! SEND MCZ SYSTEM !
2156 D05A CALR SKIPLN ! SKIP ECHO !
2158 9E08 RET
215A END BADPAK

```

```

015A      GLOBAL
          GETACK  PROCEDURE
          !*****
          *
          *   GETACK: RECEIVE AND INTERPRET ACK
          *   FROM MCZ. GOOD ACK = '2'
          *   BAD ACK = '7'
          *   ABORT = '9'
          *
          *   REG USE: RETURN  Z,NC IF GOOD ACK
          *   NZ,NC IF BAD ACK
          *   NZ,C IF ABORT
          *
          !*****!
ENTRY
015A D048      CALR      MCZCOM      ! GET CHR !
015C 0A09      CPB       RL1,#'0'    ! CK FOR ACK !
015E 3030
0160 EE04      JR        NZ,NACK      ! NO..... !
0162 D060      CALR      SKIPLN      ! YES, REC ACK !
0164 8D41      SETFLG    Z
0166 8D83      RESFLG    C
0168 9E08      RET
          ! CK FOR '7' AND '9' NON-ACKNOWLEDGEMENTS !
NACK:
016A 0A09      CPB       RL1,#'7'    ! CK FOR RESEND !
016C 3737
016E EE04      JP        NZ,ABRT      ! NO.... !
0170 D067      CALR      SKIPLN
0172 8D43      RESFLG    Z
0174 8D83      RESFLG    C
0176 9E08      RET
          ! CHECK FOR ABORT !
ABRT:
0178 0A09      CPB       RL1,#'9'
017A 3939
017C E602      JR        Z,ENDIT      ! YES, ABORT... !
017E D050      CALR      RECMSG      ! GET ANOTHER CHR !
0180 E8EC      JR        GETACK      ! TRY AGAIN.... !
          ENDIT:
0182 D070      CALR      SKIPLN
0184 9D43      RESFLG    Z
0186 8D81      SETFLG    C
0188 9E08      RET
018A          END GETACK

```

```

018A LINRCT PROCEDURE
!*****
*
* LINRCT: RECEIVES LINE OF CHAR FROM *
* MCZ AFTER RECEIPT OF '/' *
* AND STORES IN INTBUF, ADDING *
* CR AT END AND FILTERING OUT *
* CONTROL CHARACTERS. (<20H) *
* (TRUNCATES AFTER 80 CHAR) *
*
*****!
ENTRY
! WAIT FOR ASCII / !
018A D056 CALR RECMSG
018C 0A08 CPB RL0,'#/'
018E 2F2F
0190 EEFC JR NZ,LINRCT ! WAIT !
! BEGIN STORING CHARACTERS !
0192 76E4 LDA R4,INTBUF(R14)
0194 0000
0196 CB50 LDB RL3,#80 !SET LINE LENGTH !
! STORE CHAR IN INTBUF !
LOPSTR:
0198 D05D CALR RECMSG ! GET CHAR !
019A 2E48 LDB GR4,RL0 ! STORE !
019C 0A08 CPB RL0,#CR ! CK FOR END !
019E 0D0D
01A0 EE02 JR NZ,SKPSOM ! GOT CHAR.. !
01A2 D07C CALR SKPB
01A4 9E08 RET
!CONTROL CHAR FILTERED AND DEC LINE COUNTER !
SKPSOM:
01A6 0A08 CPB RL0,'#'
01A8 2020
01AA E7F6 JR C,LOPSTR
01AC 1940 INC R4,#1 ! GOOD CHAR !
01AE FB0C DEJNZ RL3,LOPSTR ! DEC COUNT !
!TRUNCATE, TOO MANY CHAR !
LOPOVR:
01B0 D069 CALR RECMSG
01B2 0A08 CPB RL0,#CR ! LOOK FOR CR !
01B4 0D0D
01B6 EEFC JP NZ,LOPOVR
01B8 76ED LDA R13,INTBUF(R14)
01BA 0000
01BC 010D ADD R13,#80
01BE 0050
01C0 2ED8 LDB GR13,RL0

```

```

01C2 9E08      RET
01C4           END LINRCT

01C4           UNPACK  PROCEDURE
!*****
*
*   UNPACK: UNPACKS RECEIVED PACKETS
*           FROM MCZ IN INTBUF AND
*           LOADS IN SPECIFIED MEMORY
*           AREA. ASCII CHAR ARE CON-
*           VERTED TO HEX VALUES.
*
*   REG USE: INPUT  RH3 = #BYTE DATA
*****!
ENTRY
01C4 A03C      LDB      RL4,RH3      ! SAVE COUNT !
01C6 DFDF      CALR     CONVAD      ! CONV START ADR !

! CHECK FOR USER ENTERED ADDR FOR LOAD !
01C8 0B0B      CP       R11,%FFFFE
01CA FFFE
01CC E601      JR       Z,USE_MCZADR
01CE A1B1      LD       R1,R11      ! USER SPECIFIED !

USE_MCZADR:
01D0 76E2      LDA      R2,INTBUF(R14)
01D2 0000
01D4 A927      INC      R2,#8

CANDS:
01D6 DFF8      CALR     TRNHEX      ! CONVERT 2-ASCII CHR !
01D8 2E18      LDB      @R1,RL0    ! STORE IN MEM !
01DA 4910      INC      R1,#1
01DC FC04      DEJNZ    RL4,CANDS   ! CONV AND STORE ALL !

! UPDATE USER SPECIFIED ADDRESS !
01DE 0B0B      CP       R11,%FFFFE
01E0 FFFE
01E2 E601      JR       Z,NO_UPDATE ! USE MCZ ADR !
01E4 A11B      LD       R11,R1     ! UPDATE USER ADR !

NO_UPDATE:
01E6 9E08      RET
01E8           END UNPACK

```

01E8

TRNHEX PROCEDURE

```

*****
*
*   TRNHEX: CONVERTS TWO ASCII CHAR FRM *
*           INTBUF TO TWO 4-BIT HEX # *
*           AND ADD TO CKSUM. *
*
*   REG USE: INPUT  R2 = PTR TO 1ST CHR *
*                   RL3= CKSUM ACCUM *
*   RETURN  R2 = UPDATE PTR *
*           RL3= UPDATED ACCUM *
*           RL0= HEX VALUE *
*           AND C IF NON-ASCII *
*           NC IF ALL GOOD *
*
*****!

```

ENTRY

```

01E8 DFF6 CALR    ATOHEX    ! CONVERT 1ST CHR !
01EA 9E07 RET      C
01EC 808B ADDB    RL3,RL0   ! ADD TO CKSUM !
01EE B309 SLA     R0,#12    ! MOVE TO H NIBBLE !
01F0 000C
01F2 DFFB CALR    ATOHEX    ! CONVERT 2ND CHR !
01F4 9E07 RET      C
01F6 808B ADDB    RL3,RL0
01F8 8408 ORB     RL0,RH0   ! COMBINE NIBBLES !
01FA 8D83 RESVLG  C
01FC 9E08 RET
01FE
END TRNHEX

```

01FE

ATOHEX PROCEDURE

```

*****
*
*   ATOHEX: CONVERTS ONE ASCII CHAR TO *
*           4-BIT HEX NIBBLE. *
*
*   REG USE: INPUT  R2 = PTR TO CHR *
*           RETURN  R2 = PTR + 1 *
*           RL0= HEX NIBBLE *
*
*****!

```

ENTRY

```

01FE 2028 LDB     RL0,R2
0200 A920 INC     R2,#1      ! INC PTR !
0202 34CA LDA     R10,R12(#CONVERT)
0204 0000*
0206 1FA0 CALL    GR10
0208 9E08 RET
020A
END ATOHEX

```

020A

CONVAD PROCEDURE

```

!*****
*
* CONVAD: CONVERTS STARTING ADDRESS
* OF PACKET DATA TO HEX #.
*
* REG USE: RETURN R1 = ADDRESS(HEX)
*
*****!

```

ENTRY

```

020A 76E2 LDA R2,INTBUF(R14)
020C 0000
020E D014 CALR TRNHEX
0210 A081 LDB RH1,RL0 ! STORE 1ST BYTE !
0212 D016 CALR TRNHEX
0214 A089 LDB RL1,RL0 ! STORE 2ND BYTE !
0216 9E08 RET
0218 END CONVAD

```

0218

CHKPAK PROCEDURE

```

!*****
*
* CHKPAK: CK RECEIVED MCZ PAC CKSUM
* AGAINST ACCUMULATED HEX
* VALUE CKSUM AFTER ASCII-TO-
* HEX CONVERSION.
*
* REG USE: RETURN RH3 = BYTE COUNT
* AND C IF BAD OR
* NON-ASCII.
*
*****!

```

ENTRY

```

0218 76E2 LDA R2,INTBUF(R14)
021A 0000
021C C303 LDB RH3,#3
021E DFF9 CALR CHKSUM ! CK 1ST CKSUM !
0220 9E07 RET C ! BAD CK !
0222 8C34 TESTB RH3
0224 9E06 RET Z ! NO DATA !
0226 93F3 PUSH QR15,R3 ! SAVE BYTE COUNT !
0228 DFFE CALR CHKSUM ! CK 2ND CKSUM !
022A 97F3 POP R3,QR15
022C 9E08 RET
022E END CHKPAK

```

022E

CHKSUM PROCEDURE

```

!*****
*
*   CHKSUM: CONVERTS ALL REC ASCII CHR
*           IN PAC TO HEX AND ACCUM NEW
*           CKSUM. COMPARE CKSUMS AND
*           REPORT DIFFERENCES.
*
*   REG USE: INPUT  R2 = PTR TO PAC
*                   RH3= # CHR PAIRS
*                   RETURN RH3= BYTE COUNT
*                   RL3= NEW CKSUM
*                   RH3= REC CKSUM
*                   AND C IF BAD OR
*                   NON-ASCII REC
*
*****

```

ENTRY

022E 9CB8	CLRB	RL3	! RESET CKSUM !
0230 DC25	AB:CALR	TRNHEX	! CONVERT PAIRS !
0232 9E07	RET	C	
0234 F303	DEJNZ	RH3,AB	! CONTINUE..... !
0236 A063	LDB	RH3,RL0	
0238 93F3	PUSH	QF15,R3	! SAVE BYTE CNT !
023A D02A	CALR	TRNHEX	! CONVERT NEXT TWO !
023C 97F3	POP	R3,QF15	
023E 9E07	FET	C	
0240 8AB8	CPB	RL0,RL3	! COMPARE CKSUMS !
0242 9E06	RET	Z	! GOOD CK... !
0244 8D61	SETFLG	C	! BAD CKSUM !
0246 9E08	RET		
0248	END CHKSUM		

0248

GLOBAL

LOADFL PROCEDURE

```

!*****
*
*   LOADFL: RECEIVES PACKET FROM MCZ IN
*           FOLLOWING FORMAT:
*
*   <ADR><CNT><CKS1><DTA>...<DTA><CKS2>
*
*   ADR = START ASR IN 28000 MEM
*   CNT = # DATA WORDS
*   CKS1= CKSUM OF <ADR> + <CNT>
*   <DTA>...<DTA> = 30 DATA WORDS
*   CKS2= CKSUM OF DATA HEX VALUES
*
*   PROCEDURE VERIFIES CKSUMS BEFORE
*   STORING DATA IN 28000 MEM. PACKETS
*   ARE ACK FOR WITH: '0' = GOOD
*                   '7' = RESEND
*                   '9' = ABORT
*   IF REC '//' FROM MCZ, ECHOS WHAT
*   REC NEXT TO CONSOLE AND ABORT.
*
*****!

```

ENTRY

0248 D125	CALR	FNAME	! CK FILENAME !
024A 65E4	SET	MFLAGS(R14),#LDMDE	!SIGNAL LOAD IN !
024C 031C			
			!PROGRESS!
024E D109	CALR	CMDPAS	! SND CMD TO MCZ !
0250 9E06	RET	Z	! 280 PROG NO LOAD !
	RECLOP:		
0252 D065	CALR	LINRCT	! GET PACKET !
0254 76E2	LDA	R2,INTBUF(R14)	
0256 0000			
0258 2028	LDB	RL0,GR2	
025A 0A08	CPE	RL0,#'/'	! CK FOR '//' !
025C 2F2F			
025F FE10	JR	NZ,CONTIN	INO, CONTINUE...!
0260 76E1	LDA	R1,OUTBUF(R14)	!YES,!
0262 0080			
0264 2103	LD	R3,#%20	
0266 0020			
0268 BB21	LDIR	GR1,GR2,R3	!ERROR MSG SETUP !
026A 0310			
026C 76E1	LDA	R1,OUTBUF(R14)	
026F 0080			
0270 0101	ADD	R1,#%20	
0272 0020			


```

0274 6FF1      LD      OUTPTR(R14),R1 !SET OUTPTR !
0276 0306

0278 34CA      LDA      R10,R12(#PBUFNC)
027A 0000*
027C 1FA0      CALL     GP10
027E 9E08      RET

CONTIN:
0280 6735      BIT      MFLAGS(R14),#ESC    ! CK FOR ABORT !
0282 031C
0284 EE34      JR      NZ,ABT                ! YES, ABORT...!
0286 D038      CALR     CHKPAK                ! CK CKSUMS !
0288 EF02      JR      NC,GDLD                ! GOOD LOAD !
028A D0A8      CALR     BADPAK                ! SEND NON-ACK !
028C E8E2      JR      RECLOP                ! TRY AGAIN !

! CHECK FOR LAST PACKET AND PRINT <ENT ADR> !
GDLD:
028E 8C38      CLR3
0290 8138      ADD      R8,R3    ! ACCUM NUMBER BYTES !
                                ! OF TRANSFER !

0292 8C34      TESTB    RH3                ! CK COUNT=0 !
0294 EE28      JR      NZ,STOR                ! OK, BEGIN STR !
0296 D0AA      CALR     GODPAK                ! SEND GOOD ACK !
0298 54E0      LDL      RR0,INTBUF(R14)
029A 0000
029C 76ED      LDA      R13,OUTBUF(R14)
029E 0080
02A0 010D      ADD      R13,#%0C
02A2 000C

! CHECK FOR USER SPECIFIED ADDR !
02A4 0B09      CP      R9,#%AAAA
02A6 AAAA
02A8 E61D      JR      Z,END_LOAD    ! NO ECHO TO CONS !
02AA 0B0B      CP      R11,#%FFFE    ! CK FOR LOAD ADR !
02AC FFFE
02AE F608      JR      Z,SAME_ADR    ! USE MCZ ADR !
02B0 6FED      LD      OUTPTR(R14),R13 ! SET OUTBUF ADR !
02B2 0306
02B4 61E5      LD      R5,ADR_STR(R14) ! GET USER ADR !
02B6 0344
02B8 76CA      LDA      R10,CONVW(R12)
02BA 0000*
02BC 1FA0      CALL     GP10    ! CONVERT TO ASCII AND !
                                ! AND STORE IN OUTBUF !
02BE F801      JR      FIN_BUF
SAME_ADR:

```

```

02C0 1DD0      LDL      GR13,RR0

      FIN_BUF:
02C2 3402      LDAB     P2,ENTADR      !LOAD ENTRY LABEL!
02C4 0040
02C6 76E1      LDA      R1,OUTBUF(R14)
02C8 0080
02CA 2100      LD       R0,#6
02CC 0006
02CE 9B21      LDIB     GR1,GR2,R0
02D0 0010
02D2 76ED      LDA      R13,OUTBUF(R14)
02D4 0080
02D6 010D      ADD      R13,#%10
02D8 0010
02DA 6FED      LD       OUTPTR(R14),R13
02DC 0306
02DE 34CA      LDA      R10,R12(#PRNTEF)
02E0 0000*
02E2 1FA0      CALL     GR10           ! PRINT MESSAGE !
      END_LOAD:
02E4 9E08      RET

      STOR:
02E6 D06F      CALR     CONVAD
02E8 D0D3      CALR     GODPAK      ! SEND ACK !
02EA D094      CALR     UNPACK      ! UNPACK AND STORE !
02EC E8B2      JR       RECLOP      ! CONTINUE....!

      ABT:
02EE 3402      LDAR     R2,EMSG
02F0 000A
02F2 34CA      LDA      R10,R12(#SNDMSG)
02F4 0000*
02F6 1FA0      CALL     GR10           ! SEND MESSAGE !
02F8 D0DD      CALR     ABORTM      ! SEND ABORT !
02FA 9E08      RET

02FC          END_LOADFL

      EMSG:
02FC 07        BVAL     7
02FE 2F41      WVAL     '/A'
0300 424F      WVAL     'BO'
0302 5254      WVAL     'RT'
0304 0D        BVAL     %0D
      ENTADR:
0306 454E      WVAL     'EN'
0308 5452      WVAL     'TR'
030A 5920      WVAL     'Y'

```

030C	504F	WVAL	'PO'
030E	494E	WVAL	'IN'
0310	5420	WVAL	'T'

END LOAD_CMD

4. REGISTER MODULE

28000ASM 2.02
 LOC OBJ CODE STMT SOURCE STATEMENT

```

1 REGISTER_CMD MODULE
$LISTON $TTY
!*****
*
* REGISTER CMD: DISPLAYS CONTENTS OF
* ALL USER (') REGS OR
* EACH REGISTER INDIVIDUALLY IN THE
* SUBSTITUTION MODE. A 'Q' ENDS THE
* SESSION; A CP ADVANCES IN ORDER
* THROUGH REG CONTENTS WITHOUT ANY
* CHANGES; AND A VALID HEX ENTRY
* WILL ALTER THE REGISTERED CONTENTS.
*
* SYNTAX: REGISTER [<REG NAME>]
*
*****!
```

```

EXTERNAL EROR LABEL
EXTERNAL GETCHR PROCEDURE
EXTERNAL STOBUF PROCEDURE
EXTERNAL DISP PROCEDURE
EXTERNAL PRNTBF PROCEDURE
EXTERNAL CONVB LABEL
EXTERNAL GETNXT PROCEDURE
EXTERNAL DISPNC LABEL
EXTERNAL CONVW PROCEDURE
```

```

$SECTION REGISTER_PROC
$REL 0
```

```

0000 30 20      LKTB ARRAY [* BYTE]:='0 1 2 3 4 5
              6 7 8 9 101112131415PCFCRLRH'
0002 31 20
0004 32 20
0006 33 20
0008 34 20
000A 35 20
000C 36 20
000E 37 20
```

```

0010 38 20
0012 39 20
0014 31 30
0016 31 31
0018 31 32
001A 31 33
001C 31 34
001E 31 35
0020 50 43
0022 46 43
0024 52 40
0026 52 48

```

```

GLOBAL
PRREG2 LABEL
PRREG1 PROCEDURE
0026
!*****
*
* PRREG1: OUTPUT CONTENTS OF USER
* REGISTERS 0-13 TO CONS.
*
* PRREG2: OUTPUTS CONTENTS OF USER
* REGS R14,R15,RPC,RFC.
*
*****!
ENTRY
0028 BD6E LDK R6,#14 ! SET # REGS !
002A 34F1 LDA R1,R14(#R0_) ! LOAD BASE ADR !
002C 031E
002E F803 JR PLOOP

! PRREG2 ENTRY POINT !
PRREG2:
0030 BD64 LDK R6,#4 ! SET 2ND LINE REG # !
0032 34F1 LDA R1,R14(#R14_) ! LOAD BASE ADR !
0034 033A

! MAIN PRINT LOOP !
PLOOP:
0036 2115 LD R5,R1
0038 34C4 LDA R10,R12(#CONVW) ! CONVERT HEX TO !
003A 0000*
003C 1FA0 CALL GR10
! ASCII !
003E AB60 DEC R6,#1 ! DONE? !
0040 E604 JR Z,PRNT ! OUTPUT IF YES !
0042 69E0 INC OUTPTR(R14),#1
0044 0306
0046 A911 INC R1,#2 ! GET NEXT REG ADR !
0048 F8F6 JR PLOOP ! LOOP !

```

```

PRNT:
004A 34CA LDA R10,R12(#PRNTBF)
004C 0000*
004E 1EAB JP GR10

0050 END PRREG1

GLOBAL
RGHDR2 LABEL
0050 RGHDR1 PROCEDURE
!*****
*
* RGHDR1: OUTPUT HEADER FOR REGISTERS *
* R0 - R13. *
*
* RGHDR2: OUTPUT HEADER FOR REGISTERS *
* R14, R15, RPC, RPC. *
*
*****!
ENTRY
0050 BD0E LDK R0,#14 ! SET PRINT COUNT !
0052 3405 LDAR R5,LKTBL
0054 FFAA
0056 E805 JR HLOOP

! SECOND HEADER ENTRY POINT !
RGHDR2:
0058 ED04 LDK R0,#4 ! SET PRINT COUNT !
005A 3405 LDAR R5,LKTBL
005C FFA2
005E 0105 ADD R5,#28
0060 001C

! MAIN PRINT LOOP !
HLOOP:
0062 31E2 LD R2,R14(#OUTPTR) ! LOAD OUTBUF INDEX !
0064 0306
0066 0C25 LDB GR2,#'R'
0068 5252
006A 69E0 INC OUTPTR(R14)
006C 0306
006E 2151 LD R1,GR5 ! GET CHR FROM TABLE !
0070 DFFA CALR STOBUF ! STORE IN OUTBUF !
0072 AB00 DEC R0,#1 ! DONE? !
0074 E6EA JR Z,PRNT ! YES, OUTPUT BUFFER !
0076 69E1 INC OUTPTR(R14),#2 ! NO, CONTINUE!
0078 0306
007A A951 INC R5,#2 ! ADVANCE TABLE INDEX!
007C E8F2 JR HLOOP

```

007E END RGHDR1

007E GLOBAL
STOBUF PROCEDURE

```
!*****
*
*   STOBUF: STORES CONTENTS OF REGISTER *
*           INTO OUTBUF AND INCREMENTS *
*           OUTPTR.                   *
*
* REG USE: INPUT   R1 = CONTENTS       *
*
*****!
```

ENTRY

```
007E 93F4       PUSH       GR15,R4       ! SAVE WORK REG !
0080 61E4       LD         R4,OUTPTR(R14)
0082 0306
0084 2E41       LDB        GR4,RH1       ! STR 1ST BYTE !
0086 A940       INC        R4
0088 2E49       LDB        GR4,PL1       ! STR 2ND BYTE !
008A 69E1       INC        OUTPTR(R14),#2
008C 0306
008E 97F4       POP        R4,GR15       ! RESTORE WRK REG !
0090 9E08       RET
0092       END STOBUF
```

0092 GLOBAL
REGISTER PROCEDURE

```
!*****
*
*   REGISTER: DISPLAY AND ALLOW CHANGE *
*           OF USER REGISTERS.       *
*
* REG USE: INPUT   ALL               *
*           RETURN SAME               *
*
*****!
```

ENTRY

```
0092 340B       LDAR       R11,LKTBL
0094 FF6A
0096 34CA       LDA        R10,R12(#GETNXT)
0098 0000*
009A 1FA0       CALL       GR10        ! SKIP REST CMD !
009C FF01       JR         NZ,AM
009E E85E       JR         PRNTAL

00A0 0A08       AM:CPB       RL0,#'R'
00A2 5252
00A4 EE22       JR         NZ,GLOBER
! CHECK DISPLAY MODE - R, RR, RH, RL !
```

```

00A6 34CA      LDA      R10,R12(#GETCHR)
00A8 0000*
00AA 1FA0      CALL     QR10          ! GET NXT CHR !
00AC E61E      JR       Z,GLOBER      ! ERROR !
00AE A08E      LDB      RL6,RL0       ! GET FIRST CHR !
00B0 0A08      CPB      RL0,#'R'      ! CK FOR 'RR' !
00B2 5252
00B4 E608      JR       Z,PEGID       ! YES, GET REG ID !
00B6 8C68      CLRB     RH6
00B8 0A28      CPB      RL0,#'L'      ! IS LOW BYTE? !
00BA 4C4C
00BC E604      JR       Z,REGID       ! YES, GET REG ID !
00BE C602      LDB      RH6,#2
00C0 0A08      CPB      RL0,#'H'      ! IS HIGH BYTE? !
00C2 4848
00C4 EF04      JR       NZ,SAVID

! GET REGISTER ID NUMBER !
REGID:
00C6 34CA      LDA      R10,R12(#GETCHR)
00C8 0000*
00CA 1FA0      CALL     QR10          ! GET 1ST CHAR !
00CC E60E      JR       Z,GLOBER
SAVID:
00CE A081      LDB      RH1,RL0
00D0 34CA      LDA      R10,R12(#GETCHR)
00D2 0000*
00D4 1FA0      CALL     QR10          ! GET 2ND CHR !
00D6 EF02      JR       NZ,SAVID2
00D8 C920      LDB      RL1,#' '      ! PAD WITH SPACE !
00DA E801      JR       FNDNAM
SAVID2:
00DC A089      LDB      RL1,RL0       ! SAVE BOTH DIGITS !
! FIND REG ID IN REG LOOKUP TABLE !
FNDNAM:
00DE 2108      LD       R8,#18        ! TABLE LENGTH !
00E0 0012
00E2 11B9      LD       R9,R11        ! BASE OF LKUP TBL !
00E4 BB94      CPIR      R1,QR9,R8,EQ ! LOOK FOR MATCH !
00E6 0816
00E8 E603      JR       Z,AJ
GLOBER:
00EA 34CA      LDA      R10,R12(#EROR)
00EC 0000*
00EE 1EAB      JP       QR10
00F0 AB91      AJ:DEC    R9,#2         ! ADJUST CORRECT ADR!
00F2 2102      LD       R2,#17        ! DETERMINE REG MEM !

```



```

00F4 0011
00F6 8382      SUB      R2,R8      ! INDEX !
00F8 0128      LD       R8,R2
00FA B381      SLL      R8,#1
00FC 0001

! DETERMINE DISPLAY MODE OUTLINE !
00FE 0A0E      CPB      RL6,#'H'  ! RL6=MODE !
0100 4848
0102 E65E      JR       Z,BYT      ! BYT MODE !
0104 0A0E      CPB      RL6,#'L'
0106 4C4C
0108 E65B      JR       Z,BYT      ! ALSO BYTE MODE !
010A 0A0E      CPB      RL6,#'R'
010C 5252
010E E628      JR       Z,LWORD    ! LONG WORD MODE !

```

! SINGLE WORD DISPLAY MODE ROUTINE !
SWORD:

```

0110 2101      LD       R1,#'R'
0112 5220
0114 D04C      CALR     STOBUF      ! STORE IN OUTBUF !
0116 63E0      DFC      OUTPTR(R14),#1
0118 0306
011A 2191      LD       R1,GR9      ! STORE REG ID !
011C D050      CALR     STOBUF
011E 69E0      INC      OUTPTR(R14),#1  ! ADD SPACE !
0120 0306
0122 34ED      LDA      R13,R14(#R0_)
0124 231E
0126 71D5      LD       R5,R13(R8)
0128 0800
012A 34CA      LDA      R10,R12(#DISP)
012C 0000*
012E 1FA0      CALL     GR10        ! OUTPUT TO CONS !
0130 9E07      RET      C          ! REC '0' !
0132 E60A      JR       Z,SAME      ! REC CR, STAYS SAME !
0134 2192      LD       R2,GR9
0136 34BA      LDA      R10,R11(#34)
0138 0022
013A 8BA2      CP       R2,R10
013C EE01      JF       NZ,JMPOVR   ! NOT PC REG !
013E A330      RES      R3,#0      ! CHG TO EVEN ADR !

```

JMPOVR:

```

0140 76ED      LDA      R13,R0_(R14)  ! CHG REG CONTENTS !
0142 031E
0144 73D3      LD       R13(R8),R3
0146 0800

SAME:
0148 A981      INC      R8,#2      ! ADJ REG INDEX !

```

```

314A A991      INC      R9,#2      ! ADJ TABLE ADR !
014C 34B3      LDA      R3,R11(#35) ! GET END OF TBLE !
014E 0023
0150 8B39      CP       R9,R3      ! END OF TABLE? !
0152 F7DE      JR       C,SWORD    ! NO, CONTINUE...!
0154 9E08      RET

```

! ROUTINE TO PRINT ALL HEADERS AND CONTENTS !
 PRINTAL:

```

0156 D084      CALR     RGHDR1
0158 D099      CALR     PRREG1
015A D082      CALR     RGHDR2
015C D097      CALR     PRREG2
015E 9E08      RET

```

! LONG WORD DISPLAY MODE ROUTINE !
 LWORD:

```

0160 A1BD      LD       R13,R11    ! R15 ADDR !
0162 010D      ADD      R13,#30
0164 001E
0166 8BD9      CP       R9,R13
0168 EFC0      JR       NC,GLOBER   ! RR0 - RR14 OK !
016A 0A09      CPE      R1,#' '    ! CK IF DIGIT REG !
016C 2020
016E E602      JR       Z,EVNCK
0170 A710      BIT      R1,#0      ! CK IF 2ND CHR EVEN !
0172 E801      JR       OVER
EVNCK:
0174 A718      BIT      R1,#8
OVER:
0176 EEB9      JR       NZ,GLOBER

```

! LONG WORD DISPLAY MODE ROUTINE !
 LWLOOP:

```

0178 2101      LD       R1,#'RR'
017A 5252
017C D080      CALR     STOBUFF     ! STORE IN OUTBUF !
017E 2191      LD       R1,GR9
0180 1FA0      CALL     GR10      ! ADD REG ID !
0182 69E0      INC      OUTPTR(R14),#1 ! ADD SPACE !
0184 0306
0186 34E4      LDA      R4,R14(#R0_) ! LOAD 1ST WORD !
0188 031E
018A 7145      LD       R5,R4(R8)
018C 0800
018E 34CA      LDA      R10,R12(#CONVW)
0190 0000*
0192 1FA0      CALL     GP10      ! CONVERT 1ST !
0194 A941      INC      R4,#2
0196 7145      LD       R5,R4(R8) ! LOAD 2ND WORD !

```

```

0198 0870
019A 34CA      LDA      R10,R12(#DISP)
019C 0000*
019F 1FA0      CALL     GR10
01A0 9E07      RET      C
01A2 E607      JR       Z,AROUND      ! REC CR, NO CHG !
01A4 34E4      LDA      R4,R14(#R0_)
01A6 031E
01A8 7342      LD       R4(R8),R2
01AA 0800
01AC A941      INC      R4,#2
01AE 7343      LD       R4(R8),R3
01B0 0800

```

```

AROUND:
01B2 A983      INC      R8,#4
01B4 A993      INC      R9,#4      ! INCREMENT TO NEXT RR !
01B6 34B3      LDA      R3,R11(#16)
01B8 0010
01BA 8B39      CP       R9,R3      ! FINISHED? !
01BC E7DD      JR       C,LWLOOP
01BE 9E08      RET      ! DONE !

```

```

! BYTE DISPLAY ROUTINE !
BYT:
01C0 A1B4      LD       R4,R11
01C2 A947      INC      R4,#8
01C4 8B49      CP       R9,R4      ! CK IF REG >P7 !
01C6 EF91      JR       NC,GLOBER
01C8 B361      SPL      R6,#8
01CA FFF8
01CC EE01      JR       NZ,THRU
01CE A980      INC      R8

```

```

THRU:
01D0 A1B4      LD       R4,R11
01D2 0104      ADD      R4,#18
01D4 0012
01D6 7141      LD       R1,R4(R6)
01D8 0600
01DA D0AF      CALF     STOBUF      ! STORE IN OUTBUF !
01DC 2191      LD       R1,GR9
01DE 1FA0      CALL     GR10
01E0 31E4      LD       R4,R14(#R0_)
01E2 031E
01E4 724D      LDB      RL5,R4(R8)
01E6 0800
01E8 34CA      LDA      R10,R12(#CONVB)
01EA 0000*
01EC 1FA0      CALL     GR10      ! CONVERT WORD !

```

```

01EE 69E0      INC      OUTPTR(R14),#1
01F0 0306
01F2 34CA      LDA      R10,R12(#DISPNC)
01F4 0000*
01F6 1FA0      CALL     GR10      ! OUTPUT, CK FOR INPUT !
01F8 9E07      RET       C          ! FINISHED, PEC 'Q' !
01FA E604      JR        Z,ABA      ! REC CR. STAYS SAME !
01FC 34E4      LDA      R4,R14(#R0_)
01FE 031E
0200 724B      LDB      R4(R8),RL3
0202 0800

```

ABA:

```

0204 A980      INC      R8,#1
0206 AB61      DEC      R6,#2      ! INCREMENT INDEXES !
0208 E6E3      JR        Z,THRU     ! OUTPUT LOW BYTE !
020A 2106      LD        R6,#2
020C 0002
020E A991      INC      R9,#2      ! GET NEXT BYTE GRP !
0210 A1B3      LD        R3,R11
0212 A937      INC      R3,#8
0214 8B39      CP        R9,R3      ! CK FOR END !
0216 E7DC      JR        C,THRU     ! NO. CONTINUE...!
0218 9E08      RET          ! YES. !

```

```

021A      END REGISTER
          END REGISTER_CMD

```

5. DISPLAY MODULE

Z8000ASM 2.02
 LOC OBJ CODE STMT SOURCE STATEMENT

1 DISPLAY_CMD MODULE
 \$LISTON \$TTY

```

!*****
*
*   DISPLAY CMD: DISPLAYS CONTENTS OF
*                   SPECIFIED MEMORY LOC
*   WITH ABILITY TO CHANGE CONTENTS
*   OF MEM.AS PER <CNT>. CONTENTS
*   ARE DISPLAYED 16-BYTES/LINE WITH
*   SPACE BETWEEN BYTES/WORDS/LWORDS
*   AS SELECTED [B/W/L]. WITHOUT
*   COUNT.CONTENT IS DISPLAYED IN
*   UNIT B/W/L. ENTERED DATA WILL
*   CHG CONTENTS; CR WILL NOT; AND
*   'O' WILL EXIT CMD.
*
*   FILL: STORES GIVEN DATA(WORD)
*         IN ALL INCLUSIVE MEMORY LOC
*         DEFINED BY <BGN ADR> AND
*         <END ADR>.
*
*   MOVE: MOVES BLOCK OF DATA AS
*         DEFINED BY SIZE <SIZ> FROM
*         START ADR <SCR> TO DEST.
*         ADR <DST>.
*
*   SYNTAX: DISPLAY <ADR>[<CNT>][B/W/L]
*           MOVE <SCR> <DST> <SIZ>
*           FILL <BGN ADR><END ADR><WD>
*
*****!
```

CONSTANT

(INCLUDE GLOBAL CONSTANTS)

EXTERNAL EROR LABEL
 EXTERNAL ASCHEX PROCEDURE

```

GLOBAL
$SECTION DISPLAY_PROC
$REL 0

```

```

0000 GLOBAL
SKPBLK PROCEDURE
!*****
*
* SKPBLK: SKIP OVER BLANKS TO NEXT
* CHARACTER.
*
* REG USE: RETURN RLO = 1ST NON-BLK
* CHAR AND Z IF =CR
*
*****!
ENTRY
! SKIP OVER BLANKS TO NEXT ARGUMENT !
0000 DF30 CALR GETCHR
0002 9F06 PET Z ! GOT CR !
0004 0A08 CPB RLO,#' ' ! CK FOR BLANK !
0006 2020
0008 E6FB JR Z,SKPBLK ! YES.....!
000A 9F08 RET ! GOT CHAR !

```

```

000C END SKPBLK

```

```

000C GLOBAL
GETADR PROCEDURE
!*****
*
* GETADR: GETS NEXT ARGUMENT AND
* CONVERTS TO HEX ADDRESS.
*
* REG USE: INPUT RLO = 1ST CH OF ARG
* RETURN R3 = HEX ADR
* AND Z,C IF CR ONLY
* Z,NC IF ARG,CR
* NZ,NC IF ARG,SP
*
*****!
ENTRY
! CK FOR CR ONLY !
000C 8D38 CLR R3
000E 0A08 CPB RLO,#CR ! CK FOR CR !
0010 0D0D
0012 EE02 JR NZ,NOTCR
0014 8D81 SETPLG C
0016 9E08 RET ! RETURN FOR CR ONLY !

```

AD-A109 552


NAVAL POSTGRADUATE SCHOOL MONTEREY CA
SASS HARDWARE ARCHITECTURE AND DEVELOPMENTAL MONITOR.(U)
JUN 81 G S BAKER
NPS52-81-016

F/G 9/2

UNCLASSIFIED

NL

2 of 3
Page 1 of 3




```

!CONVERT ASCII ADDRESS TO HEX ADDRESS !
NOTCR:
0018 DFE2    CALR    CONVERT    !BYTE TO 4-BIT HEX !
001A E70A    JR      C,REPERR   ! GOT BAD CHR !
001C FEB8    RLDB    RL0,RL3
001F BE38    RLDB    RL0,RH3    !SHFT LEFT TO MSW !
0020 DFF0    CALR    GETCHR     ! GET CHR FROM INTBUF!
0022 9E06    RET     Z
0024 0A06    CPB     RL0,#' '    !CK FOR SPACE !
0026 2020
0028 EEF7    JR      NZ,NOTCR   ! IF NOT, CONT.....!
002A D016    CALF    SKPBLK     ! SKIP TO NEXT ARG !
002C 2D83    RESFLG  C
002E 9E08    RET

```

```

REPERR:
0030 34CA    LDA     R10,R12(#ERCR)
0032 0000*
0034 1FA8    JP      QF10
0036        END GETADR

```

```

GLOBAL
0036 GETNXT PROCEDURE
!*****
*
*   GETNXT: SKIP TO BEGINING OF NEXT
*           ARGUMENT IN COMMAND.
*
*   REG USE:  PRTURN  RL0 = CHAR OR CR
*              AND Z IF = CR
*
*****!
ENTRY
! SKIP OVER CURRENT ARGUMENT TO NEXT SPACE !
0036 DFFB    CALR    GETCHR
0038 9E06    RET     Z          ! RTN IF CH=CR !
003A 0A08    CPB     RL0,#' '    ! FIND FIRST SPACE !
003C 2020
003E EEF3    JR      NZ,GETNXT
0040 E8DF    JR      SKPBLK     ! NOW SKIP BLANKS !

0042        END GETNXT

```

```

GLOBAL
0042  GETCHR  PROCEDURE
*****
*
*   GETCHR: GETS NEXT CHR FROM INTBUF
*           AND INCREMENTS INTPTR.
*
*   REG USE: RETURN  RL0 = CHR
*               AND Z IF CR
*
*****!
ENTRY
0042  93F2    PUSH    GR15,R2      ! SAVE WORK REG !
0044  61F2    LD      R2,INTPTR(R14)
0046  0304
0048  2028    LDB     RL0,GR2      ! GET CHR !
004A  69E0    INC     INTPTR(R14),#1  ! INC PTR !
004C  0304
004E  0A08    CPB     RL0,#CR      ! CK FOR CR !
0050  0D0D
0052  97F2    POP     R2,GR15
0054  9E08    RET
0056                END GETCHR

```

```

GLOBAL
0056  CONVERT  PROCEDURE
*****
*
*   CONVERT: CONVERTS 8-BIT ASCII CHR
*           TO 4-BIT HEX VALUE. VALID
*           CHR IS 0-9 OR A-F; IF NOT
*           CHR, EXIT TO EXEC EROR.
*
*   REG USE: INPUT  RL0 = 8-BIT ASCII
*               RETURN RL0 = 4-BIT HEX IN
*                   LSW.
*
*****!
ENTRY
! CHECK FOR VALID CHAR !
0056  0A08    CPB     RL0,#'0'      ! FILTER <'0' ASCII !
0058  3030
005A  9E07    RET     C              ! ERROR !
005C  0A08    CPB     RL0,#'9'+1    ! CK IF DIGIT !
005E  3A3A
0060  E708    JR      C,NOFIX
0062  0A08    CPB     RL0,#'A'      ! FILTER <'A' ASCII !
0064  4141
0066  9E07    RET     C
0068  0A08    CPB     RL0,#'F'+1    ! FILTER >'F' ASCII !

```

```

006A 4747
006C EF06      JP      NC.PETSIG      !ERROP!
006E 0208      SUBB     RL0,#7        ! ALPHA ADJUST !
0070 07C7

NOFIX:
0072 0608      ANDB     RL0,#%0F      ! GET LOW NIBBLE !
0074 0F0F
0076 8D83      PESFLG    C
0078 9E08      RET
                                ! RTN HEX VALUE !
PETSIG:
007A 8D81      SETFLG    C
007C 9E08      RET
                                ! RTN FOR BAD CHR !

007E      END CONVERT

GLOBAL
      PEUFNC LABEL
007E      PRNTBF PROCEDURE
!*****
*
*   PRNTBF: PRINT CONTENTS OF OUTBUF
*           TO CONS WITH CR AT END.
*
*   PBUFNC: PRINT BUFFER CONTENTS WITH
*           NO CR.
*
*****!
ENTRY
! STORE CR IN OUTBUF !
007E 61E2      LD        R2,OUTPTR(R14)
0080 0306
0082 0C25      LDB        CR2,#CR
0084 0D0D
0086 69E0      INC        OUTPTR(R14),#1
0088 0306

PBUFNC:
008A 76E1      LDA        R1,OUTBUF(R14)      ! LOAD ADDR OF OUTBUF !
008C 0080

! OUTPUT LOOP !
PENT:
008E 2018      LDF        RL0,CR1      ! GET CHR !
0090 A910      INC        R1           ! INC INDEX !
0092 DFE9      CALR       SNDCHR       ! OUTPUT CHR !
0094 E604      JR         Z,OUTLF      ! ?CHR = CR !
0096 4BE1      CP         R1,OUTPTR(R14) ! CK FOR END !
0098 0306
009A E7F9      JR         C,PRNT       ! LOOP.....!
009C E802      JR         FINI        ! FINISHED !

```

```

! ADD LF AFTER OUTPUT OF CR !
OUTLF:
009E C80A      LDB      RL0,#LF      ! OUTPUT LF !
00A0 DFF0      CALR     SNDCHR

! FILL OUTBUF WITH BLANKS AND RESET OUTPTR !
FINI:
00A2 76E3      LDA      R3.OUTBUF(R14)
00A4 0080
00A6 6FE3      LD       OUTPTR(R14),R3 ! RESET PTR !
00A8 0306
00AA 2100      LD       R0,#OUTSIZ/2-1 ! FILL CNT !
00AC 003F
00AE 4DE5      LD       OUTBUF(R14),# ' '
00B0 0080
00B2 2020
00B4 76E2      LDA      R2,OUTBUF(R14)
00B6 0080
00B8 A123      LD       R3,R2
00BA A931      INC      R3,#2
00BC FB21      LDIR     GR3,GR2,R0    ! FILL OUTBUF !
00BE 0030
00C0 9E08      RET
00C2          END PRNTBF

GLOBAL
00C2 SNDCHR PROCEDURE
!*****!
*
* SNDCHR: CK MONITOR FLAG WORD FOR *
* OUTPUT STOP SIGNAL (OSTOP); *
* IF NOT, SEND CHAR TO CONS. *
*
* REG USE: INPUT  RL0= CHR *
* RETURN  RL0= CHR AND Z IF *
* CHR = CR. *
*
!*****!
ENTRY
! WAIT FOR OUTPUT OK SIGNAL !
00C2 67E2      BIT      MFLAGS(R14),#OSTOP ! CK FLAG !
00C4 031C
00C6 EEF0      JR       NZ,SNDCHR
! OUTPUT CHAR TO TERMINAL !
00C8 3A04      INB      RH0,PORTBC ! GET PORT STATUS !
00CA FFE3
00CC A600      BITB     RH0,#TXR      ! TRANS RDY? !
00CE F6F9      JR       Z,SNDCHR      ! NO, CONTINUE...!
00D0 3A86      OUTB     PORTBD,RL0    ! YES, OUTPUT CHR !
00D2 FFE1

```

```

00D4 0A08      CPB      RL0,#CR
00D6 0D0D
00D8 9308      RET
00DA          END SNDCHR

```

```

GLOBAL
CONVB LABEL
CONVW PROCEDURE
00DA
!*****
*
* CONVW: CONVERT INTERNAL WORD, 4-
* 4-BIT HEX VALUES TO FOUR
* 8-BIT ASCII REPRESENTATIONS
* OF THE HEX VALUES.
*
* CONVB: CONVERT INTERNAL BYTE HEX
* VALUE TO ASCII CHARACTERS.
*
* REG USE: INPUT R5 = WORD/BYTE(S)
* R3 = CKSUM ACCUM
* RETURN R3 = UPDATED ACCUM
* AND ASCII CHR
* IN OUTBUF
*
*****!
ENTRY
! CONVERT WORD !
00DA A050      LDB      RH0,RH5      ! 1ST BYTE !
00DC DFFF      CALP     NIBBLE
! CONVERT BYTE ENTRY POINT !
CONVB:
00DE A0D0      LDB      RH0,RL5

NIBBLE:
00E0 BE08      RLDP     RL0,RH0      ! FIRST NIBBLE !
00E2 DFFF      CALP     COMPUT
00E4 BE08      RLDB     RL0,RH0      ! NEXT NIBBLE !
! CONVERT NIBBLE TO ASCII CHAR AND STORE !
COMPUT:
00E6 0608      ANDB     RL0,#%0F     ! GET NIBBLE !
00E8 0F0F
00EA 809B      ADDB     RL3,RL0      ! UPDATE CKSUM !
00EC 0A08      CPB      RL0,#%0A     ! 0-9? !
00EE 0A0A
00F0 E702      JR       C, ASCII     ! YES... !
00F2 0008      ADDB     RL0,#7       ! NO, CONVERT CHR !
00F4 0707

ASCII:
00F6 0008      ADDB     RL0,#%30     ! CONVEPT TO ASCII !
00F8 3030

```

```

! STORE IF OUTBUF !
00FA 93F1    PUSH    GR15,R1    ! SAVE P1 !
00FC 61E1    LD      R1,OUTPTR(R14)
00FE 0306
0100 2E18    LDE     GR1,RL0    ! STORE CHR !
0102 69E0    INC     OUTPTR(R14)
0104 0306
0106 97F1    POP     P1,GR15
0108 9E08    RET
010A        END CONVW

```

```

GLOBAL
DISPNC LABEL
DISP    PROCEDURE
010A
!*****
*
* DISP: CONVERTS INPUT TO FOUR ASCII
* CHAR, STORES IN OUTBUF, AND
* DISPLAYS WITH CR; GETS NEXT
* 8 ASCII CHARS, STORES IN
* INTRBUF, AND CONVERTS TO HEX
* LONG WORD IN RR2.
*
* DISPNC: SENDS TO CONSOLE ALL IN
* OUTBUF UP TO OUTPTR, WITHOUT
* CR; GETS NEXT 8-ASCII CHR
*
* REG USE: INPUT    R5 = WORD
*                RETURN R2,R3 = 8-HEX
*                AND C   IF REC 0
*                NC,Z IF CR
*                NC,NZ IF INPUT
*                WITH CR
*
*****!

```

```

ENTRY
010A D019    CALR    CONVW    ! ADD SPACE !
010C 69E0    INC     OUTPTR(R14),#1
010E 0306

```

```

DISPNC:
0110 D044    CALR    PBUFNC    ! OUTPUT TO CONS !
0112 34CA    LDA     R10,R12(ASCHEX)
0114 0000*
0116 1FA0    CALL    GR10    ! GET NEW R2,R3 INPUT !
0118 9E08    RET
011A        END DISP

```

```

GLOBAL
011A DISPLAY PROCEDURE
!*****!
*
* DISPLAY: DISPLAYS SPECIFIED CONTENTS*
* OF MEMORY.*
*
* REG USE: R07,RL7 = #BYTES/SPACE*
* R8 = OUTBUF ADR FOR OUTPUT*
* R11 = <ADDR>*
* R13 = <COUNT>*
*
*****!
ENTRY
011A D073 CALR GETNXT
011C 2107 LD R7,#202
011E 0202
0120 EE01 JR NZ,GOTARG ! HAVE NEXT ARG !
0122 F84C JR EXERR ! RETURN TO EXEC !
GOTARG:
0124 D08D CALR GETADR ! NEXT ARG IS ADR !
0126 A13B LD R11,R3 ! SAVE ADDRESS !
0128 F637 JR Z,SUBMOD ! <ADR><CR> = SUBMODE!
012A D090 CALR GETADR ! GET <CNT> !
012C A13D LD R13,R3
012E F601 JR Z,TSTCNT ! GOT CR AFTER <CNT> !
0130 EE45 JR NZ,EXERR ! NOT THERE....!
TSTCNT:
0132 8DD4 TEST R13 ! TEST <CNT> !
0134 E643 JR Z,EXERR ! <CNT>=0, ERROR !
! MAIN LOOP FOR PRINTING DISPLAY LINES !
NEWL:
0136 2109 LD R9,#16 ! BYTES/LINE !
0138 0010
013A A1B5 LD R5,R11
013C F032 CALR CONW ! CONVERT BYTE !
013E 69F0 INC OUTPTR(R14)
0140 0306
0142 76E2 LDA R8,OUTBUF(R14) ! SET DISPLAY !
0144 0080
0146 0108 ADD R8,#53
0148 0035
! FORMAT !
014A 0C85 LDB QP8,'#*'
014C 2A2A
014E A980 INC R8
! LOOP FOR DISPLAY B/W/L UNITS !

```

```

PUTONE:
0150 20BD      LDB      RL5,GR11      ! FETCH MEMORY !
0152 2E8D      LDB      GR8,RL5
0154 2A0D      CPB      RL5,#' '      ! CK FOR CHAR !
0156 2020
0158 E703      JR       C,DONTP      ! DONT PRINT !
015A 2A0D      CPB      RL5,#%7F     ! CK FOR PRNT CHR !
015C 7F7F
015E E702      JR       C,RITE      ! YES, PRINT !
DONTP:
0160 0C85      LDB      GR8,#'.'     ! REPLACE WITH '.' !
0162 2E2E
RITE:
0164 A980      INC      R8,#1
0166 0C85      LDB      GR8,#'*'
0168 2A2A
016A D047      CALR     CONVB        ! CONVERT WORD !
016C A9B0      INC      R11,#1      ! INC MEM PTR !
016E AB90      DEC      R9
0170 FE08      JR       NZ,SPACE    ! NOT EOL !
0172 A980      INC      R8
0174 6FE8      LD       OUTPTR(R14),R8 ! SET PTR TO EO-BUF !
0176 0306
0178 D07E      CALR     PRNTBF      ! PRINT LINE !
017A A07F      LDB      RL7,RH7     ! RESET B/SP CNT !
017C ABD0      DEC      R13
017E EEDB      JR       NZ,NEWL     ! START NEW LINE !
0180 9E08      RET              ! OR ELSE DONE !

! CHECK FOR POSITION OF SPACE !
SPACE:
0182 FF1A      DBJNZ    RL7,PUTONE  ! NO SPACE YET !
0184 69E0      INC      OUTPTR(R14)  ! PUT SPACE !
0186 0306
0188 A07F      LDB      RL7,RH7     ! RESET B/SP CNT !
018A ABD0      DEC      R13
018C EEE1      JR       NZ,PUTONE   ! CONTINUE..... !
018E A980      INC      R8
0190 6FE8      LD       OUTPTR(R14),R8
0192 0306
0194 D08C      CALR     PRNTBF      ! FINISHED !
0196 9308      RET

! SUBSTITUTION MODE, SINGLE DISPLAY !
SUBMOD:
0198 A1B9      LD       R9,R11
019A A1B5      LD       R5,R11
019C D062      CALR     CONW        ! CONVERT BYTE !
019E 69E0      INC      OUTPTR(R14)
01A0 0306

```



```

AGAIN:
01A2 20FD      LDB      RL5,R11
01A4 D064      CALR     CONVB      ! CONVERT WORD !
01A6 A9E0      INC      R11,#1
01A8 FF04      DBJNZ    RL7,AGAIN
01AA 69E0      INC      OUTPTR(R14),#1      ! INSERT SPACE !
01AC 0306
01AE A07F      LDB      RL7,RH7      ! RESET B/SP CNT !

```

```

! GET SUBSTITUTION OR 'Q' OR CR !
01B0 D051      CALR     DISPNC
01B2 9E07      RET      C
01B4 E6F1      JR       Z,SUBMOD      ! GOT CR,.....!
01B6 2F93      LD       GR9,R3      ! SUBST. WORD !
01B8 A07F      LDB      RL7,RH7      ! RESET B/SP CNT !
01BA F8FE      JP       SUBMOD

```

```

EXERR:
01BC 34CA      LDA      R10,R12(ERROR)
01BE 0000*
01C0 1EAB      JP       GP10

```

```

01C2          END DISPLAY

```

```

GLOBAL BIARG LABEL
01C2 GLOBAL TRIARG PROCEDURE
!*****!
* TRIARG: GETS NEXT THREE ARG AFTER *
* CMD, INTO INTBUF; ASCII-TO- *
* HEX CONVERSION IS PERFORMED *
* ON ADDRESSES. *
*
* BIARG: SEEKS NEXT TWO ARG IN THE *
* SAME MANNER. *
*
* REG USE: RETURN R3 = 3RD ARG (TRI) *
* R4 = 2ND ARG *
* R5 = 1ST ARG *
*
* R3 = 2ND ARG (BI) *
* R4 = 1ST ARG *
* AND NC IF ALL ARG *
*
*****!

```

```

ENTRY
01C2 D0C7      CALP     GETNXT      ! SKIP REST OF CMD !
01C4 D0DD      CALR     GETADR      ! GET 1ST ARG !

```

```

01C6 E608      JR      Z, ERRSTP      ! CR=ERROR !
01C8 A135      LD      R5, R3
01CA E801      JR      GET2ND
! TWO ARGUMENTS ENTRY POINT !
BIARG:
01CC D0CC      CALR     GETNXT

GET2ND:
01CE D0E2      CALR     GETADR      ! GET NEXT ARG !

01D0 E603      JR      Z, ERRSTP      ! CR=ERROR !
01D2 A134      LD      R4, R3
01D4 D0E5      CALR     GETADR      ! GET LAST ARG !

01D6 9E0F      RET      NC
ERRSTP:
01D6 8D81      SETFLG   C              ! SIGNAL ERROR!
01DA 9E08      RET
01DC          END TRIARG

GLOBAL
01DC          MOVE PROCEDURE
!*****
*
*   MOVE: MOVES DATA IN MEMORY.
*
*   REG USE: RETURN  R5 = <ADR>
*                  R4 = <NEW ADR>
*
*****!
ENTRY
01DC D00E      CALR     TRIARG      ! GET THREE ARGS !
01DE E70D      JR      C, WTP      ! NOT ENOUGH ARG !
01E0 A156      LD      R6, R5
01E2 8346      SUB      R6, R4      ! FIND MOVE DIRECT !
01E4 E703      JR      C, UP      ! WILL MOVE UP.... !
01E6 BA51      LDIRB    GR4, GR5, R3 ! WILL MOVE DOWN !
01E8 0340
01EA 9E08      RET
UP:
01EC 8135      ADD      R5, R3
01EE AB50      DEC      R5
01F0 8134      ADD      R4, R3
01F2 AB40      DEC      R4
01F4 BA59      LDDRB    GR4, GR5, R3 ! MOVE BLOCK !
01F6 0340
01F8 9E08      RET
WTP:
01FA 34CA      LDA      R10, R12(#ERROR)

```

```

01FC 0000*
01FE 1EAB      JP      @R10

0200      END MOVE

0200      GLOBAL FILL PROCEDURE
!*****
*
*   FILL: STROES GIVEN DATA WORD IN ALL *
*   SPECIFIED MEMORY LOCATIONS.         *
*
*****!
ENTRY
0200 34CA      LDA      R10,R12(#EROR)
0202 0000*
0204 D022      CALP     TRIARG      ! FETCH THREE ARGS !
0206 1EA7      JP      C,@R10
0208 A750      BIT      R5,#0      !MUST BE EVEN ADR!
020A 1EAE      JP      NZ,@R10
020C 8354      SUB      R4,R5      !COMPARE START TO!
                                !END!
020E 1EA7      JP      C,@R10
0210 B341      SRL      R4,#1      !SET COUNT!
0212 FFFF
0214 2F53      LD       @R5,R3      !STORE DATA AT START!
0216 9E06      RET      Z          !ONLY ONE REQ !
0218 A153      LD       R3,R5
021A A931      INC      R3,#2      !NEXT MEM LOC !
021C BB51      LDIR     @R3,@R5,R4  ! FILL ALL !
021E 0430
0220 9E08      RET
0222      END FILL

      END DISPLAY_CMD

```

6. BRK_QUIT MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 BRK_QUIT_CMD MODULE
\$LISTON \$TTY

```

!*****
*
* BREAK: COMMAND TO RESET A BREAK ADR *
* REMOVES AN OLD ONE, AND SETS *
* A NEW ONE. *
*
* QUIT: COMMAND TO ENTER THE TRANSPAR. *
* MODE WHERE ALL RECEIVED CHAR *
* ARE ECHOED BETWEEN MCZ SYS *
* AND CONSOLE. Z8000 FUNCTIONS *
* IN RELAY CAPACITY ONLY. *
*
* SYNTAX: BREAK [<ADR>] *
* QUIT *
*
*****!

```

CONSTANT

(INCLUDE GLOBAL CONSTANTS)

EXTERNAL	GETNXT	PROCEDURE
EXTERNAL	GETADR	PROCEDURE
EXTERNAL	GMCZAD	PROCEDURE
EXTERNAL	SNDMCZ	PROCEDURE
EXTERNAL	GETBUF	PROCEDURE
EXTERNAL	SNDCHR	PROCEDURE
EXTERNAL	EROR	LABEL
EXTERNAL	SKPBLK	PROCEDURE
EXTERNAL	CONVERT	PROCEDURE
EXTERNAL	GETCHR	PROCEDURE

GLOBAL

\$SECTION BRK_QUIT_PROC

\$REL 0

2000

GLOBAL

ASCHEX PROCEDURE

!*****

```
*
*   ASCHEX: ROUTINE TO CONVEIT ONE LINE *
*   CF ASCII INPUT TO HEX VALUE *
*   (8-ASCII CHR TO ONE LWORD) *
*
*   REG USE: RETURN  RR2 = 8-ASCII CHR *
*                   AND C IF REC 'Q' *
*                   NC,Z IF CR *
*                   NC,NZ IF SPACE *
*
```

*****!

ENTRY

```
0000 C82A   LDB     RL0,#'*'
0002 34CA   LDA     R10,R12(#SNDCHR)
0004 0000*
0006 1FA0   CALL    GR10      ! OUTPUT PROMPT !
0008 DFE0   CALL    GETLINE   ! GET LINE INTBUF !
000A 8D29   CLR     R2
000C 8D38   CLP     R3      ! CLR RETURN REGS !
000E 34CA   LDA     R10,R12(#SKPBLK)
0010 0000*
0012 1FA0   CALL    GR10
0014 9E06   RET     Z      ! REC CR !
0016 0A09   CPB     RL0,#'0'
0018 5151
001A FE02   JR      NZ,GB3    ! NOT '0',.....!
001C 8D81   SETFLG  C
001E 9E08   RET     C      ! RETURN WITH '0' !
```

GB3:

```
0020 34CA   LDA     R10,R12(#CONVERT)
0022 0000*
0024 1FA0   CALL    GR10      ! ASCII TO HEX !
0026 E70E   JR      C,ENDERR   ! NON-ASCII CHR !
0028 BEB8   RLDB    RL0,RL3
002A EE38   RLDB    RL0,RH3
002C BEA8   RLDB    RL0,RL2
002E BE29   RLDB    RL0,RH2    ! ROTATE NIBBLE !
0030 34CA   LDA     R10,R12(#GETCHR)
0032 0000*
0034 1FA0   CALL    GR10      ! GET NEXT ASCII CHAR !
0036 E604   JP      Z,NOMORE    ! GOT NOTHING !
0038 0A08   CPB     RL0,#' '    ! END OF INPUT !
003A 2020
003C FEF1   JR      NZ,GB3      ! YES, ALL DONE !
003E 8D83   RESFLG  C
```

NOMORE:

```

0040 8D43      RESFLG    Z
0042 9E08      RET

                                ENDERR:
0044 34CA      LDA        R10,R12(#EROR)
0046 0000*
0048 1EAS      JP         QR10
004A          END ASCHEX

GLOBAL
004A          GETLINE  PROCEDURE
!*****
*
*   GETLINE: REC ONE LINE INPUT FROM
*             CONS (PORT2), UP TO 80-CHR
*             MAX, STORE IN INTBUF PLUS
*             CR, AND ECHO BACK TO CONS.
*
*   REG USE: RETURN  RL0= 1ST CHR IN BUF*
*                   AND Z IF CHR = CR
*
*****!
ENTRY
004A 76E2      LDA        F2,INTBUF(R14)    ! GET BASE INTBUF !
004C 0000
004E 2101      LD         R1,#INSIZ        ! GET MAX SIZE !
0050 0080
0052 6FE2      LD         INTPTR(R14),R2
0054 0304
0056 DFF7      CALR       CONSOL          ! FILL LINE IN INTBUF!
0058 E6F5      JR         Z,ENDERR        ! LINE TOO LONG !
005A 34CA      LDA        R10,R12(#SKPBLK)
005C 0000*
005E 1FA0      CALL       QR10
0060 6BE0      DEC        INTPTR(R14)      ! RETURN TO START !
0062 0304
0064 0A08      CPB        RL0,#CR
0066 0D0D
0068 9E08      RET
006A          END GETLINE
! GOT 1ST CHR = CR !

```

```

006A      GLOBAL
          CONSOL PROCEDURE
          !*****
          *
          *   CONSOL: STORE CONS INPUT LINE IN   *
          *   BUFFER ADDRESS PROVIDED.          *
          *   PLACE CR AT END OF LINE,          *
          *   AND PROVIDE DELETE CHAR           *
          *   AND DELETE LINE EDIT FUNC.        *
          *
          *   REG USE: INPUT  R1 = SIZE OF BUFFER *
          *                   R2 = BUFFER ADR     *
          *                   RETURN R1 = # OF REC CHR *
          *                   AND Z IF BUF LIMIT  *
          *
          !*****
          ENTRY
006A 6FE2      LD      BUFADR(R14),R2      ! SAVE BOTH BUF ADR !
006C 0300
006E 6FE1      LD      BUFSIZ(R14),R1      ! AND BUF SIZE !
0070 0302
          HDNG:
0072 61E2      LD      R2,BUFADR(R14)
0074 0300
0076 8D18      CLR     R1
          REDLOP:
0078 DFC1      CALR    CONRD      ! GET CHAR AND ECHO !
007A 0A08      CPB     RL0,#%61    ! CONVERT TO UPPER CASE!
007C 6161
007E E704      JR      C,UPCASE    ! NOT LOWER CASE !
0080 0A08      CPB     RL0,#%7B
0082 7B73
0084 EF01      JR      NC,UPCASE    ! YES LOWER CASE !
0086 A285      RESE     RL0,#5      ! CONVERT TO UPCASE !
          UPCASE:
0088 2E28      LDB     GR2,RL2
          ! PERFORM EDIT FUNCTIONS ON INPUT !
008A 0A08      CPB     RL0,#BS     ! CK FOR DEL CHR !
008C 0808
008E EE11      JR      NZ,CONTCK    ! NO, CONTINUE CK !
0090 AB20      DEC     R2,#1         ! YES, BACKSPACE !
0092 AB10      DEC     R1
0094 4BE2      CP      R2,BUFADR(R14) ! NOT TOO FAR !
0096 0300
0098 E707      JR      C,DC_OVR
009A C820      LDB     RL0,#'
009C 34CA      LDA     R10,R12(#SNDCHR)
009E 0000*
00A0 1FA0      CALL    QB10         ! BLANK OUT BAD CHR !

```

```

00A2 C808      LDB      RL0,#BS
00A4 1FA0      CALL     GR10
00A6 E8E8      JR        REDLOP      ! CONTINUE.....!

```

```

DO_OVR:
00A8 C82A      LDB      RL0,#'*'
00AA 34CA      LDA      R10,R12(#SNDCHR)
00AC 0000*
00AE 1FA0      CALL     GR10          ! SEND PROMPT !
00B0 E8E0      JR        HDNG        ! START AGAIN !

```

```

CONTCK:
00B2 0A08      CPB      RL0,#LINDEL  ! CK FOR LINE DEL !
00B4 7F7F
00B6 E609      JR        Z,DELIN     ! YES,.....!
00B8 A920      INC      R2,#1
00BA A910      INC      R1
00BC 0A08      CPB      RL0,#CR      ! CK FOR CR !
00BE 0D0D
00C2 E60E      JR        Z,ADDLF     ! YES, ADD LF CHR !
00C2 4BE1      CP        R1,BUFSIZ(R14) ! SIZE CK !
00C4 0302
00C6 EED8      JR        NZ,REDLOP   ! OK, GET NFXT CHR !
00C8 9E06      RET          Z          ! TOO LARGE, ERROR !

```

```

DELIN:
00CA C85E      LDB      RL0,#%5E
00CC 34CA      LDA      R10,R12(#SNDCHR) ! SND LINE DEL !
00CE 0000*
00D0 1FA0      CALL     GR10
00D2 DFF5      CALR     NEWLNE       ! START NEW LINE !
00D4 C820      LDB      RL0,#'
00D6 34CA      LDA      R10,R12(#SNDCHR)
00D8 0000*
00DA 1FA0      CALL     GR10          ! SND CHR !
00DC E8CA      JR        HDNG        ! START AGAIN !

```

```

ADDLF:
00DE C80A      LDB      RL0,#LF
00E0 34CA      LDA      R10,R12(#SNDCHR)
00E2 0000*
00E4 1FA0      CALL     GR10          ! SEND LF CHR !
00E6 8D43      RESFLG  Z
00E8 9E08      RET
00EA          END CONSOL

```



```

GLOBAL
NEWLNE PROCEDURE
!*****
*
*   NEWLNE: SENDS CR AND LF TO CONSOLE
*
* *****!
ENTRY
00EA 34CA    LDA      R10,R12(#SNDCHR)
00EC 0000*
00EE C80D    LDB      R10,#CR
00F0 1FA0    CALL     @R10
00F2 C80A    LDB      R10,#LF
00F4 1FA0    CALL     @R10      ! ADR SNDCHR IN R10 !
00F6 9F08    RET
00F8        END NEWLNE

```

```

GLOBAL
CONRD  PROCEDURE
!*****
*
*   CONRD: GETS CHAR FROM CONSOLE INPUT
*           BUFFER (INTBUF) AND ECHOS
*           BACK TO CONSOLE. LOOPS UNTIL
*           RECEIVE CHARACTER.
*
*   REG USE: RETURN  R10= CHR
*                   AND Z IF CHR=CR
*
* *****!
ENTRY
00F8 61F0    TC:LD      R0,GETOUT(R14)
00FA 030E
00FC 4BE0    CP        R0,NXTPTR(R14)      ! COMPARE GET AND !
00FE 030C
                                ! PUT PTRS !
                                ! REC NOTHING.... !
0100 E6FB    JR        Z,TC
0102 93F2    PUSH     @R15,R2
0104 34CA    LDA      R10,R12(#GETBUF)
0106 0000*
0108 1FA0    CALL     @R10      ! GET RNGBUF ADP !
010A 6FE0    LD       GETOUT(R14),R0
010C 030E
010E 2028    LDB      R10,@R2      ! STO CHR FOR RTN !
0110 97F2    POP      R2,@R15
! CHECK FOR NON-DISPLAY FROM LOAD_FILE !
0112 0B09    CP      R9,#ZAAAA
0114 AAAA
0116 E603    JR      Z,NO_DISPLAY
0118 34CA    LDA      R10,R12(#SNDCHR)

```

```

011A 0000*
011C 1FA0      CALL      QR10

                NO DISPLAY:
011F 9E08      RET
0120          END CONRD

GLOBAL
BREAK PROCEDURE
0120          !*****
                *
                * BREAK: CLEARS PPREVIOUSLY SET BREAK *
                * POINT BY REPLACING UNIMP. *
                * INSTRUCTION (0E00) WITH ORG *
                * INSTRUCTION FOR THE ADR, AND *
                * SETS A NEW BREAK POINT IF *
                * SPECIFIED (<ADR>). *
                *
                !*****!
ENTRY
! CLEAR PREVIOUS BREAK POINT !
0120 61E2      LD        R2,BRKADR(R14)
0122 0316
0124 61E1      LD        R1,BRKSTR(R14)
0126 0314
0128 2F21      LD        QR2,R1      ! RESTORE INST !
012A 4DE8      CLR       BRKADR(R14)
012C 0316
012E 4DE8      CLR       BRKSTR(R14)
0130 0314
0132 4DE5      LD        BRKCNT(R14),#1  ! RESET CNT TO 1 !
0134 030A
0136 0001
0138 34CA      LDA       R10,R12(#GETNXT)
013A 0000*
013C 1FA0      CALL      QR10      ! GET NEXT ARGUMENT !
013E 9E06      RET       Z        ! NO NEW ADDRESS !

! GET NEW BREAK ADDRESS !
0140 34CA      LDA       R10,R12(#GETADR)
0142 0000*
0144 1FA0      CALL      QR10      ! GET BRK ADR !
0146 A132      LD        R2,R3      ! SAVE BPK ADR !
0148 E607      JR        Z,GB4      ! NO BRKCNT...!

! GET NEW BREAK COUNT !
014A 34CA      LDA       R10,R12(#GETADR)
014C 0000*
014E 1FA0      CALL      QR10      ! GET COUNT !
0150 8D34      TEST      R3        ! TEST FOR ZERO !

```

```

0152 E602      JR      Z,GB4      ! BRKCNT = 1 !

                                NCZ:
0154 6FE3      LD      BRKCNT(R14),R3  ! SET BRKCNT !
0156 030A

                                ! SET UNIMPLEMENTED INSTRUCTION IN BRKADR !
                                GB4:
0158 A320      RES      R2,#0      ! MAKE EVEN ADR !
015A 6FE2      LD      BRKADR(R14),R2
015C 0316
015E 2121      LD      R1,R2
0160 6FE1      LD      BRKSTR(R14),R1  ! SAVE INST !
0162 0314
0164 61E1      LD      R1,UNIMP(R14)
0166 0308
0168 2F21      LD      R2,R1      ! PLACE '0E00' !

                                ! CHECK FOR WRITE TO EXISTING MEMORY !
016A 2121      LD      R1,R2
016C 4BE1      CP      R1,UNIMP(R14)
016E 0308
0170 9E06      RET      Z
0172 4DE5      LD      BRKCNT(R14),#1  ! MEMORY NOT THERE !
0174 030A
0176 0E01
0178 4DE8      CLR      BRKADR(R14)
017A 0316
017C 4DE8      CLR      BRKSTR(R14)
017E 0314
0180 34CA      LDA      R10,R12(=ERROR)
0182 0E00*
0184 1FA8      JP      R10      ! GOT WRONG BRK PNT !

0186      END BREAK

                                GLOBAL
                                QUIT PROCEDURE
0186      !*****
                                *
                                *   QUIT: TRANSMITS ALL CHF AND CR FROM *
                                *   CONS TO MCZ; THEN RELAYS ALL *
                                *   TO CONS FROM MCZ; AND ETC. *
                                *
                                *****!
                                ENTRY
0186 4DE8      CLR      MCZPUT(R14)
0188 0310
018A 4DE8      CLR      MCZGET(R14)
018C 0312

```

```

018E 65E0      SET      MFLAGS(R14),#TRPMDE  ! RESET BUF PTRS !
0190 031C

```

! AND ENTER TRANSPARENT MODE !

! CONSOLE RECEIVE ROUTINE !

PORTB:

```

0192 61E0      LD        R0,GETOUT(R14)
0194 030E
0196 4BE0      CP        R0,NXTPTR(R14)  ! CK FOR CONS INPUT !
0198 030C
019A E60A      JR        Z,PORTA        ! NO, CK MCZ..... !

```

! PROCESS CONSOLE INPUT !

```

019C 34CA      LDA        R10,R12(#GETBUF)
019E 0000*
01A0 1FA0      CALL       @R10          ! GET RNCBUF ADR !
01A2 6FE0      LD        GETOUT(R14),R0  ! SET BEGIN PTR !
01A4 030E
01A6 2028      LDB        R10,@R2
01A8 34CA      LDA        R10,R12(#SNDMCZ)
01AA 0000*
01AC 1FA0      CALL       @R10          ! ECHO CHR TO MCZ !
01AE EEF1      JR        NZ,PORTB      ! CONTINUE UNTIL CR !

```

! MCZ RECEIVE ROUTINE !

PORTA:

```

01B0 61E0      LD        R0,MCZGET(R14)
01B2 0312
01B4 4BE0      CP        R0,MCZPUT(R14)  ! CK FOR MCZ INPUT !
01B6 0310
01B8 E6EC      JR        Z,PORTB        ! NO, CK CONSOLE...!
01BA 34CA      LDA        R10,R12(#GMCZAD)
01BC 0000*
01BE 1FA0      CALL       @R10          ! GET MCZBUF ADR !
01C0 6FE0      LD        MCZGET(R14),R0
01C2 0312
01C4 2028      LDB        R10,@R2        ! GET CHAR FROM MCZBUF !
01C6 34CA      LDA        R10,R12(#SNDCHR)
01C8 0000*
01CA 1FA0      CALL       @R10          ! OUTPUT CHR TO CONSOLE !
01CC EBF1      JR        PORTA        ! CONTINUE TIL EMPTY !
01CE

```

END QUIT

END BRK_QUIT_CMD

7. DEBUG MODULE

Z8000ASM 2.02
LOC OBJ CODE STMT SOURCE STATEMENT

1 DEBUG_CMD MODULE
\$LISTCN \$TTY

```

*****
*
* JUMP CMD: CHANGES USER PC VALUE AND
*           BEGINS PROGRAM EXECUTION
*           AT THAT POINT <PC>.
*
* GO CMD:   BEGINS PROGRAM EXECUTION
*           AT THE CURRENT USER PC.
*
* NEXT CMD: STEPS THROUGH PROGRAM
*           EXECUTION ONE INST. AT A
*           TIME OR IN MULTIPLES <N>.
*
* SYNTAX:   JUMP <PC>
*           GO
*           NEXT [<N>]
*
*****!

```

CONSTANT

```

RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPORT   := %FFC3
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR    := %(2)0001000000000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %08

```

```

LINDEL    := %7F
CR        := %0D
LF        := %0A
TXOFCH    := %13
TXONCH    := %11
INSIZ     := 128      ! INTBUF SIZE !
OUTSIZ    := 128      ! OUTBUF SIZE !
RESIZ     := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE    := 0
ISTOP     := 1
OSTOP     := 2
SNDMDE    := 3
LDMDE     := 4
ESC       := 5
TXMSK     := %6

```

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

```

0000      INTBUF  ARRAY [128 BYTE]
0080      OUTBUF  ARRAY [128 BYTE]
0100      PNGBUF  ARRAY [256 BYTE]
0200      MCZBUF  ARRAY [256 BYTE]

0300      BUFADR  WORD
0302      BUFSIZ  WORD

0304      INTPTR  WORD
0306      OUTPTR  WORD

0308      UNIMP   WORD
030A      BRKCNT  WORD

030C      NXTPTR  WORD
030E      GETOUT  WORD
0310      MCZPUT  WORD
0312      MCZGET  WORD
0314      BRKSTR  WORD
0316      BRKADR  WORD
0318      TMPSP   WORD
031A      TMPFCW  WORD

031C      MFLAGS  WORD

! USER REGISTER STORAGE !

031E      R0_     WORD

```

0320	R1_	WORD
0322	R2_	WORD
0324	R3_	WORD
0326	R4_	WORD
0328	R5_	WORD
032A	R6_	WORD
032C	R7_	WORD
032E	R8_	WORD
0330	R9_	WORD
0332	R10_	WORD
0334	R11_	WORD
0336	R12_	WORD
0338	R13_	WORD
033A	R14_	WORD
033C	R15_	WORD
033E	RPC_	WORD
0340	RFC_	WORD

0342	RETRY	WORD
0344	ADR_STR	WORD

INTERNAL
 \$SECTION PSA_DATA
 \$ABS 0

0000	PSA	RECORD [
		DATA_AREA	WORD
		CODE_AREA	WORD
		UNIMP_INST	LONG
		PRIV_INST	LONG
		SYSTEM_CALL	LONG
		SEG_TRAP	LONG
		NMI_INT	LONG
		NVI_INT	LONG
		VEC_FCW	WORD
		VEC_PC	ARRAY [200 WORD]
]	

EXTERNAL
 GETNXT PROCEDURE
 GETADR PROCEDURE
 RGHDR1 PROCEDURE
 RGHDR2 PROCEDURE
 PRREG1 PROCEDURE
 PRREG2 PROCEDURE
 ERROR LABEL
 EXEC PROCEDURE

\$SECTION DEBUG_PROC
 \$REL 0

```

GLOBAL
0000  DEBUG ENTRY PROCEDURE
!*****!
*
*  DEBUG_ENTRY: RESTORES DMONITOR R12
*                AND R14 (CODE AND DATA)*
*                REGISTERS FOR INTERRUPT*
*                ENTRIES.
*
*****!
ENTRY
0000 93F1  PUSH  GR15,R1
0002 93FE  PUSH  GR15,R14
0004 7D15  LDCTL  P1,PSAPOFF      ! GET PSA BASE !
0006 211E  LD      R14,GR1      ! RESTORE DATA BASE !
0008 6FFC  LD      R12_(R14),R12 ! SAVE USER R12 !
000A 0336
000C 611C  LD      R12,CODE_AREA(P1) ! CODE BASE !
000E 0002
0010 97F1  POP    R1,GR15
0012 6FE1  LD      R14_(R14),R1
0014 033A
0016 97F1  POP    R1,GR15
0018 9E08  RET
001A  END DEBUG_ENTRY

```

```

GLOBAL
001A  SAVREG PROCEDURE
!*****!
*
*  SAVREG: SAVES USER PROGRAM STATUS
*                AND REGS 1-14 CONTENTS.
*
*****!
ENTRY
001A 6FEF  LD      TMPSP(R14),R15      ! RTN ADR !
001C 0318
001E 31F0  LD      R0,R15(#4)      !SAVE: !
0020 0004
0022 6FE0  LD      RFC_(R14),R0      ! USER FCW !
0024 0340
0026 31F0  LD      R0,R15(#6)
0028 0006
002A 6FE0  LD      RPC_(R14),R0      ! USER PC !
002C 033E
! SAVE R1 - R14 !
002E 76EF  LDA      R15,R1_(R14)
0030 0320

```



```

0032 1CF9      LDM      GR15,R1,#11    ! STORE REGS !
0034 01C4
0036 61EF      LD       R15,TMPSP(R14)  ! RESTORE SP !
0038 0318
003A 6FED      LD       R13_(R14),R13
003C 0338
003E 9E08      RET
0040          END SAVREG

GLOBAL
0040          RESTOR  PROCEDURE
!*****
*
*   RESTOR: RESTORES USER PROGRAM STATUS*
*           AND REGS 0-11,13 CONTENTS.  *
*
*****!
ENTRY
0040 6FEF      LD       TMPSP(R14),R15    ! SAVE STK PTR !
0042 0318
0044 61EF      LD       R15,R15_(R14)    ! SET USER SP !
0046 033C
0048 61E1      LD       R1,RFC_(R14)      ! RESTORE:      !
004A 0340
004C 33F1      LD       R15(#2),R1        ! USER PCW !
004E 0002
0050 61E1      LD       R1,RPC_(R14)
0052 033E
0054 33F1      LD       R15(#4),R1        ! USER PC !
0056 0004
!RESTORE R0 ~ R15 !
0058 34EF      LDA      R15,R14/#R0_)
005A 031E
005C 1CF1      LDM      R0,GR15,#12    ! RESTORE REGS !
005E 0003
0060 61ED      LD       R13,R13_(R14)
0062 0338
0064 61EF      LD       R15,TMPSP(R14)    ! RESTORE SP !
0066 0318
0068 9E08      RET
006A          END RESTOR

```

```

GLOBAL
GO LABEL
JUMP PROCEDURE
206A *****
*
* JUMP: TRANSFERS PROGRAM EXECUTION *
* TO LOCATION SPECIFIED IN CMD. *
*
* GO: BEGIN EXECUTION AT CURRENT *
* USER PC VALUE. *
*
*****!
ENTRY
006A 34CA LDA R10,R12(#GETNXT)
006C 0000*
006E 1FA0 CALL QR10 ! GET NEXT ARG !
0070 E616 JR Z,SETERR ! NO ARGS !
0072 34CA LDA R10,R12(#GETADR)
0074 0000*
0076 1FA0 CALL QR10 ! RTN JMP ADR IN R3 !
0078 A330 RES R3,#0 ! SET TO EVEN ADR !
007A 6FE3 LD RPC_(R14),R3 ! SET NEW PC VALUE !
007C 033E
!GLOBAL GO CMD !
207E 61E3 GO:LD R3,RPC_(R14)
0080 033E
0082 4BE3 CP R3,BRKADR(R14) ! PC = BRKADR? !
0084 0316
0086 E665 JR Z,BRKPOU ! YES TAKE INT. !
0088 D025 CALR RESTOR ! NO, RESTORE REGS !
008A 61EF LD R15,R15_(R14) ! RESTORE SP !
008C 033C
008E 61EC LD R12,R12_(R14)
0090 0336
0092 93F1 PUSH QR15,R1
0094 61E1 LD R1,R14_(R14)
0096 033A
0098 A11E LD R14,R1
009A 97F1 POP R1,QR15
009C 7B00 IRET ! BEGIN EXEC BY IRET !
SETERR:
009E 34CA LDA R10,R12(#EROR)
00A0 0000*
00A2 1EAS JP QR10 ! RETURN TO EXEC !
00A4 END JUMP

```

```

GLOBAL
BRKIHD PROCEDURE
!*****!
*
*   BRKIHD: BREAK INTERRUPT HANDLER
*   WHICH EXECUTES SINGLE USER
*   INST, PUTS BACK BREAK INST
*   (UNIMPLEMENTED INST.), AND
*   RESTORES USER PCW.
*
*****!
ENTRY
00A4 93F2    PUSH    GR15,R2
00A6 93F1    PUSH    GR15,R1      ! SAVE SYS REG 1-2 !
00A8 93FE    PUSH    GR15,R14
00AA 7D15    LDCTL    F1,PSAPOFF
00AC 211E    LD       R14,GR1      ! DATA_AREA ADDR !
00AE 61E2    LD       R2,BRKADR(R14)
00B0 0316    LD
00B2 61E1    LD       R1,UNIMP(R14)
00B4 0308    LD
00B6 2F21    LD       GR2,R1      ! STORE UNIMP(R14) INST !
                                ! FOR BREAK SIGNAL !
00B8 67EC    BIT      TMPFCW(R14),#VIBIT !CK VI EN !
00BA 031A    JR
00BC EE05    JR       NZ,ALTHRU    ! YES, FINISHED !
00BE 31F2    LD       R2,R15(#8)   ! NO,.... !
00C0 0008    RES
00C2 A32C    RES      R2,#VIBIT    ! ..SO EN VI !
00C4 33F2    LD       R15(#8),R2   ! AND PUT BACK !
00C6 0008
ALTHRU:
! RESTORE USER R12 AND R14 !
00C8 97FE    POP      R14,GR15
00CA 97F1    POP      R1,GR15
00CC 97F2    POP      R2,GR15      ! RESTORE REGS !
00CE 7B00    IRET
00D0        END BRKIHD

```

```

GLOBAL
SSINT PROCEDURE
!*****!
*
*   SSINT: SINGLE STEP INT HANDLER FOR
*   USE WITH NEXT CMD. ALLOWS
*   SINGLE INST EXECUTION.
*
*****!
ENTRY
00D0 D069    CALR    DEBUG_ENTRY
00D2 6FEF    LD      R15_(R14),R15
00D4 033C
00D6 6FE0    LD      R0_(R14),R0
00D8 031E
00DA D061    CALR    SAVREG      ! SAVE ALL REGS !
00DC 61E2    LD      R2,BRKADR(R14)
00DE 0316
00E0 61E1    LD      R1,UNIMP(R14)
00E2 0308
00E4 2F21    LD      QR2,R1      ! RESTORE UNIMP(R14) INST !
00E6 67EC    BIT     TMPFCW(R14),#VIBIT
00E8 031A
00EA EE02    JR      NZ,DWN      ! VI EN !
00EC 63EC    RES     RFC_(R14),#VIBIT
00EE 0340

DWN:
00F0 34CA    LDA     R10,R12(#PRREG1)
00F2 0000*
00F4 1FA0    CALL    QR10      ! OUTPUT REG CONTENT!
00F6 34CA    LDA     R10,R12(#PRREG2)
00F8 0000*
00FA 1FA0    CALL    QR10
00FC 6BE0    DEC     BRKCNT(R14),#1
00FE 030A
0100 EE1B    JR      NZ,SINST    ! CONTINUE SS !
0102 4D05    LD      BRKCNT,#1   ! RESET NEXT CNT !
0104 030A
0106 0001
0108 4DES    CLR     MFLAGS(R14)
010A 031C
010C 7C05    EI      VI
010E 34CA    LDA     R10,R12(#EXEC)
0110 0000*
0112 1EAB    JP      QR10
0114        END SSINT

```

```

GLOBAL
BRKROU LABEL
SINST LABEL
NEXT PPOCEDURE
0114
!*****
*
* NEXT: SINGLE OR MULTIPLE STEPPING
* THRU USER PROGRAM WITH REG
* CONTENTS DISPLAYED AFTER EACH
* INSTRUCTION EXECUTION.
*
*****!
ENTRY
0114 34CA LDA R10,R12(#GETNXT)
0116 0000*
0118 1FA0 CALL QR10 ! SKIP REST CMD !
011A E605 JR Z,KA ! NO NEXT COUNT !
011C 34CA LDA R10,R12(#GETADR)
011E 0000*
0120 1FA0 CALL QR10 ! GET COUNT !
0122 0D34 TEST R3
0124 EE01 JR NZ,KB ! COUNT<0 !
0126 ED31 KA:LDK R3,#1 ! SET CNT=1 !
0128 6FE3 KB:LD BRKCNT(R14),R3 ! SET BRKCNT !
012A 030A
012C 34CA LDA R10,R12(#RGHDR1)
012E 0000*
0130 1FA0 CALL QR10 ! DISPLAY HDR !
0132 34CA LDA R10,R12(#RGHDR2)
0134 0000*
0136 1FA0 CALL QR10
! SINGLE INSTRUCTION EXECUTION ROUTINE !
SINST:
0138 3402 LDAR F2,SSINT ! SETUP INT HDLR !
013A FF94
013C 61E3 LD R3,BRKADR(R14)
013E 0316
0140 4FE3 CP R3,RPC_(R14) ! PC=BRKADR(R14)? !
0142 033E
0144 EE0D JR NZ,KC ! NO CONTINUE....!
0146 61E3 LD R3,BRKADR(R14)
0148 0316
014A 61E1 LD R1,BRKSTR(R14)
014C 0314
014E 2F31 LD QR3,R1 ! RESTORE ORIGINAL INST !
0150 E807 JR KC ! CONTINUE.....!
! BREAK INTERRUPT HANDLER ROUTINE ENTRY !
BRKROU:
0152 3402 LDAR R2,BRK1HD ! SET INT HDLR !

```

```

0154 FF4E
0156 61E3      LD      R3,BRKADR(R14)
0158 0316
015A 6101      LD      R1,BRKSTR      ! RESTORE BRK INST !
015C 0314
015E 2F31      LD      @R3,R1

      ! EXECUTE SINGLE USER INST AND RETURN BY IRET !
      KC:
0160 7C01      DI      VI
0162 7D15      LDCTL   R1,PSAPOFF
0164 7613      LDA     R3,VEC_PC(R1)
0166 001E
0168 3332      LD      R3(#12),P2      ! SET INT HDLR IN PSA !
016A 000C

016C D097      CALP    RESTOR      ! RESTORE REGS,PC,PCW !
016E 61EF      LD      R15,R15_(R14)  ! RESTORE SP !
0170 033C
0172 31F1      LD      R1,R15(#2)
0174 0002
0176 6FE1      LD      TMPFCW(R14),R1
0178 031A
017A 0501      OR      R1,#VINTR      ! ENABLE VI !
017C 1000
017E 33F1      LD      R15(#2),R1    ! PUT BACK !
0180 0002

      ! RESTORE USER R12 AND R14 !
0182 61E1      LD      R1,F1_(R14)
0184 0320
0186 93F1      PUSH    @R15,R1
0188 61EC      LD      R12,R12_(R14)
018A 0336
018C 61E1      LD      R1,R14_(R14)
018E 033A
0190 A11E      LD      R14,R1

0192 97F1      POP     R1,@R15
0194 3B16      OUT     %FFC0,R1      ! ARM SINGLE STEP !
0196 FFC0
0198 A1AA      LD      R10,R10
019A 7B00      IRET     ! RTN AND EXECUTE ONE INST !
019C          END NEXT
          END DEBUG_CMD

```

2. SEND MODULE

Z8000ASM 2.02

LOC CBJ CODE STMT SOURCE STATEMENT

1 SEND_CMD MODULE
\$LISTON \$TTY

```
!*****
* SEND CMD: SENDS SPECIFIC BLOCK OF *
* MEM <BGN ADR><END ADR> TO *
* MCZ TO STORE AS <FNAME> *
* W/RELOAD OPT. ENTRY ADR *
* <ENT ADR>. ALL HEX VALUES *
* CONVERTED TO ASCII FOR *
* TRANS. IN TEXTONIX FROMAT *
* PACKETS; AND UP TO TEN *
* ATTEMPTS AT PACKET TRANS. *
* WILL BE MADE. *
*
* SYNTAX: SEND <BGNADR><ENDADR> *
* [ <ENT ADR> ] *
*
*****!
```

CONSTANT

(INCLUDE GLOBAL CONSTANTS)

EXTERNAL	
FNAME	PROCEDURE
BIARG	LABEL
GETADR	PROCEDURE
SNDMSG	PROCEDURE
SKIPLN	PROCEDURE
CMDPAS	PROCEDURE
CONVB	LABEL
CONVW	PROCEDURE
EROR	LABEL
GETACK	PROCEDURE
OUTLNE	PROCEDURE

GLOBAL
\$SECTION SEND_PROC
\$REL 0

```

GLOBAL
0000 SNDPAC PROCEDURE
!*****!
*      SNDPAC: FORMATS TRANSFER PACKET      *
*      DATA IN TEXTRONIX FROMAT           *
*      AND SENDS TO MCZ.                   *
*
*      REG USE: INPUT  R8 = BGN ADR          *
*                      R9 = WORD CNT         *
*      RETURN R8 = BGN ADDR OF             *
*                      NEXT AND Z IF LAST*
*
*****!
ENTRY
0000 8D38    CLR      R3
0002 C82F    LDB      RL0,#'/'
0004 6EE8    LDB      OUTBUF(R14),RL0      ! STORE / !
0006 0080
0008 69E0    INC      OUTPTR(R14),#1
000A E3F6
000C 8D94    TEST     R9
000E 9E06    RET      Z

!CONVERT BGN ADR TO ASCII, ADD TO CKSUM !
0010 A185    LD       R5,R8
0012 34CA    LDA      R10,R12(#CONVW)
0014 0000*
0016 1FA0    CALL     @R10                ! CONVERT ASCII !
0018 A195    LD       R5,R9
001A 34CA    LDA      R10,R12(#CONVB)
001C 0000*
001E 1FA0    CALL     @R10                ! CONVERT WORD !
0020 A0BD    LDB      RL5,RL3
0022 34CA    LDA      R10,R12(#CONVB)
0024 0000*
0026 1FA0    CALL     @R10
! FORMAT ALL DATA !
0028 8D38    CLR      R3
PROCLP:
002A 208D    LDB      RL5,@R8
002C 34CA    LDA      R10,R12(#CONVB)
002E 0000*
0030 1FA0    CALL     @R10
0032 A980    INC      R8,#1
0034 AB90    DEC      R9
0036 EEF9    JR       NZ,PROCLP          ! CONT CONVERSION !
0038 A0BD    LDB      RL5,RL3            ! DONE, STR CKSUM !
003A 34CA    LDA      R10,R12(#CONVB)

```



```

003C 0000*
003E 1FA0      CALL      @R10      ! CONVERT CKSUM !
0040 1F20      CALL      @R2
0042 8D43      RESFLG    Z
0044 9E08      RET
0046          END SNDPAC

```

```

0046          GLOBAL
LASTPC PROCEDURE
!*****
*   LASTPC:  FORMATS LAST PACKET FOR   *
*           TRANS WITH ENTRY ADR,     *
*           COUNT=0, AND CKSUM.       *
*                                     *
*   RFG USE:  INPUT   R6 = ENTRY ADR  *
*                                     *
*****!

```

```

ENTRY
0046 A165      LD        R5,R6
0048 34CA      LDA       R10,R12(#CONVW)
004A 0000*
004C 1FA0      CALL      @R10      ! CONVERT BYTE !
004E CD00      LDB       RL5,#0
0050 34CA      LDA       R10,R12(#CONVB)
0052 0000*
0054 1FA0      CALL      @R10      ! CONVERT WORD !
0056 A0BD      LDB       RL5,RL3   ! LOAD CKSUM !
0058 34CA      LDA       R10,R12(#CONVB)
005A 0000*
005C 1FA0      CALL      @R10
005E 1F20      CALL      @R2      ! SND TO....!
0060 9E08      RET
0062          END LASTPC

```

```

0062          GLOBAL
ERMSG PROCEDURE
!*****
*   ERMSG:  SENDS ASCII // MSG TO     *
*           MCZ TO ABORT SEND CMD.    *
*                                     *
*****!

```

```

ENTRY
0062 C02F      LDB       RH0,#'/'
0064 C92F      LDB       RL3,#'/'
0066 6FE0      LD        OUTBUF(R14),R0   ! LOAD BUF // !
0068 0080
006A 76ED      LDA       R13,OUTBUF(R14)
006C 0080
006E A9D1      INC       R13,#2
0070 6FED      LD        OUTPTR(R14),R13
0072 0306

```

```

0074 34CA      LDA      R10,R12(#OUTLINE)
0076 0000*
0078 1FA0      CALL     QR10          ! OUTPUT LINE - MCZ !
007A 9E08      RET
007C          END ERMSG

```

```

007C          GLOBAL
SEND PROCEDURE
!*****
*
* SEND: FORMATS AND TRANSFERS PACS
* CONTAINING DATA FROM THE
* SPECIFIED MEMORY AREA TO BE SAVED
* AS A MCZ FILE.
*
*****!

```

```

ENTRY
007C 34CA      LDA      R10,R12(#FNAME)
007E 0000*
0080 1FA0      CALL     QR10          ! CK FNAME !
0082 0B0B      CP       R11,%FFFE    ! CK FOR NO ADR !
0084 FFFE
0086 E60B      JR       Z,GOTERR
0088 A1B8      LD       R8,R11        ! SAVE BGN ADR !
008A 34CA      LDA      R10,R12(#GETADR)
008C 0000*
008E 1FA0      CALL     QR10
0090 E706      JR       C,GOTERR      ! ERROR !
0092 A137      LD       R7,R3        ! SAVE END ADR !
0094 34CA      LDA      R10,R12(#GETADR)
0096 0000*
0098 1FA0      CALL     QR10          ! GET ENT ADR !
009A A136      LD       R6,R3
009C 8387      SUB      R7,R8        ! # BYTES !
GOTERR:
009E 34CA      LDA      R10,R12(#ERROR)
00A0 0000*
00A2 1EA7      JP       C,QR10       ! RTN EXEC !
00A4 A970      INC      R7           ! BYTE COUNT !
00A6 65E3      SET      MFLAGS(R14),#SNDMDE
00A8 031C
! SIG SND MODE !
! SEND CMD TO MCZ TO LOAD SEND PROGRAM !
00AA 34CA      LDA      R10,R12(#CMDPAS)
00AC 0000*
00AE 1FA0      CALL     QR10          ! SND CMD !
00B0 9E06      RET      Z
00B2 34CA      LDA      R10,R12(#GETACK) ! GET ACK !
00B4 0000*
00B6 1FA0      CALL     QR10

```

```

00B8 E603      JR      Z,AC
00BA 3402      LDAR     R2,CPEAR      ! SEND FILE OPEN !
00BC 00B0
00BE F83B      JR      PEM           ! ERROR TO CONS !

00C0 67E5      AC:BIT      MFLAGS(R14),#ESC
00C2 031C
00C4 E607      JR      Z,AD           ! CK FOR ESC KEY !
!SEND ABORT TO CONSOLE AND MCZ IF REC ESC KEY !
SNDABT:
00C6 D033      CALR     ERMSG
00C8 3402      LDAR     R2,ABTMSG     ! SND ABORT MSG !
00CA 0086
00CC 34CA      LDA      R10,R12(#SNDMSG)
00CE 0000*
00D0 1FA0      CALL     GR10
00D2 9E08      RET

00D4 4DF5      AD:LD      RETRY(R14),#10
00D6 0342
00D8 000A
00DA 0B07      CP       R7,#30
00DC 001E
00DE EF03      JR      NC,COMP        ! #BYTES SND > 30 !
00E0 A179      LD       R9,R7        ! #<30, USE REST !
00E2 8D78      CLR      R7          ! LAST PACKET !
00E4 F804      JR      AE

COMP:
00E6 2109      LD       R9,#30        ! SND 30-BYTES !
00E8 001E
00EA 0307      SUB      R7,#30        ! GET NEW #BYTES !
00EC 001E
00EE A19B      AE:LD      R11,R9      ! SAVE COUNT !

! MAIN RETRY LOOP FOR RESENDING PACKETS TO MCZ !
RESEND:
00F0 67E5      BIT      MFLAGS(R14),#ESC ! CK FOR USER ABORT !
00F2 031C
00F4 FEF8      JR      NZ,SNDABT     ! GOT, SND ABORT...!
00F6 3402      LDA      R2,R12(#OUTLNE)
00F8 0000*
00FA D07E      CALR     SNDPAC
00FC E60F      JR      Z,LONE        ! SND LAST PACKET !
00FE 34CA      LDA      R10,R12(#SKIPLN)
0100 0000*
0102 1FA0      CALL     GR10          ! SKIP MCZ INPUT !
0104 34CA      LDA      R10,R12(#GETACK)
0106 0000*
0108 1FA0      CALL     GR10          ! WAIT FOR ACK !

```

```

010A FF01      JR      NZ,AF      ! REC NON-ACK !
010C 28E3      JR      AD          ! REC ACK !

010E E711      AF:JR      C,AG      ! REC 9 FOR ABORT !
0110 83E8      SUB      R8,R11
0112 A1B9      LD        R9,R11      ! RESEND !
0114 6BE0      DEC      RETRY(R14),#1
0116 0342
0118 E615      JR      Z,SNDSTP      ! SEND DONE !
011A E8EA      JR      RESEND

      ! SEND LAST PACKET TO MCZ !
      LONE:
011C 34C2      LDA      R2,R12(#OUTLINE)
011E 0000*
0120 D06E      CALR     LASTPC      ! PREPARE LAST PAC !
0122 34CA      LDA      R10,R12(#SKIPLN)
0124 0000*
0126 1FA0      CALL     @R10      ! SKIP MCZ ECHO !
0128 34CA      LDA      R10,R12(#GETACK)
012A 0000*
012C 1FA0      CALL     @R10      ! WAIT FOR ACK !
012E 9E06      RET      Z          ! FINISHED...!
0130 EF06      JR      NC,AZ      ! RESEND.....!

0132 3402      AG:LDAR    R2,WRTErr
0134 0024
      PEM:
0136 34CA      LDA      R10,R12(#SNDMSG)
0138 0000*
013A 1FA0      CALL     @R10      ! SEND WRITE ERROR !
013C 9E08      RET

013E 6BE0      AZ:DEC      RETRY(R14),#1
0140 0342
0142 EED6      JR      NZ,RESEND      ! TRY AGAIN !

      SNDSTP:
0144 D072      CALR     ERMSG
0146 3402      LDAR     R2,CKMSG
0148 0036
014A 34CA      LDA      R10,R12(#SNDMSG)
014C 0000*
014E 1FA0      CALL     @R10      ! SND CKSUM ERROR !
0150 9E08      RET
0152      END SEND

```

ABTMSG:		
0152	07	BVAL %07
0153	2F	BVAL /
0154	4142	WVAL 'AB'
0156	4F52	WVAL 'OR'
0158	54	BVAL 'T'
0159	0D	BVAL %0D

WRTERR:		
015A	18	BVAL %18
015B	2F	PVAL /
015C	4649	WVAL 'FI'
015E	4C45	WVAL 'LE'
0160	2057	WVAL 'W'
0162	5249	WVAL 'RI'
0164	5445	WVAL 'TE'
0166	2045	WVAL 'E'
0168	5252	WVAL 'RR'
016A	4F52	WVAL 'OR'
016C	0D	BVAL %0D
016D	20	BVAL

OPERR:		
016E	17	BVAL %17
016F	2F	BVAL /
0170	4F50	WVAL 'OP'
0172	454E	WVAL 'EN'
0174	2046	WVAL 'F'
0176	494C	WVAL 'IL'
0178	4520	WVAL 'E'
017A	4552	WVAL 'ER'
017C	524F	WVAL 'RO'
017E	52	BVAL 'R'
017F	0D	BVAL %0D

CKMSG:		
0180	12	BVAL %12
0181	43	BVAL 'C'
0182	4B53	WVAL 'KS'
0184	554D	WVAL 'UM'
0186	2045	WVAL 'E'
0188	5252	WVAL 'RR'
018A	4F52	WVAL 'OR'
018C	0D	BVAL %0D
019D	20	BVAL

END SEND_CMD

0 errors
Assembly complete

APPENDIX C - ECOTLOAD Program Listing

A. PROM PROGRAMMING

The Bootload program listing contained in sections B - F was programmed into the firmware by the use of the two support programs (Z8XFR and CPMXFR) of Appendix E and the following procedures.

1. Bootup the SASS hardware to the monitor program by the following sequence of actions:

RESET

TYPE <CR>

RESET MCZ System

TYPE <CR>

DEPRESS "INTA" switch (NMI).
(displays: "LOADING.....")

When prompt appears ('*'), the monitor is loaded (approximately 20 sec).

2. Bootup the INTEL MDS System with a CP/M disk having the CPMXFR program.
3. On the SASS Developmental System, load the desired bootload program into memory at address 6000 HEX by the following command:

TYPE "LOAD <Filename> 6000"

4. Load Z8000 transfer program (CPMXFR) by:

TYPE "LOAD CPMXFR"

5. Setup to execute transfer program with the following commands:

TYPE "F RPC <CR>"

TYPE 'A900 <CR>'

TYPE "5000 <CR>"

6. Connect the cable between the TTY port on the MDS system and connector 'A' on the SASS system.
(connector 'A' is the MCZ port cable of MBC)
7. Execute the CP/M transfer program (CPMYFR) on the MDS system, selecting code transfer ('C').
8. On the SASS system, begin transfer by the following actions:

TYPE "G <CR>"

After the transfer is completed, the SASS monitor will display the prompt ('*'), and the MDS system will provide an indication that two files (PROM08.OBJ and PROM09.OBJ) have been created.

To move the file first to ISIS-II and then to the PROM programmer, the following procedures apply:

9. On the MDS system with an ISIS-II disk in drive B:, transfer the two CP/M files to ISIS as follows:

TYPE 'TOISIS PROM08.OBJ <CR>'

TYPE "TOISIS PROM09.OBJ <CR>"

10. Reboot MDS system with ISIS-II disk in drive A: and
and convert OBJ files to HEX files as follows:

TYPE "OBJHEX PROM08.OBJ TO PROM08.HEX <CR>"

TYPE "OBJHEX PROM09.OBJ TO PROM09.HEX <CR>"

11. Execute UPM (Universal PROM Programmer) by:

PLACE CLEAN PROM IN PROGRAMMER

TYPE "UPM <CR>"

TYPE "READ FILE PROM08.HEX INTO 0000"

TYPE "PROGRAM FROM 0001 TO 2048 START 0000"

PLACE CLEAN PROM IN PROGRAMMER (high byte)

TYPE "READ FILE PROM09.HEX INTO 0000"

TYPE "PROGRAM FROM 0000 TO 2047 START 0000"

The PROM's are now programmed.

3. BOOTLOAD PROGRAM LISTING

1. BOOTLOAD1 MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 BOOTLOAD1 MODULE
\$LISTON \$TTY

CONSTANT

RXR := 2
TXR := 0
PAR := 7
PORTAD := %FFD9
PORTBD := %FFE1
PORTAC := %FFDB
PORTBC := %FFE3

IDPORT := %FFCB
ICPORT := %FFC9

ROM_DISABLE := %FFF0
TCMD := %FFD2
TDTA := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF9
VINTR := %(2)0001000000000000
VIBIT := 12
ESCAPE := %1B
BS := %08
LINDEL := %7F
CR := %0D
LF := %0A
TXOFCH := %13
TXONCH := %11
INSIZ := 128
OUTSIZ := 128
RBSIZ := 256

! INTBUF SIZE !
! OUTBUF SIZE !
! RING BUFFER SIZE !

! BIT POSITIONS IN MONITOR FLAG WORD !

TRPMDE := 0
ISTOP := 1
OSTOP := 2

```

SNDMDE      := 3
LDMDE       := 4
ESC         := 5
TXMSK       := %6

COMDS       := 11
MAX_CPU     := 8

```

TYPE

```

MESSAGE      ARRAY[3 WORD]
MEM_ARRAY    ARRAY[32 WORD]
SWITCH       ARRAY[3 WORD]
CPU_ENTRY    RECORD [
    SIGNAL          WORD
    CPU_ID          WORD
    MSG_BLK         MESSAGE
    MEM_MAP         MEM_ARRAY]
ID_ARRAY     ARRAY[MAX_CPU WORD]
ENTRY_ARRAY  ARRAY[MAX_CPU CPU_ENTRY]

```

INTERNAL

```

$SECTION TABLE1_DATA
$ABS 0

```

2000

```

CONFIG_TABLE RECORD [
    RW_PATTERN      WORD
    CPU_NUM         WORD
    NORM_RW_PAT     WORD
    NORM_CPU_CNT    WORD
    TABLE_LOCK     WORD
    CPU_CNT         WORD
    CPU_LIST        ENTRY_ARRAY]

```

INTERNAL

```

$SECTION DATA_DEC
$ABS 0

```

```

0000      INTPUF      ARRAY [128 BYTE]
0080      OUTBUF      ARRAY [128 BYTE]
0100      RNGPUF      ARRAY [256 BYTE]
0200      MCZBUF      ARRAY [256 BYTE]

0300      BUFADR      WORD
0302      BUFSIZ      WORD

0304      INTPTR      WORD
0306      OUTPTR      WORD

0308      UNIMP        WORD

```

030A	BRKCNT	WORD
030C	NXTPTR	WORD
030E	GETOUT	WORD
0310	MCZPUT	WORD
0312	MCZGET	WORD
0314	BRKSTR	WORD
0316	BRKADR	WORD
0318	TMPSP	WORD
031A	TMPFCW	WORD
031C	MFLAGS	WORD

! USER REGISTER STORAGE !

031E	R0_	WORD
0320	R1_	WORD
0322	R2_	WORD
0324	R3_	WORD
0326	R4_	WORD
0328	R5_	WORD
032A	R6_	WORD
032C	R7_	WORD
032E	R8_	WORD
0330	R9_	WORD
0332	R10_	WORD
0334	R11_	WORD
0336	R12_	WORD
0338	R13_	WORD
033A	R14_	WORD
033C	R15_	WORD
033E	RPC_	WORD
0340	RFC_	WORD
0342	RETRY	WORD
0344	ADR_STR	WORD
0346	CMDTBL	ARRAY [12 WORD]

INTERNAL
\$SECTION PSA_DATA
\$ABS 0

0000	PSA	RECORD [
		DATA_AREA	WORD
		CODE_AREA	WORD
		UNIMP_INST	SWITCH
		PRIV_INST	SWITCH
		SYSTEM_CALL	SWITCH
		SEG_TRAP	SWITCH
		NMI_INT	SWITCH
		NVI_INT	SWITCH

```

VEC_FCW      WORD
VEC_PC      ARRAY [200 WORD]
]

```

```

$SECTION EXEC_PROC
EXTERNAL
    NMI      PROCEDURE
    CONINT   PROCEDURE
    MCZMND   PROCEDURE
    BOOTLOAD_CPU  PROCEDURE
    MEM_CPU   LABEL

```

```

GLOBAL EROR LABEL
GLOBAL EXEC LABEL
GLOBAL INITL PROCEDURE

```

0000

```

!*****
*      DMONITOR INITIALIZATION      *
!*****

```

```

ENTRY
ORGADP:

```

```

0000 0000      WVAL      %0000      ! UNIMP INST !
0002 4000      WVAL      %4000
0004 0008      WVAL      STARTP

```

```

PHYS_ID:

```

```

0006 F1F1      WVAL      %F1F1      ! UNIQUE PHYS_ID !

```

```

!*****
*
*      INDEPENDENT PROCESSOR STAGE
*
!*****

```

```

! START OF INITIAL ENTRY TO DMONITOR !
STARTP:

```

```

!*****
*
*      CLEAR MEM: 'CLEARS' MEMORY BY WRIT-
*      ING R/W PATTERN <55AA> AT THE
*      BEGINING OF EACH BLOCK AND
*      CLEARING THE NEXT THREE WORD
*      LOCATIONS. CPU WILL WAIT AT
*      THE END FOR A PERIOD OF TIME
*      (APPROX. 2MSEC).
*
!*****

```

```

0008 2104      LD        R4, #%F800      ! TOP MEM BLOCK !
000A F800
000C 2101      LD        R1, #%55AA      ! R/W PATTERN !
000E 55AA

```

```

0010 0D28      CLR      R2
0012 0D43      RES FLG  Z

```

```

! MAIN LOOP FOR CLEARING MEMORY !
CLEAR_MEM:

```

```

DO
0014 A143      LD        R3,R4
0016 A931      INC       R3,#2
0018 2F41      LD        @P4,R1      ! STORE PATTERN !
001A 2105      LD        R5,#5
001C 0005

```

```

DO
001E 2F32      LD        @R3,R2
0020 A931      INC       R3,#2
0022 AB50      DEC       R5
0024 E601      JR        Z,NXT_ONE
0026 E8FB      OD

```

```

NXT_ONE:

```

```

0028 0E04      CP        R4,#0000    ! CK FOR LAST FLK !
002A 0000
002C E603      JR        Z,WAIT1
002E 0304      SUE       R4,#0800
0030 0800
0032 E8FB      OD

```

```

WAIT1:

```

```

!*****
*
* CPU WAITS APPROX. 2MSEC FOR ALL
* CPU'S TO COMPLETE THE SAME TASK
* BEFORE CONTINUING.
*
*****!

```

```

0034 2103      LD        R3,#50
0036 0032
DO
0038 1904      MULT      R4,#1
003A 0001
003C AB30      DEC       R3
003E E601      JR        Z,SCRIBE_MEM
0040 F8FB      OD

```

```

!*****
*
*  SCRIBE_MEM: TRAVERSES THROUGH MEM
*              BLOCKS SEARCHING FOR R/W PAT-
*              TERN INDICATING ACCESSIBLE
*              MEMORY (RAM). CPU INDICATES
*              ITS PRESENCE BY INCREMENTING
*              STORED CPU_NUM. CPU WAITS FOR
*              FOR A PERIOD OF 2MSEC.
*
*****!
SCRIBE_MEM:
0042 2104      LD      R4,%F800      ! TOP BLOCK ADR !
0044 F800

! MAIN LOOP FOR MEMORY SCRIBE !

      DO
0046 2148      LD      R8,R4
0048 8B18      CP      R8,R1      ! CK FOR R/W PATTERN !
004A FE09      JR      NZ,NOMATCH ! NOT FOUND !

! CPU INDICATES ACCESS TO THIS BLOCK !
004C A143      LD      R3,R4
004E A931      INC     R3,#2      ! GET CPU_NUM ADR !
0050 3B26      OUT     BUS_LOCK,R2 ! MUTUAL EXCLUSION !
0052 FFF9
0054 2138      LD      R8,R3      ! GET CPU_NUM !
0056 A980      INC     R8,#1      ! INCREMENT !
0058 2F38      LD      R3,R8      ! RESTORE !
005A 3E26      OUT     BUS_UNLOCK,R2
005C FFF8

      NOMATCH:
005E 8D44      TEST     R4
0060 E603      JR      Z,WAIT2    ! FOUND LAST BLOCK !
0062 0304      SUB     R4,%0800
0064 0800

0066 E8EF      OD

```

WAIT2:

```
!*****
*
* CPU WAITS APPROX. 2MSEC FOR ALL
* CPU'S TO COMPLETE THE SAME TASK
* BEFORE CONTINUING.
*
*****!
```

```
0068 2123 LD R3,#50
006A 0032
DO
006C 1904 MULT RR4,#1
006E 0001
0070 AB30 DEC R3
0072 E601 JR Z,DEFINE_MEM
0074 F8FE OD
```

```
!*****
*
* DEFINE MEM: CPU SEARCHES FOR LOWEST
* MEMORY BLOCK WITH HIGHEST CPU
* COUNT (GLOBAL) AND LOWEST MEM
* BLOCK WITH CPU_NUM=1 (LOCAL).
*
* REG USE: RETURN R7 = LOW GLOBAL
* R6 = LOW LOCAL
* R5 = CPU_NUM (HIGH)
*
*****!
```

DEFINE_MEM:

```
0076 8D58 CLR R5
0078 2104 LD R4,%F800 ! TOP BLOCK ADR !
007A F800
007C A146 LD R6,R4 ! LOCAL START !
007E A147 LD R7,P4 ! GLOBAL START !
DO
0080 2148 LD R8,R4
0082 8B18 CP R8,R1 ! CK FOR R/W PATTERN !
0084 EE0C JR NZ,NEXT_BLK ! NOT ACCESSIBLE !
```

! CHECK FOR LOCAL OR GLOBAL !

```
0086 A142 LD R2,R4
0088 A921 INC R2,#2 ! GET CPU_NUM ADR !
008A 2123 LD R3,R2 ! GET CPU_NUM !
008C 0B03 CP R3,#1 ! CK FOR LOCAL !
008F 0001
0090 E605 JR Z,LOCAL_MEM
```

! RECORD GLOBAL MEM AND UPDATE CPU_NUM !

```

0092 8B53      CP      R3,R5
0094 F704      JR      C,NEXT_BLK      ! R5 IS HIGHEST !
0096 A135      LD      R5,R3          ! UPDATE CPU CNT !
0098 A147      LD      R7,R4          ! UPDATE GLOBAL ADF !
009A E801      JR      NEXT_BLK

```

! RECCSD LOCAL MEMORY !

LOCAL_MEM:

```

009C A146      LD      R6,R4          ! UPDATE LOCAL !

```

NEXT_BLK:

```

009E 8D44      TEST     R4
00A0 F603      JR      Z,SPEC_CASE    ! FINISHED !
00A2 0304      SUB      R4,#0800      ! GET NEXT BLOCK !
00A4 0800

```

```

00A6 E8EC      OD

```

```

!****      R7 = LOW GLOBAL      R6 = LOW LOCAL      ****!
!                      R5 = CPU COUNT                      !

```

SPEC_CASE:

!**** FOR SINGLE PROCESSOR MONOBOARD CASE ***!

```

00A8 2107      LD      R7,#F800
00AA F800
00AC FE04      JR      NZ,STACK_INT
00AE 2107      LD      R7,#8000
00B0 8000
00B2 2105      LD      R5,#1
00B4 0001

```

STACK_INT:

```

!*****
*
*      LOCAL INITIALIZATION STAGE
*
*      INITIALIZATION OF INTERNAL CPU
*      SPECIAL PURPOSE REGISTERS
*      AND CPU DATA STRUCTURES.
*
*****!

```

```

!*****
*      LOAD PROGRAM STATUS AREA POINTER
*
*****!

```

```

00B6 A161      LD      R1,R6
00B8 0101      ADD      R1,#0100      ! SET PSA !
00BA 0100

```



```

003C 7D1D      LDCTL      PSAPCFF,R1      ! LOAD PSAP !

! R6 CONTAINS LOW MEMORY AREA FOR DMONITOR DATA!
00BE A164      LD          R4,R6
00C7 C1F4      ADD          R4,#%0200
00C2 0230
00C4 A14E      LD          R14,R4      ! DATA_AREA !
00C6 34FC      LDAR        R12,ORGADR    ! SET CCDE ADR !
00C8 FF36

! **** R12=CCDE ADR      R14=DATA AREA **** !
!*****
*              SET STACK POINTER              *
!*****

00CA A161      LD          R1,R6      ! SET UP STACK PTR !
00CC 0101      ADD          R1,#%00F0
00CE 00F0
00D0 A11F      LD          R15,R1      ! SET SYSTEM STACK POINTER !

! ** INITIALIZE REFRESH CNTR REGISTER ** !

00D2 2101      LT          R1,#%9F00      ! LD RATE VALUE !
00D4 9F00
00D6 7D1B      LDCTL      REFRESH,R1

!*****
*
*   SFTW_INIT: INITIALIZES ALL BASIC
*               DATA STRUCTURES FOR THE
*               SINGLE PROCESSOR.
*
!*****

! CLEAR DMONITOR RAM AREA !
00D8 A162      LD          R2,R6      ! CLR DMONITOR RAM !
00DA A121      LD          R1,R2
00DC A911      INC          R1,#2
00DE 2103      LD          R3,#%250
00E0 0250
00E2 0D65      LD          GR6,#0
00E4 0000

00E6 BB21      LDIR        GR1,GR2,R3
00E8 0310

! INITIALIZE BLANK BUFFERS !
00EA 34F2      LDA          R2,R14(#INTBUF)      ! FILL CONS INPUT BUF !
00EC 0000
00EE 34E1      LDA          R1,R14(#INTBUF)      ! WITH SPACES !

```

```

00FC 0000
00F2 1911      INC      R1,#2
00F4 2123      LD        R3,#INSIZ
00F6 0080
00F8 0D25      LD        QR2,#' '
00FA 2020
00FC BB21      LDIR      QR1,QR2,R3
00FE 0310

```

```

! LD FIXED DATA IN RAM !
0100 34E7      LDA        R7,R14(#INTBUF)
0102 0000
0104 33E7      LD        R14(#INTPTR),P7
0106 0304
0108 34E7      LDA        R7,R14(#OUTBUF)
010A 0080
010C 33E7      LD        R14(#OUTPTR),R7
010E 0306

```

```

!*****
*   INITIALIZE PROGRAM STATUS AREA   *
!*****

```

```

0110 7D25      LDCTL      R2,PSAPOFF
0112 2101      LD        R1,#%4000
0114 4000
0116 8D48      CLR        R4
0118 3423      LDA        R3,R2(#UNIMP_INST)
011A 0004
          DO
011C 7331      LD        R3(P4),R1
011E 0400
          INC      R4,#4
0120 A943      CP        R4,#28
0122 0B04
0124 001C      JR        Z,LD_PC
0126 E601      OD
0128 E8F9      LD_PC:

```

```

012A 3423      LDA        R3,R2(#NMI_INT)      ! LOAD NMI HDLR !
012C 001C
012E 76C4      LDA        R4,NMI(R12)
0130 0020*
0132 3334      LD        R3(#2),R4
0134 0002

```

```

! SET INTERRUPT HANDLERS !
0136 3423      LDA        R3,R2(#VEC_PC) ! BASE OF INT VEC!
0138 002A

```

```

013A 76C2      LEA        R2,CONINT(R12) !CONS INPUT!
013C 0000*
013E 3332      LD         R3(#0),R2
0140 0000

```

```

                                ! MCZ INPUT !
0142 76C2      LDA        R2,MCZEND(R12)
0144 0000*
0146 3332      LD         R3(#4),R2
0148 0004

```

```

!*****
*
*   HDW_INIT:  INITIALIZES HARDWARE IC
*               TO A KNOWN STATE WITH ALL
*               NECESSARY INPUT_OUTPUT
*               FUNCTIONS.  INADDITION, THE
*               SYSTEM TIMER FUNCTIONS AND
*               INTERRUPT STRUCTURE IS SET
*               TO A KNOWN STATE.
*
*****!

```

```

HDW_INIT:
! ** INITIALIZE USARTS  9551 ** !

```

```

014A 2101      LD         R1,#%00CE      ! SET MODE !
014C 00CE
014F 3A96      OUTB       PORTBC,RL1
0150 FFE3
0152 3A96      OUTB       PORTAC,RL1
0154 FFDB

0156 2101      LD         R1,#%0027      ! TX, RX, RTS, DTR !
0158 0027
015A 3A96      OUTB       PORTBC,RL1
015C FFE3
015E 3A96      OUTB       PORTAC,RL1
0160 FFDB

```

```

! ** INIT. INTERRUPT CONTRCLLER  8259A ** !

```

```

0162 2101      LD         R1,#%0013      ! LOAD ICW1 !
0164 0013
0166 3A96      OUTB       ICPORT,RL1
0168 FFC9

016A 2101      LD         R1,#%0000      ! LOAD ICW2 !
016C 0000
016E 3A96      OUTB       IDPORT,PL1

```

0170 FFCB

0172 2101 LD R1, #0003 ! LOAD IC#4 !
0174 0003
0176 3A96 OUTB IDPORT, PL1
0178 FFCB

! ** INITIALIZE TIMING CONTROLLER 9513 ** !

017A 2101 LD R1, #FFFF ! RESET DEVICE !
017C FFFF
017E 3B16 OUT TCMD, R1
0180 FFD2

0182 2101 LD R1, #FFEF ! SET 16-BIT MODE !
0184 FFEF
0186 3B16 OUT TCMD, R1
0188 FFD2

018A 2101 LD R1, #FF5F ! LOAD ALL REGS !
018C FF5F
018E 3B16 OUT TCMD, R1
0190 FFD2

0192 2101 LD R1, #FFE8 ! DISABLE AUTO SEQ !
0194 FFE8
0196 3B16 OUT TCMD, R1
0198 FFD2

! SYSTEM 32-BIT CONTINUOUS CLOCK !

019A 2101 LD R1, #FF01 ! LD 'CM' CNTR GRP1 !
019C FF01
019E 3B16 OUT TCMD, R1
01A0 FFD2
01A2 2101 LD R1, #0C29 ! CNTR MODE VALUE !
01A4 0C29
01A6 3B16 OUT TDTA, R1
01A8 FFD0

01AA 2101 LD R1, #FF02 ! LD 'CM' CNTR GRP2 !
01AC FF02
01AE 3B16 OUT TCMD, R1
01B0 FFD2
01B2 2101 LD R1, #0029 ! CNTR MODE VALUE !
01B4 0029
01B6 3B16 OUT TDTA, R1
01B8 FFD0

! QUANTUM COUNT-DOWN TIMER !

01BA 2101 LD R1, #FF05 ! LD 'CM' CNTR GRP5 !

01B0	FF05			
01B2	3B16	OUT	TCMD,R1	
01C0	FFD2			
01C2	2101	LD	R1, #0002	! CNTR MODE VALUE !
01C4	0002			
01C6	3B16	OUT	TDTA,R1	
01C8	FFD0			
01CA	2101	LD	R1, #FF0D	! LD 'LOAD' GRP5 !
01CC	FF0D			
01CE	3B16	OUT	TCMD,R1	
01D0	FFD2			
01D2	2101	LD	R1, #0005	! LD VALUE !
01D4	0005			
01D6	3B16	OUT	TDTA,R1	
01D8	FFD0			
! HARDWARE PRE-EMPT MECHANISM !				
01DA	2101	LD	R1, #FF04	! LOAD 'CM' GRP4 !
01DC	FF04			
01DE	3B16	OUT	TCMD,R1	
01E0	FFD2			
01E2	2101	LD	R1, #0002	! LOAD CM !
01E4	0002			
01E6	3B16	OUT	TDTA,R1	
01E8	FFD0			
01EA	2101	LD	R1, #FF0C	! LOAD 'LOAD' GRP4 !
01EC	FF0C			
01EE	3B16	OUT	TCMD,R1	
01F0	FFD2			
01F2	2101	LD	R1, #0005	! LOAD REG !
01F4	0005			
01F6	3B16	OUT	TDTA,R1	
01F8	FFD0			
01FA	2101	LD	R1, #FF43	! LD GEN CNTR GRP162 !
01FC	FF43			
01FE	3B16	OUT	TCMD,R1	
0200	FFD2			
0202	2101	LD	R1, #FF23	! 4PM REAL TIME CLK !
0204	FF23			
0206	3B16	OUT	TCMD,R1	
0208	FFD2			
020A	7C05	EI	VI	

```

*****
*
*      COOPERATING PROCESSOR STAGE
*      PROPER
*
*      TEST_LOCK: ROUTINE TO GAIN ACCESS
*      TO CONFIG_TABLE.
*
*      REG USE: INPUT  R7 = LOW GLOBAL MEM
*
*****!
TEST_LOCK:
020C 7678      LDA      R8, TABLE_LOCK(R7) ! LOCK ADR !
020E 0008

! MAIN LOCK TESTING LOOP !
DO
0210 3B26      OUT      BUS_LOCK, R2      ! LOCK SYSTEM BUS !
0212 FFF9
0214 0D86      TSET     GR8                ! TEST TABLE LOCK !
0216 3B26      OUT      BUS_UNLOCK, R2 ! UNLOCK SYSTEM BUS !
0218 FFF8
021A ED03      JR       PL, TEL_ACCESS ! GOT EXCLU. ACCESS !

! DELAY BEFORE NEXT ATTEMPT TO REDUCE !
! CYCLE STEALING ON BUS FROM BOOTLOAD_CPU !
021C 1904      MULT     RR4, #1
021E 0001
0220 F8F7      OD

*****
*
*      TEL_ACCESS: ROUTINE TO DETERMINE
*      BOOTLOAD_CPU AND MEMBER_CPU'S.
*
*****!
TEL_ACCESS:
0222 7673      LDA      R3, CPU_CNT(R7) ! TABLE LOCKED !
0224 000A
0226 2134      LD       R4, GR3          ! GET LOG CPU NO. !
0228 0B04      CP       R4, #0          ! IS CPU FIRST? !
022A 0000
022C E603      JR       Z, GO_BOOTCPU ! YES !
022E 76C1      LDA      R1, MEM_CPU(R12)
0230 0000*
0232 1E18      JP       GR1

GO_BOOTCPU:
0234 76C1      LDA      R1, BOOTLOAD_CPU(R12)
0236 0000*

```

0238 1E18 JP GR1

023A END INITL

END BCOTLC'D1

2. BOOTLOAD2 MODULE

Z8700ASM 2.62

LOC OBJ CODE STMT SOURCE STATEMENT

1 BOOTLOAD2 MODULE
\$LISTON \$TTY

CONSTANT

RXR := 2
TXR := 0
PAR := 7
PORTAD := %FFD9
PORTBD := %FFE1
PORTAC := %FFDE
PORTBC := %FFE3

IDPORT := %FFCB
ICPCRT := %FFC9

ROM_DISABLE := %FFF0
TCMD := %FFD2
TDTA := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8

VINTR := %(2)0001000000000000

VIBIT := 12

ESCAPE := %1B

PS := %08

LINDEL := %7F

CR := %0D

LF := %0A

TXOFCH := %13

TXONCH := %11

INSIZ := 128 ! INTBUF SIZE !

OUTSIZ := 128 ! OUTBUF SIZE !

RBSIZ := 256 ! RING BUFFER SIZE !

! BIT POSITIONS IN MONITOR FLAG WORD !

TRPMDE := 0

ISTOP := 1

OSTOP := 2

SNDEMDE := 3

LDMDE := 4

ESC := 5

TXMSK := %6

MAX_CPU := 8


```

TYPE
MESSAGE    ARRAY[3 WORD]
MEM_ARRAY  ARRAY[32 WORD]
SWITCH     ARRAY[2 WORD]
CPU_ENTRY  RECORD [
    SIGNAL      WORD
    CPU_ID      WORD
    MSG_BLK     MESSAGE
    MEM_MAP     MEM_ARRAY]
ID_ARRAY   ARRAY[MAX_CPU WORD]
ENTRY_ARRAY ARRAY[MAX_CPU CPU_ENTRY]

```

```

INTERNAL
$SECTION TABLE1_DATA
$ABS 0

```

```

0000    CONFIG_TABLE  RECORD [
        RW_PATTERN    WORD
        CPU_NUM        WORD
        NORM_PW_PAT    WORD
        NORM_CPU_CNT   WORD
        TABLE_LOCK    WORD
        CPU_CNT        WORD
        CPU_LIST        ENTRY_ARRAY]

```

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

```

0000    INBUF    ARRAY [128 BYTE]
0080    OUTBUF   ARRAY [128 BYTE]
0100    RNGBUF   ARRAY [256 BYTE]
0200    MCZBUF    ARRAY [256 BYTE]

0300    BUFADR    WORD
0302    BUFSIZ    WORD
0304    INTPTR    WORD
0306    OUTPTR    WORD
0308    NXTPTR    WORD
030A    GETOUT    WORD
030C    MCZPUT    WORD
030E    MCZGET    WORD

0310    MFLAGS    WORD

0312    RETRY     WORD
0314    ADR_STR    WORD

```

INTERNAL

\$SECTION PSA_DATA

\$ABS 0

0000

PSA RECORD [

DATA_AREA

WORD

CODE_AREA

WORD

UNIMP_INST

SWITCH

PRIV_INST

SWITCH

SYSTEM_CALL

SWITCH

SEG_TRAP

SWITCH

NMI_INT

SWITCH

NVI_INT

SWITCH

VEC_FCW

WORD

VEC_PC

ARRAY [200 WORD]

]

\$SECTION BOOT2_PROC

EXTERNAL

NMI

PROCEDURE

GETLNE

PROCEDURE

SNDCHR

PROCEDURE

SVMSG

PROCEDURE

MCZHND

PROCEDURE

CONINT

PROCEDURE

GETBUF

PROCEDURE

QUIT

PROCEDURE

LOAD_FILE PROCEDURE

PHYS_ID LABEL

```

! ***** BOOTLOAD_CPU START ***** !
GLOBAL
NMI_RTN LABEL
PROP LABEL
MEM_CPU LABEL
0000 BOOTLOAD_CPU PROCEDURE
!*****!
*
* BOOTLOAD_CPU: CPU ASSUMES ROLE AS *
* INITIALIZATION COORDINATOR. *
* CPU DETERMINES NUMBER OF CPU *
* IN SYSTEM AND INITIALIZES THE *
* CONFIG_TABLE ACCORDINGLY. IT *
* THEN IDENTIFIES ITSELF AND *
* WAITS FOR MEMBER_CPU'S TO *
* IDENTIFY THEMSELVES; AND THEN *
* CONSOLIDATES CONFIG_TABLE DATA *
* INTO SYSTEM TABLE (MIN_CONFIG_ *
* TBL). *
*
* REG USE: INPUT R5 = NUMBER CPU'S *
* R6 = LOW LOCAL MEM *
* R7 = LOW GLOBAL MEM *
*
*****!
ENTRY
! LOAD CPU_CNT WITH NEXT LOG_CPU NUMBER !
0000 4075 LD CPU_CNT(R7),#1 ! LOAD LOG_CPU 1 !
0002 000A
0004 0001
0006 4DE5 LD ADR_STR(R14),#0 ! SAVE LOG_CPU NO. !
0008 0314
000A 0000

! CLEAR CONFIG_TABLE FOR CPU_NUM ENTRIES !
000C A153 LD R3,R5 ! GET CPU COUNT !
000E 8D28 CLR R2
DO
0010 0102 ADD R2,#37 ! SIZE OF CPU ENTRY !
0012 0025
0014 AB30 DEC R3
0016 E601 JR Z,NXT
0018 E9FB OD

! CLEAR CONFIG_TABLE FOR TOTAL CPU ENTRIES !
NXT:
001A 7673 LDA R3,CPU_LIST(R7) ! BASE ADR !
001C 000C
001E 0D35 LD GR3,#0
0020 0000

```

```

0022 A134      LD      R4,R3
0024 0941      INC     R4,#2
0026 FB31      LDIR    CR4,CR3,R2    ! CLEAR TABLE !
0028 0240

! COMPLETE OWN CONFIG TABLE ENTRY !
002A 7673      LDA      R3,CPU_LIST(R7)    ! LOG_CPU 0 !
002C 000C
002E 61C9      LD       R8,PHYS_ID(R12)    ! UNIQUE ID !
0030 0000*
0032 6F38      LD       CPU_ID(R3),R8    ! ENTER IN TABLE !
0034 0202
0036 763D      LDA      R13,MEM_MAP(R3)
0038 000A
003A DF1C      CALR     MAP_MEMORY    ! ENTER MEM MAP !

! UNLOCK CONFIG TABLE !
003C 7678      LDA      R8,TABLE_LOCK(R7) ! LOCK ADR !
003E 0208
0040 0D85      LD       CR8,#0           ! CLEAR LOCK !
0042 0000

! WAIT FOR ALL CPU'S TO IDENTIFY THEMSELVES !
0044 7678      LDA      R8,CPU_CNT(R7)    ! CPU_CNT ADR !
0046 000A
0048 A159      LD       R9,R5           ! GET TOTAL PHYS_CPU !
DO
004A 218D      LD       R13,CR8          ! GET VALUE !
004C 8B9D      CP       R13,R9           ! CK FOR MATCH !
004E E603      JR       Z,GOT_SIG
0050 1904      MULT    RR4,#1           ! DELAY !
0052 0001
0054 E8FA      OD

GOT_SIG:
0056 DF53      CALR     SIGNAL_CPU
0058 E82A      JR       DECISION        ! PROCEED TO SECONDARY !
                                           ! STORAGE INTERFACING !

```

```

! ***** MEMBER_CPU START ***** !
!*****
*
*      MEM_CPU: IDENTIFIES ITSELF IN
*      CONFIG_TABLE AND ENTERS MEM
*      MAP.  WAITS FOR DIRECTOR_CPU
*      TO SIGNAL TO CONTINUE.
*
*      REG USE: INPUT  R3 = BASE OF OWN
*                  ENTRY
*
*****!
MEM_CPU:
005A 7673      LDA      R3,CPU_LIST(R7)  ! BASE OF ENTRY !
005C 000C
005E 6174      LD       R4,CPU_CNT(R7)  ! LOG_CPU NUMBER !
0060 000A
0062 6F14      LD       ADP_STR(R14),R4  ! SAVE LOG_CPU NO. !
0064 0314
0066 8D28      CLR      R2
DO
0068 0102      ADD      R2,#74          ! DETERMINE BASE OF !
006A 004A
006C AB40      DEC      P4              ! ENTRY !
006E E601      JR       Z,CONT
0070 E8FB      OD

CONT:
0072 812A      ADD      R10,R2          ! COMPUTE BASE ADR !
0074 A1A3      LD       R3,R10          ! SAVE BASE ADR !

! ENTER UNIQUE ID IN TABLE ENTRY !
0076 76C2      LDA      R2,PHYS_ID(R12)
0078 0000*
007A 2129      LD       R8,R2          ! GET UNIQUE ID !
007C 6F38      LD       CPU_ID(R3),R8  ! ENTER IN TABLE !
007E 0002

! ENTER MEM_MAP IN TABLE ENTRY !
0080 763D      LDA      R13,MEM_MAP(R3) ! MEM_MAP BASE !
0082 000A
0084 DF41      CALR     MAP_MEMORY

! LOAD CPU_CNT WITH NEXT LOG_CPU NUMBER !
0086 7678      LDA      R8,CPU_CNT(R7)
0088 000A
008A 2189      LD       R9,R8          ! CPU COUNT !
008C A990      INC      P9              ! ADD ONE, !
008E 2F89      LD       GR8,R9         ! AND PUT BACK !

```

```

! UNLOCK CONF_TABLE FOR OTHER PROCESSORS !
0090 7678      LDA      R8, TABLE_LOCK(R7)
0092 0008
0094 0D85      LD       GR8, #0          ! CLEAR LOCK !
0096 0000

! WAIT FOR SIGNAL TO PROCEED WITH BOOTLOAD !
0098 7638      LDA      R8, SIGNAL(R3)  ! OWN SIGNAL ADR !
009A 0000
DO
009C 2182      LD       R2, GR8          ! TEST SIGNAL !
009E 0302      CP       R2, #1
00A0 0001
00A2 3603      JR       Z, RESET_SIG
00A4 1904      MULT    RR4, #1          ! DELAY !
00A6 0001
00A8 F8F9      OD

RESET_SIG:
00AA 4D38      CLR      SIGNAL(R3)
00AC 0000

```

```

! *****
*
*          BOOTSTRAP LOADING FUCTION
*
*  THIS SECTION CONTAINS NECESSARY
*  SECONDARY STORAGE INTERFACING
*  PRIMITIVES TO EFFECT A DOWNLOAD.
*
* *****!

```

```

! *****
*          BOOTLOAD-MONITOR DECISION POINT
*
* *****!

```

```

DECISION:
00AE 082A      LDB      RL0, #'*'      ! PROMPT MIN MEC !
                                           ! INITIALIZATION !
00B0 76CA      LDA      F10, SNDCHR(R12)
00B2 0000*
00B4 1FA0      CALL     GR10          ! OUTPUT PROMPT !

! SET RINGBUFFER OFFSET POINTERS !
00B6 4DF8      CLR      GETOUT(R14)
00B8 030A
00BA 4DE8      CLR      NXTPTR(R14)
00BC 0308

```

```

00BE 7C05      EI      VI
                ! GLOBAL TABLE FOR CPU SYNCHRONIZATION; LOG_CPU !
                ! NUMBER DETERMINES BOOT_COORDINATOR IN GENERAL !
                ! CASE, BUT NOT USED WITH MCZ IMPLEMENTATION. !

                ! MAIN LOOP FOR BOOT_COORD DETERMINATION !
                DO
                ! CHECK FOR CONSOLE INPUT !
00C0 61F7      LD      R0,GETOUT(R14)
00C2 030A
00C4 4FE0      CP      R0,NXTPTR(R14)
00C6 2308
00C8 EE06      JR      NZ,RESPONSE ! HAVE REC CHR !

                ! CHECK FOR BOOTLOAD SIGNAL !
LOP_MOR:
00CA 6131      LD      R1,SIGNAL(R3)
00CC 0300
00CE 0B01      CP      R1,%0001 ! CK FOR SIGNAL !
00D0 0001
00D2 E62C      JR      Z,BGN_BOOT ! REC BOOTLOAD SIG !
00D4 E8F5      CD

RESPONSE:
                ! DETERMINE INPUT CHAR RESPONSE !
00D6 76CA      LDA      R10,GETBUF(R12)
00D8 0000*
00DA 1FA0      CALL     GR10
00DC 2028      LDB      RL0,GR2
00DE 76CA      LDA      R10,SENDCHP(R12)
00E0 0000*
00E2 1FA0      CALL     GR10 ! ECHO TO CONSOLE !
00E4 A10D      LD      R13,R0 ! SAVE CHAR !
00E6 C80D      LDB      RL0,#CR
00E8 1FA0      CALL     GR10 ! SEND CR TO CONS !
00EA C80A      LDB      RL0,#LF
00EC 1FA0      CALL     GR10 ! SEND LINE FEED !

                ! INSURE MCZ SYSTEM IS INITIALIZED !
00EE 3402      LDAR     R2,MCZ_MSG ! INIT MESSAGE !
00F0 00F0
00F2 76CA      LDA      R10,SENDMSG(R12)
00F4 0000*
00F6 1FA0      CALL     GR10 ! SEND TO CONSOLE !

00F8 4DF8      CLR      GETOUT(R14)
00FA 030A
00FC 4DE8      CLR      NXTPTR(R14)
00FE 0308
0100 76CA      LDA      R10,QUIT(R12)

```

```

0102 0000*
0104 1348      JP      0R10      ! ENTER TRANSPARENT MODE !

      ! RETURN POINT FORM TRANSPARENT MODE !
NMI_RTN:
      ! DETERMINE COMMAND BRANCH !
0106 3402      LDAR      R2,LOAD_MSG
0108 0286
010A 76CA      LDA      R10,SNDRMSG(R12)
010C 0000*
010F 1FA0      CALL     0R10

0110 A1D2      LD      R2,R13
0112 0A0A      CPB      R12,#%53      ! CK FOR SASS BOOTSTRAP !
0114 5353
0116 EE03      JR      NZ,OTHER
0118 340D      LDAR      R13,BOOT_COORD
011A 021E
011C E802      JR      SET_PTRS

      OTHER:
011E 340D      LDAR      R13,MONITOR ! START OF DMONITOR !
0120 007C

      SET_PTRS:
0122 61E1      LD      R1,NXTPTR(R14) ! RESET RNIGBUF !
0124 0308
0126 6FE1      LD      GETOUT(R14),R1 ! OFFSET POINTERS !
0128 037A

012A 1ED8      JP      0R13      ! BRANCH !

      ! NON-BOOTLOAD_CPU RESPONSE TO SIGNAL !
BGN_BOOT:
      ! PASS LOG_CPU OF CPU INTO BOOTSTRAP !
012C 61FC      LD      R12,ADR_STR(R14)
012E 0314
0130 4D38      CLR      SIGNAL(R3)
0132 0000

0134 6131      LD      R1,MSG_BLK(R3)
0136 0004
0138 1E18      JP      0R1      ! TRANSFER TO BOOTSTRAP !

```

 * ASSUME BOOTLOAD COORDINATOR ROLE *

BOOT_COORD:

```

013A 6FE3      LD      RETRY(R14),R3    ! SAVE ENTRY BASE !
013C 0312
013E 3404      LDAR     R4,BOOTLOAD    ! LOAD FILENAME !
0140 0090
0142 A173      LD      R3,R7          ! GLOBAL MEMORY !
0144 0103      ADD      R3,#0200      ! BOOTLOAD ADR !
0146 0200

! LOAD BOOTLOAD PROGRAM !
0148 76CA      LDA      R10,LOAD_FILE(R12)
014A 0000*
014C 1FA0      CALL     0F10

014E A174      LD      R4,R7          ! GLOBAL MEMORY !
0150 414B      LD      R11,R4         ! SAVE BASE ADR !
0152 010B      ADD      R11,#0200     ! BOOTLOAD ADR !
0154 0200
0156 210C      LD      R12,#0
0158 0000
015A A151      LD      R1,R5          ! NUMBER OF CPU'S !

! STORE BOOTLOAD ADDRESS IN MSG_BLK OF ALL CPU'S !
DO
015C 6F43      LD      MSG_BLK(R4),R3 ! PLACE ADDRESS !
015E 0004
0160 AB10      DEC      R1
0162 E603      JR      Z,SIG_NXT
0164 0104      ADD      R4,#74        ! NEXT LOG_CPU NUMBER !
0166 004A
0168 E8F9      OD

SIG_NXT:
! SIGNAL ALL CPU'S TO TRANSFER CONTROL !
016A 61EC      LD      R12,ADR_STR(R14) ! GET OWN LOG_CPU NO. !
016C 0314
016E DFD0      CALR     SIGNAL_CPU
0170 617A      LD      R10,CPU_LIST(R7)
0172 000C
0174 4DA5      LD      SIGNAL(R10),#1 ! BOOTLOAD CPU SIGNAL !
0176 0000
0178 0001
017A 61E3      LD      R3,RETRY(R14)   ! OWN ENTRY BASE !
017C 0312
017E 4D38      CLR      SIGNAL(R3)
0180 0000
0182 1FB9      JP      0R11           ! TRANSFER SELF !

```

```

      EFOR:
0184 3402      LDAR      R2,ERR_MSG
0186 0074
0188 76CA      LDA       R10,SNDRMSG(R12)
018A 0000*
018C 1FA0      CALL      GR10
018F F88F      JR        DECISION

```

!***** END BOOTLOAD *****!

```

      LOAD MSG:
0190 0D      BVAL      %0D
0191 4C      BVAL      'L'
0192 4F41     WVAL      'OA'
0194 4449     WVAL      'DI'
0196 4F47     WVAL      'NG'
0198 2E2E     WVAL      '...'
019A 2E2E     WVAL      '...'
019C 2E      BVAL      ' '
019D 0D      BVAL      %0D

```

```

      MONITOR:
019F 3404      LDAR      R4,DMONITOR   ! LOAD FILE NAME !
01A0 004C
01A2 2103      LD        R3,_%0000
01A4 0000
01A6 76CA      LDA       R10,LOAD_FILE(R12)
01A8 0000*
01AA 1FA0      CALL      GR10
01AC 2103      LD        R3,_%0000
01AE 0000
01B0 F84C      JR        DISABLE_PROM ! TRANSFER CONTROL !

01B2      END  BOOTLOAD_CPU

```

```

01P2      SIGNAL_CPU PROCEDURE
          !*****
          *
          *   SIGNAL_CPU: PLACES SIGNAL (#1) IN
          *   SIGNAL BLOCK FOR EACH CPU EN-
          *   TRY IN CONFIG_TABLE.
          *
          !*****
          ENTRY
          ! SIGNAL ALL CPU TO DOWN-LOAD !
          LDA      R13,CPU_LIST(R7)

01B2 767D          ADD      R13,#74          ! LOG_CPU 1 ENTRY !
01B4 000C
01B6 010D
01B8 004A          LD       R4,R5          ! TOTAL NO. CPU !
01BA A154          DFC      R4
01BC AB40          JR       Z,ALL_SIG
01BE E608

          DO
01C0 4DD5          LD       SIGNAL(R13),#1 ! LOAD SIGNAL !
01C2 0000
01C4 0001
01C6 AB40          DEC      R4
01C8 E603          JR       Z,ALL_SIG
01CA 010D          ADD      R13,#74          ! NEXT LOG_CPU ADR !
01CC 004A
01CE E8F8          OD

          ALL_SIG:
01D0 9E08          RET

01D2      END SIGNAL_CPU

          BOOTLOAD:
01D2 0F          BVAL      %0F
01D3 4C          BVAL      'L'
01D4 4F41        WVAL      'OA'
01D6 4420        WVAL      'D'
01D8 424F        WVAL      'EC'
01DA 4F54        WVAL      'OT'
01DC 5354        WVAL      'ST'
01DE 5241        WVAL      'RA'
01E0 5020        WVAL      'P'

          MCZ_MSG:
01E2 0A          BVAL      %0A
01E3 52          BVAL      'R'
01E4 4553        WVAL      'ES'
01E6 4554        WVAL      'ET'
01E8 204D        WVAL      'M'

```

```

01EA 435A    WVAL    'CZ'
01EC 0F      BVAL    %0D
01ED 20      BVAL

```

DMONITOR:

```

01EF 0F      BVAL    %0D
01FF 4C      BVAL    'L'
01F0 4F41    WVAL    'OA'
01F2 4420    WVAL    'D'
01F4 4D4F    WVAL    'MO'
01F6 4E49    WVAL    'NI'
01F8 544F    WVAL    'TO'
01FA 5220    WVAL    'P'

```

ERR MSG:

```

01FC 06      BVAL    %06
01FD 45      BVAL    'E'
01FE 5252    WVAL    'RR'
0200 4F52    WVAL    'OR'
0202 0D      BVAL    %0D
0203 20      BVAL

```

0204

MAP MEMORY PROCEDURE

```

!*****
*
*   MAP_MEMORY: MAPS CPU MEMORY ACCESS
*   BY DOMAIN, AS TO LOCAL (1),
*   GLOBAL (2), DUAL_USE (3),
*   NON_USE (4), NON_ACCESS (5).
*
*   REG USE: INPUT  R13 = ADR MEM_MAP
*
*****!

```

ENTRY

```

0204 A1D1    LD      R1,R13      ! SAVE BASE ADR !
0206 2102    LD      R2,%55AA    ! R/W PATTERN !
0208 55AA
020A 8D43    CLR     R4
020C 2109    LD      R9,%F800    ! END ADR !
020E F800
0210 2110    LD      R0,R1      ! 1ST MAP BLK !
0212 DFFF    CALR    SYS_MAP    ! MAP SYSTEM MODE !
0214 9E08    RET
0216
END MAP_MEMORY

```

0216

SYS_MAP PROCEDURE

```

*****
*
*   SYS_MAP: MAPS MEMORY ACCESS IN THE
*   SYSTEM MODE INTO CONFIG_TABLE
*   FOR CPU.
*
*   REG USE: INPUT  R1 = BASE MAP BLK
*                   R2 = R/W PATTERN
*                   R4 = START MEM
*                   R9 = END ADR
*
*****

```

ENTRY
DO

```

0216 6148      LD      R8,RW_PATTERN(R4)      ! CK FOR R/W !
0218 0000
021A 8B29      CP      R8,R2
021C EE0D      JR      NZ,BAD_MEM ! NO R/W/ !
021E 6148      LD      R8,CPU_NUM(R4)        ! GET CPU_CNT !
0220 0002
0222 0F09      CP      R8,#%0001 ! CK FOR LOCAL !
0224 0001
0226 FE02      JR      NZ,GLOBE_CK
0228 C001      LDB     RH0,#%01 ! RECORD LOCAL !
022A E807      JR      CONTINUE

```

GLOBE_CK:

```

022C 9B58      CP      R8,R5 ! CK FOR GLOBAL !
022E FE02      JR      NZ,NO_USE ! 1<CPU_NUM<R5 !
0230 C002      LDB     RH0,#%02 ! RECORD GLOBAL !
0232 E803      JR      CONTINUE

```

NO_USE:

```

0234 C004      LDB     RH0,#%04 ! RECORD NON_USE !
0236 E801      JR      CONTINUE

```

BAD_MEM:

```

0238 C005      LDB     RH0,#%05 ! RECORD NON_ACCESS !

```

CONTINUE:

```

023A 2F10      LD      GR1,R0 ! STORE MAP BLOCK !
023C A911      INC     R1,#2 ! NEXT MAP BLK !
023F 8B49      CP      R9,R4
0240 9E06      RET     Z ! FINISHED !
0242 9D08      CLR     R0
0244 0104      ADD     R4,#%0800 ! NEXT MEM ADR !
0246 0800

```

0248 F8F6 OD

024A END SYS_MAP

024A DISABLE_PROM PROCEDURE

```
*****
*
*   DISABLE_PROM: REPOSITIONS CODE FOR
*               PROM DISABLING AND TRANSFER
*               OF CONTROL FLOW.
*
*   REG USE: INPUT   R3 = TRANS ADR
*
*****!
```

ENTRY

```
024A A161       LD           R1,R6       ! MOVE LOCATION !
024C 3404       LDAR         R4,BGN_CODE
024E 0014
0250 2102       LD           R2,#3
0252 0003
```

! ACTUAL CODE TRANSFER !

DO

```
0254 214D       LD           R13,GR4     ! GET INSTRUCTION !
0256 2F1D       LD           GR1,R13     ! PUT AT NEW LOC !
0258 AB20       DEC          R2
025A F603       JR           Z,DO_CODE
025C A911       INC          R1,#2
025E A941       INC          R4,#2
0260 F8F9       OD
```

DO_CODE:

```
0262 1E68       JP           GR6         ! TRANSFER CONTROL !
```

BGN_CODE:

```
0264 3F16       OUT          ROM_DISABLE,R1
0266 FFF0
0268 1E38       JP           GR3
```

026A END DISABLE_PROM

END BOOTLOAD2

3. SUPPORT1 MODULE

IBM000ASM 2.02
 LOC OBJ CODE STMT SOURCE STATEMENT

1 SUPPORT1 MODULE
 \$LISTON \$TTY

```
!*****
*
* SUPPORT1 MODULE: MODULE ONE FOR
* SECONDARY STORAGE PRIMITIVE
* FUNCTIONS SUPPORT. STRICTLY
* HARDWARE DEPENDENT; SHOULD
* MEET STORAGE DEVICE REQUIRE-
* MENTS FOR INTERFACING.
*
*****!
```

CONSTANT

```
RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPCRT   := %FFCB
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR    := %(2)0001000000000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %09
LINDEL   := %7F
CR       := %0D
LF       := %0A
TXOFCH   := %13
TXONCH   := %11
INSIZ    := 128
OUTSIZ   := 128
RESIZ    := 256

! INTBUF SIZE !
! OUTBUF SIZE !
! RING BUFFER SIZE !
```

! BIT POSITIONS IN MONITOR FLAG WORD !

TRPMDE := 0
 ISTCP := 1
 OSTOP := 2
 SNDMDE := 3
 LDMDE := 4
 ESC := 5
 TXMSK := %6

COMDS := 12

EXTERNAL	GETNXT	PROCEDURE
EXTERNAL	GETADR	PROCEDURE
EXTERNAL	GMCZAD	PROCEDURE
EXTERNAL	SNDMCZ	PROCEDURE
EXTERNAL	GETBUF	PROCEDURE
EXTERNAL	SNDCHR	PROCEDURE
EXTERNAL	EROR	LABEL
EXTERNAL	SKPBLK	PROCEDURE
EXTERNAL	CONVERT	PROCEDURE
EXTERNAL	GETCHR	PROCEDURE

INTERNAL
 \$SECTION DATA_DEC
 \$ABS 0

0000	INTBUF	ARRAY [128 BYTE]
0080	OUTBUF	ARRAY [128 BYTE]
0100	RNGBUF	ARRAY [256 BYTE]
0200	MCZBUF	ARRAY [256 BYTE]
0300	BUFAIR	WORD
0302	BUFSIZ	WORD
0304	INTPTR	WORD
0306	OUTPTR	WORD
0308	UNIMP	WORD
030A	BRKCNT	WORD
030C	NXTPTR	WORD
030E	GETOUT	WORD
0310	MCZPUT	WORD
0312	MCZGET	WORD
0314	BFKSTR	WORD
0316	BRKADR	WORD
0318	TMPSP	WORD
031A	TMPFCW	WORD
031C	MFLAGS	WORD

! USER REGISTER STORAGE !

031F	R0	WORD
0320	R1	WORD
0322	R2	WORD
0324	R3	WORD
0326	R4	WORD
0328	R5	WORD
032A	R6	WORD
032C	R7	WORD
032E	R8	WORD
0330	R9	WORD
0332	R10	WORD
0334	R11	WORD
0336	R12	WORD
0338	R13	WORD
033A	R14	WORD
033C	R15	WORD
033E	RPC	WORD
0340	RFC	WORD
0342	RETFY	WORD

GLOBAL
\$SECTION SUPPORT1_PROC
\$REL 0

GLOBAL
0000 GETLINE PROCEDURE
!*****!
*
* GETLINE: REC ONE LINE INPUT FROM *
* CONS (PORT2), UP TO 80-CHR *
* MAX, STORE IN INTBUF PLUS *
* CR, AND ECHO BACK TO CONS. *
*
* REG USE: PETERN RL0= 1ST CHR IN BUF*
* AND Z IF CHR = CR *
*
*****!

ENTRY
0000 76F2 LDA R2,INTBUF(R14) ! GET BASE INTBUF !
0002 0000
0004 2101 LD R1,#INSIZ ! GET MAX SIZE !
0006 0080
0008 6FF2 LD INTPTR(R14),R2
000A 0304
000C DFF8 CALR CONSOL ! FILL LINE IN INTBUF!
000E 34CA LDA P10,R12(#SKPBLK)

```

0010 011C'
0012 1FA0      CALL      QR10
0014 6BE0      DEC       INTPTR(R14)      ! RETURN TO START !
0016 0304
0018 0AC8      CPB       RL2,#CR
001A 0D0D
001C 9E0E      RET       ! GOT 1ST CHR = CR !
001E          END GETLNE

GLOBAL
001E          CONSOL PROCEDURE
!*****
*
*   CONSOL: STORE CONS INPUT LINE IN
*           BUFFER ADDRESS PROVIDED,
*           PLACE CR AT END OF LINE,
*           AND PROVIDE DELETE CHAR
*           AND DELETE LINE EDIT FUNC.
*
*   REG USE: INPUT  R1 = SIZE OF BUFFER
*                  R2 = BUFFER ADR
*                  RETURN R1 = # OF DEC CHR
*                  AND Z IF BUF LIMIT
*
*****!

ENTRY
001E 6FE2      LD         BUFADR(R14),R2      ! SAVE BOTH BUF ADR !
0020 0300
0022 6FE1      LD         BUFSIZ(R14),R1      ! AND BUF SIZE !
0024 0302

HDNC:
0026 6132      LD         R2,BUFADR(R14)
0028 0300
002A 8D18      CLR        R1

REDLOP:
002C DFC1      CALR       CONRD      ! GET CHAR AND ECHO !
002E 0A08      CPB       RL0,#%61    ! CONVERT TO UPPER CASE!
0030 6161
0032 E704      JR         C,UPCASE    ! NOT LOWER CASE !
0034 0A08      CPB       RL0,#%7B
0036 7B7B
0038 EF01      JR         NC,UPCASE   ! YES LOWER CASE !
003A A285      RESB      RL0,#5      ! CONVERT TO UPCASE !

UPCASE:
003C 2E28      LDB        QR2,RL0

! PERFORM EDIT FUNCTIONS ON INPUT !
003E 0A08      CPB       RL0,#BS     !CK FOR DEL CHR !
0040 0809
0042 EE11      JR         NZ,CONTCK   ! NO, CONTINUE CK !

```

0044	0320	DEC	R2,#1	! YES. BACKSPACE !
0046	AB10	DFC	R1	
0048	4BF2	CP	R2,BUFADR(R14)	! NOT TOO FAR !
004A	0300			
004C	F707	JR	C,DO_OVR	
004E	C820	LDB	RL0,#'	
0050	34CA	LDA	R10,R12(#SNDCHR)	
0052	01DE			
0054	1FA0	CALL	QR10	! BLANK OUT BAD CHR !
0056	C808	LDE	PL0,#BS	
0058	1FA0	CALL	QR10	
005A	F8E8	JR	REDLOP	! CONTINUE.....!

DO_OVR:

005C	C82A	LDB	RL0,#''	
005E	34CA	LDA	R10,R12(SNDCHR)	
0060	01DE			
0062	1FA0	CALL	QR10	! SEND PROMPT !
0064	F8F2	JR	HDNG	! START AGAIN !

CONTRK:

0066	0A08	CPB	RL0,#LINDEL	! CK FOR LINE DEL !
0068	7F7F			
006A	E609	JR	Z,DELIN	! YES.....!
006C	A920	INC	R2,#1	
006E	A910	INC	R1	
0070	0A08	CPB	RL0,#CR	! CK FOR CR !
0072	0D0D			
0074	E60E	JR	Z,ADDLF	! YES, ADD LF CHR !
0076	4BE1	CP	R1,BUFSIZ(R14)	! SIZE CK !
0078	0302			
007A	EED8	JR	NZ,REDLOP	! OK, GET NEXT CHR !
007C	9E06	RET	Z	! TOO LARGE, ERROR !

DELIN:

007E	C85E	LDB	PL0,#%5E	
0080	34CA	LDA	R10,R12(SNDCHR)	! SND LINE DEL !
0082	01DE			
0084	1FA0	CALL	QR10	
0086	DFF5	CALF	NEWLINE	! START NEW LINE !
0088	C820	LDB	RL0,#'	
008A	34CA	LDA	R10,R12(SNDCHR)	
008C	01DE			
008E	1FA0	CALL	QR10	! SND CHR !
0090	F8CA	JR	HDNG	! START AGAIN !

ADDLF:

0092	C80A	LDB	RL0,#LF	
0094	34CA	LDA	R10,R12(#SNDCHR)	
0096	01DE			

```

0098 1FA0      CALL      GR10      ! SEND LF CHR !
009A ED43      RESFLG    Z
009C 9E08      RET
009E          END CONSOL

```

```

009E          GLOBAL
          NEWLNE  PROCEDURE
          !*****
          *
          *   NEWLNE: SENDS CR AND LF TO CONSOLE   *
          *
          !*****

```

```

          ENTRY
009F 34CA      LDA        R10,R12(SNDCHR)
00A0 01DE
00A2 C80D      LDB        R10,#CR
00A4 1FA0      CALL      GR10
00A6 C80A      LDB        R10,#LF
00A8 1FA0      CALL      GR10      ! ADR SNDCHR IN R10 !
00AA 9E08      RET
00AC          END NEWLNE

```

```

00AC          GLOBAL
          CONRD   PROCEDURE
          !*****
          *
          *   CONRD: GETS CHAR FROM CONSOLE INPUT *
          *           BUFFER (INTBUF) AND ECHOS   *
          *           BACK TO CONSOLE. LOOPS UNTIL *
          *           RECEIVE CHARACTER.          *
          *
          *   REG USE: RETURN  R10= CHR          *
          *                   AND Z IF CHR=CR      *
          *
          !*****

```

```

          ENTRY
00AC 61E0      TC:LD      R0,GETOUT(R14)
00AE 030E
00B0 4BE0      CP        R0,NXTPTR(R14)      ! COMPARE GET AND !
00B2 030C
          ! PUT PTRS !
          ! REC NOTHING.... !
00B4 E6FB      JR        Z,TC
00B6 93F2      PUSH      GR15,R2
00B8 34CA      LDA        R10,R12(#GETBUF)
00BA 0000*
00BC 1FA0      CALL      GR10      ! GET ENGBUF ADR !
00BE 6FE0      LD        GETOUT(R14),R0
00CC 03FE
00C2 2028      LDB        R10,GR2      ! STO CHR FOR RTN !
00C4 97F2      POP       R2,GR15

```

```

! CHECK FOR NON-DISPLAY FROM LOAD_FILE !
00C6 0B09      CP      R9,#%AAAA
00C8 AAAA
00CA E603      JR      Z,NO_DISPLAY
00CC 34CA      LDA      R10,R12(SNDCHR)
00CE 01DE
00D0 1FA0      CALL     GR10

NO_DISPLAY:
00D2 9E08      RET
00D4          END CONRD

GLOBAL
00D4          QUIT PROCEDURE
!*****
*
*   QUIT: TRANSMITS ALL CHR AND CR FROM *
*   CONS TO MCZ; THEN RELAYS ALL *
*   TO CONS FROM MCZ; AND ETC. *
*
*****!

ENTRY
00D4 4DE8      CLR      MCZPUT(R14)
00D6 0310
00D8 4DE8      CLR      MCZGET(R14)
00DA 0312
00DC 65E0      SET      MFLAGS(R14),#TRPMDE ! RESET BUF PTRS !
00DE 031C

! AND ENTER TRANSPARENT MODE !

! CONSOLE RECEIVE ROUTINE !
PORTB:
00E0 61E0      LD      R0,GETOUT(R14)
00E2 030E
00E4 4BE0      CP      R0,NXTPTR(R14) ! CK FOR CONS INPUT !
00E6 030C
00E8 E60A      JR      Z,PORTA ! NO, CK MCZ..... !

! PROCESS CONSOLE INPUT !
00EA 34CA      LDA      R10,R12(#GETBUF)
00EC 0000*
00EE 1FA0      CALL     GR10 ! GET RNGBUF ADR !
00F0 6FE0      LD      GETOUT(R14),R0 ! SET BEGIN PTR !
00F2 030E
00F4 2028      LDE      R10,GR2
00F6 34CA      LDA      R10,R12(#SNDMCZ)
00F8 0000*
00FA 1FA0      CALL     GR10 ! ECHO CHR TO MCZ !
00FC EEF1      JR      NZ,PORTB ! CONTINUE UNTIL CR !

```

```

! MCZ RECEIVE ROUTINE !
PORTA:
00FE 61E0      LD      R0,MCZGET(R14)
0100 7312
0102 4BE0      CP      R0,MCZPUT(R14)      ! CK FOR MCZ INPUT !
0104 0310
0106 E6EC      JR      Z,PORTB      ! NO, CK CONSOLE...!
0108 34CA      LDA     R10,R12(#GMCZAD)
010A 0000*
010C 1FA0      CALL    GR10      ! GET MCZBUF ADR !
010E 6FE0      LD      MCZGET(R14),R0
0110 0312
0112 2028      LDB     R10,R2      ! GET CHAR FROM MCZBUF !
0114 34CA      LDA     R10,R12(SNDCHF)
0116 01DE
0118 1FA0      CALL    GR10      ! OUTPUT CHR TO CONSOLE !
011A E8F1      JN      PORTA      ! CONTINUE TIL EMPTY !
011C          END QUIT

```

```

GLOBAL
011C SKPELK PROCEDURE
!*****
*
* SKPELK: SKIP OVER BLANKS TO NEXT
* CHARACTER.
*
* REG USE: RETURN R10 = 1ST NON-BLK
* CHAR AND Z IF =CR
*
*****!
ENTRY
! SKIP OVER BLANKS TO NEXT ARGUMENT !
011C DFE0      CALR    GETCHR
011E 9E06      RET     Z      ! GOT CR !
0120 2A09      CPB     R10,#' '      ! CK FOR BLANK !
0122 2020
0124 E6FE      JR      Z,SKPELK      ! YES,..... !
0126 9E08      RET     Z      ! GOT CHAR !

0128          END SKPELK

```

```

GLOBAL
0128 GETADR PROCEDURE
!*****
*
* GETADR: GETS NEXT ARGUMENT AND
* CONVERTS TO HEX ADDRESS.
*
* REG USE: INPUT R0 = 1ST CH OF ARG
* RETURN R3 = HEX ADR
* AND Z,C IF C? ONLY
* Z,NC IF ARG,CR
* NZ,NC IF ARG,SP
*
*****!
ENTRY
! CK FOR CR ONLY !
0128 8D38 CLR R3
012A 0A08 CPB R0,#CR ! CK FOR CR !
012C 0D0D
012E EE02 JP NZ,NOTCR
0130 8D01 SETFLG C
0132 9E08 RET ! RETURN FOR CR ONLY !

!CONVERT ASCII ADDRESS TO HEX ADDRESS !
NOTCR:
0134 DFE2 CALR CONVERT !BYTE TO 4-BIT HEX !
0136 570A JR C,REPERR ! GOT BAD CHR !
0138 BEB8 RLDB R0,R13
013A BE38 RLDE R0,RH3 !SHFT LEFT TO MSW !
013C DFF0 CALR GETCHR ! GET CHR FROM INTBUF!
013E 9E06 RET Z
0140 0A08 CPB R0,#' ' !CK FOR SPACE !
0142 2020
0144 EE07 JR NZ,NOTCR ! IF NOT, CONT.....!
0146 D016 CALR SKPBLK ! SKIP TO NEXT ARG !
0148 8D83 RESFLG C
014A 9F09 RET ! SPACE AFTER ARG !

REPERR:
014C 34CA LDA R10,R12(#EROR)
014E 0000*
0150 1EAB JP @R10
0152 END GETADR

```

```

0152      GLOBAL
          GETNXT PROCEDURE
          !*****
          *
          *   GETNXT: SKIP TO BEGINING OF NEXT
          *   ARGUMENT IN COMMAND.
          *
          *   REG USE:  RETURN  RL0 = CHAR OR CR
          *                   AND Z IF = CR
          *
          !*****
          ENTRY
          ! SKIP OVER CURRENT ARGUMENT TO NEXT SPACE !
0152 DFFB      CALR      GETCHR
0154 9E06      RET       Z           ! RTN IF CH=CR !
0156 0A08      CPB       RL0,#'      ! FIND FIRST SPACE !
0158 2020
015A FEFB      JR        NZ,GETNXT
015C E8DF      JR        SKPPLK      ! NOW SKIP BLANKS !

015F      END GETNXT

015E      GLOBAL
          GETCHR PROCEDURE
          !*****
          *
          *   GETCHR: GETS NEXT CHR FROM INTEUF
          *   AND INCREMENTS INTPTR.
          *
          *   REG USE:  RETURN  RL0 = CHR
          *                   AND Z IF CR
          *
          !*****
          ENTRY
015E 93F2      PUSH      @R15,R2      ! SAVE WORK REG !
0160 61E2      LD        R2,INTPTR(R14)
0162 0304
0164 2028      LDB       RL0,@R2      ! GET CHR !
0166 69E0      INC       INTPTR(R14),#1 ! INC PTR !
0168 0304
016A 0A08      CPB       RL0,#CR      !CK FOR CR !
016C 0D0D
016E 97F2      PCP       R2,@R15
0170 9E08      RET
0172      END GETCHR

```


0172

GLOBAL

CONVERT PROCEDURE

!*****

```
*
* CONVERT: CONVERTS 3-BIT ASCII CHR
* TO 4-BIT HEX VALUE. VALID
* CHR IS 0-9 OR A-F; IF NOT
* CHR, EXIT TO EXEC ERROR.
*
* REG USE: INPUT RLO = 3-BIT ASCII
* RETURN RLO = 4-BIT HEX IN
* LSW.
*
```

*****!

ENTRY

! CHECK FOR VALID CHAR !

```
0172 0A08 CPE RLO,#'0' ! FILTER <'0' ASCII !
0174 3030
0176 9E07 RET C ! ERROR !
0178 0A08 CPB RLO,#'9'+1 ! CK IF DIGIT '
017A 3A3A
017C E709 JR C,NOFIX
017E 0A08 CPB RLO,#'A' ! FILTER <'A' ASCII !
0180 4141
0182 9E07 RET C
0184 0A08 CPB RLO,#'F'+1 !FILTER >'F' ASCII !
0186 4747
0188 EF06 JR NC,RETSIG !ERROR!
018A 020E SUBB RLO,#7 ! ALPHA ADJUST !
018C 0707
```

NOFIX:

```
018E 0608 ANDB RLO,#%0F ! GET LOW NIBBLE !
0190 0F0F
0192 8D83 RESFLG C
0194 9E08 RET ! RTN HEX VALUE !
```

RETSIG:

```
0196 8D81 SETFLG C
0198 9E08 RET ! RTN FOR BAD CHR !
```

```
019A END CONVERT
```

```

GLOBAL
    PBUFNC LABEL
    PRNTBF PROCEDURE
C19A
!*****
*
*   PRNTBF: PRINT CONTENTS OF OUTBUF
*           TO CONS WITH CR AT END.
*
*   PBUFNC: PRINT BUFFER CONTENTS WITH
*           NO CR.
*
*****!
ENTRY
! STORE CR IN OUTBUF !
C19A 61E2    LD      R2,OUTPTR(R14)
C19C 0306
C19E 0C25    LDB     QR2,#CR
C1A0 0D0D
C1A2 69E0    INC     OUTPTR(R14),#1
C1A4 0306

PBUFNC:
C1A6 76E1    LDA     R1,OUTBUF(R14)    ! LOAD ADDR OF OUTBUF !
C1A8 0080

! OUTPUT LOOP !
PRNT:
C1AA 2018    LDB     RL0,QR1          ! GET CHR !
C1AC A910    INC     R1              ! INC INDEX !
C1AE DFE9    CALF    SNDCHR          ! OUTPUT CHR !
C1B0 E604    JR      Z,OUTLF        ! ?CHR = CR !
C1B2 4BE1    CP      R1,OUTPTR(R14)  ! CK FOR END !
C1B4 0306
C1B6 E7F9    JR      C,PRNT          ! LOOP.....!
C1B8 E802    JR      FINI           ! FINISHED !

! ADD LF AFTER OUTPUT OF CR !
OUTLF:
C1BA C80A    LDB     RL0,#LF          ! OUTPUT LF !
C1BC DFF0    CALF    SNDCHR

! FILL OUTBUF WITH BLANKS AND RESET OUTPTR !
FINI:
C1BE 76E3    LDA     R3,OUTBUF(R14)
C1C0 0080
C1C2 6FE3    LD      OUTPTR(R14),R3 ! RESET PTR !
C1C4 0306
C1C6 2100    LD      R0,#OUTSIZ/2-1 ! FILL CNT !
C1C8 003F
C1CA 4DE5    LD      OUTBUF(R14),#
C1CC 0080

```

```

01CE 2020
01D0 76E2      LDA      R2,OUTBUF(R14)
01D2 7C80
01D4 A123      LD       R3,R2
01D6 A931      INC      R3,#2
01D8 9B21      LDI      R3,R2,R2      ! FILL OUTBUF !
01DA 0030
01DC 9E08      RET
01DF          END PRNTBF

```

```

GLOBAL
SNDCHR PROCEDURE
01DE          !*****
*
*   SNDCHR: CK MONITOR FLAG WORD FOR
*   OUTPUT STOP SIGNAL (OSTOP);
*   IF NOT, SEND CHAR TO CONS.
*
*   REG USE: INPUT   RL0= CHR
*   RETURN  RL0= CHR AND Z IF
*             CHR = CR.
*
*****!
ENTRY
! WAIT FOR OUTPUT CK SIGNAL !
01DE 67E2      BIT      MFLAGS(R14),#OSTOP      ! CK FLAG !
01E0 031C
01E2 FEFD      JR       NZ,SNDCHR
!OUTPUT CHAR TO TERMINAL !
01E4 3A04      INB      R0,PORTBC      ! GET PORT STATUS !
01E6 FFE3
01E8 A600      BITB     R0,#TXR      ! TRANS PDY? !
01EA E6F9      JR       Z,SNDCHR      ! NO, CONTINUE...!
01EC 3A86      OUTB     PORTBD,RL0    ! YES, OUTPUT CHR !
01EE FFE1
01F0 0A08      CPB      RL0,#CR
01F2 0D0D
01F4 9E08      RET
01F6          END SNDCHR

```

```

GLOBAL
CONVB LABEL
CONVW PPOCEDURE
21F6
!*****
*
* CCNVW: CONVERT INTERNAL WORD, 4-
* 4-BIT HEX VALUES TO FOUR
* 8-BIT ASCII REPRESENTATIONS
* OF THE HEX VALUES.
*
* CONVB: CONVERT INTERNAL BYTE HEX
* VALUE TO ASCII CHARACTERS.
*
* REG USE: INPUT R5 = WORD/BYTE(S)
* R3 = CKSUM ACCUM
* RETURN R3 = UPDATED ACCUM
* AND ASCII CHR
* IN OUTBUF
*
*****!
ENTRY
! CONVERT WORD !
21F6 A050 LDB RH0,RH5 ! 1ST BYTE !
21F8 DFFF CALR NIBBLE
! CONVERT BYTE ENTRY POINT !
CONVB:
21FA A0D0 LDB RH2,RL5

NIBBLE:
21FC BE08 RLDB RL0,RH0 ! FIRST NIBBLE !
21FE DFFF CALR CONPUT
2200 BE08 RLDB RL0,RH0 ! NEXT NIBBLE !
! CONVERT NIBBLE TO ASCII CHAR AND STORE !
CONPUT:
2202 0608 ANDB RL0,#%0F ! GET NIBBLE !
2204 0F0F
2206 808B ADDB RL3,RL0 ! UPDATE CKSUM !
2208 0A08 CPB RL0,#%0A ! 0-9? !
220A 2A0A
220C E702 JF C, ASCII ! YES... !
220E 0008 ADDB RL0,#7 ! NO, CONVERT CHR !
2210 0707

ASCII:
2212 0008 ADDB RL0,#%30 ! CONVERT TO ASCII !
2214 3030

! STORE IF OUTBUF !
2216 93F1 PUSH GR15,R1 ! SAVE R1 !
2218 61E1 LD R1,OUTPTR(R14)
221A 0306

```

0210	2E18	LDE	@R1,RL0	! STORE CHR !
021E	69E7	INC	OUTPTR(R14)	
0220	0306			
0222	97F1	POP	R1,@R15	
0224	9E08	RET		
0226		END CONVW		
		END SUPPORT1		

4. SUPPORT2 MODULE

Z8000ASM 2.02
 LOC OBJ CODE STMT SOURCE STATEMENT

```

1 SUPPORT2 MODULE
$LISTON $TTY
!*****
*
*   SUPPORT TWO MODULE: MODULE TWO FOR
*   SECONDARY STORAGE INTERFACING
*
*****!
```

CONSTANT

```

RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPORT   := %FFCB
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF9
VINTR    := % (2) 0001000200000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %08
LINDEL   := %7F
CR       := %0D
LF       := %0A
TXOFCH   := %13
TXONCH   := %11
INSIZ    := 128      ! INTBUF SIZE !
OUTSIZ   := 128      ! OUTBUF SIZE !
RBSIZ    := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE   := 0
ISTOP    := 1
OSTOP    := 2
```

```

SNDMDE      := 3
LDMDE       := 4
ESC         := 5
TXMSK       := %6

```

EXTERNAL

```

EXEC        LABEL
PBUFNC      LABEL
NMI_RTN     LABEL
CONVW       PROCEDURE
PPNTBF      PROCEDURE
BRKROU      LABEL
NEWLNE      PROCEDURE
GETBUF      PROCEDURE
GETLNE      PROCEDURE
LOADFL      PROCEDURE

```

INTERNAL

```

$SECTION DATA_DEC
$ABS 0

```

```

0020      INTBUF  ARRAY [128 BYTE]
0080      OUTBUF  ARRAY [128 BYTE]
0100      RNGBUF  ARRAY [256 BYTE]
0200      MCZBUF  ARRAY [256 BYTE]

```

```

0300      BUFADR  WORD
0302      BUFSIZ  WORD

```

```

0304      INTPTR  WORD
0306      OUTPTR  WORD

```

```

0308      UNIMP   WORD
030A      BRKCNT  WORD

```

```

030C      NXTPTR  WORD
030E      GETOUT  WORD
0310      MCZPUT  WORD
0312      MCZGET  WORD
0314      BRKSTR  WORD
0316      BRKADR  WORD
0318      TMPSP   WORD
031A      TMPFCW  WORD

```

```

031C      MFLAGS  WORD

```

! USER REGISTER STORAGE !

```

031E      R0_     WORD

```

0320	R1_	WORD
0322	R2_	WORD
0324	R3_	WORD
0326	R4_	WORD
0328	R5_	WORD
032A	R6_	WORD
032C	R7_	WORD
032E	R8_	WORD
0330	R9_	WORD
0332	R10_	WORD
0334	R11_	WORD
0336	R12_	WORD
0338	R13_	WORD
033A	R14_	WORD
033C	R15_	WORD
033E	RPC_	WORD
0340	RFC_	WORD

0342	RETRY	WORD
0344	ADF_STR	WORD

```
GLOBAL
$SECTION SUPPORT2_PROC
$REL 0
```

```
GLOBAL
0000 NMI PROCEDURE
```

```
!*****!
*
* NMI INT: NON-MASKABLE INTERRUPT
* HANDLER FOR RETURN TO
* INITIALIZATION ENVIRONMENT
* DUE TO ERROR IN MCZ LOAD.
*
*****!
```

```
ENTRY
0000 010F ADD R15,#6 ! RESTORE STACK PTR !
0002 0006
0004 76CA LDA R10,NMI_RTN(R12)
0006 0002*
0008 1EAS JP GR10
000A END NMI
```



```

GLOBAL
000A LOAD FILE PROCEDURE
!*****
*
*   LOAD_FILE: LOADS MCZ FILENAME INTO
*               RINGBUFFER (CONS INPUT);
*               CONVERTS LOAD ADR (R3)
*               INTO ASCII CHAR AND
*               STORES IN RINGBUFFER.
*
*   REG USE: INPUT  R3 = HEX LOAD ADR
*                 R4 = FILENAME ADR
*
*****!
ENTRY
! LOAD FILENAME INTO RINGBUFFER !
000A 61E0      LD      R0,NXTPTR(R14)
000C 030C
000E A109      LD      R9,R0      ! SAVE RINGBUF OFFSET !
0010 76CA      LDA      R10,GETBUF(R12)
0012 0128
0014 1FA0      CALL     GR12      ! CONVERT TO ADR !
! RETURNS P2 = ADR !
0016 8D08      CLR      R0
0018 2048      LDB      RL0,GR4    ! 1ST BYTE=NO. CHR !
! IN FILENAME !
001A A940      INC      R4
001C 8109      ADD      R9,R0      ! UPDATE OFFSET !
001E 6FE9      LD      NXTPTR(R14),R9
0020 030C

0022 BA41      LDIBB     GR2,GR4,R0 ! ENTER FILENAME !
0024 0020

!CONVERT LOAD ADDRESS TO ASCII !
0026 0B03      CP      R3,%FFFE  ! CK FOR LOAD ADR !
0028 FF7E
002A E610      JR      Z,LD_FILE  ! USE IMAGED ADR !
002C A032      LDB      RH2,RH3    ! FIRST BYTE !
002E DFDA      CALR     HEX_TO_ASCII
0030 A124      LD      R4,R2      ! SAVE MSB'S !
0032 A0B2      LDB      RH2,RL3    ! GET SECOND BYTE !
0034 DFDD      CALR     HEX_TO_ASCII
0036 A125      LD      R5,R2      ! SAVE LSB'S !

! LOAD ADDRESS IN RINGBUFFER !
0038 61E0      LD      R0,NXTPTR(R14) ! RINGBF OFFSET !
003A 030C
003C 76CA      LDA      R10,GETBUF(R12)
003E 0128

```

```

0040 1FA0      CALL      GR10          ! CONVERT TO ADR !
0042 2F24      LD        GR2,R4        ! ENTER MSB'S !
0044 3325      LD        R2(#2),R5     ! ENTER LSP'S !
0046 0002
0048 69E3      INC       NXTPTR(R14),#4 ! UPDATE PTR !
004A 030C

```

LD_FILE:

```

! INSERT CARRIAGE RETURN !
004C 61E0      LD        R0,NXTPTR(R14)
004E 030C
0050 76CA      LDA       R10,GETBUF(R12)
0052 0128
0054 1FA0      CALL      GR10
0056 6FE0      LD        NXTPTR(R14),R0
0058 030C
005A 0C25      LDB       GR2,#%0D
005C 2D0D
! LOAD FILE WITH NO CONSOLE PROMPTING !
005E 2109      LD        R9,%AAAA      ! NO_PROMPT SIGNAL !
0060 AAAA

! GET COMMAND !
0062 76CA      LDA       R12,GETLINE(R12)
0064 0000*
0066 1FA0      CALL      GR10

0068 7C05      EI        VI          ! ENABLE VECTORED INT !
006A 76CA      LDA       R10,LOADFL(R12)
006C 0000*
006E 1FA0      CALL      GR10          ! LOAD FILE !
0070 8D98      CLR       R9          ! DELETE SIGNAL !

0072 61E1      LD        R1,NXTPTR(R14)
0074 030C
0076 6FE1      LD        GETOUT(R14),R1 ! RESFT PTRS !
0078 030E
007A 9F08      RET

007C      END LOAD_FILE

```

007C

HEX_TO_ASCII PROCEDURE

```

!*****
*
*   HEX_TO_ASCII: CONVERTS HEX ADR (TWO
*                   4-BIT VALUES) TO ASCII (TWO
*                   8-BIT VALUES).
*
*   REG USE: INPUT  RH2 = INPUT BYTE
*
*****!

```

ENTRY

```

007C BE2A    RLDB      RL2,RH2      ! CONVERT 1ST NIBBLE !
007E DFFD    CALR      HEX_ASCII
0080 A0A8    LDB       RL0,RL2      ! TEMP STORE BYTE !
0082 BE2A    RLDB      RL2,RH2      ! CONVERT 2ND NIBBLE !
0084 A082    LDB       RH2,RL0      ! RELOAD BYTE !

```

HEX_ASCII:

```

0086 060A    ANDB      RL2,#0F      ! GET NIBBLE !
0088 0F0F
008A 0A0A    CPB       RL2,#0A      ! '0-9'? !
008C 0A0A
008E E702    JP        C,CONV_ASCII
0090 000A    ADDB      RL2,#7        ! CONVERT NUMERAL !
0092 0707

```

CONV_ASCII:

```

0094 000A    ADDB      RL2,#30      ! CONV TO ASCII !
0096 3030

```

```

0098 9E08    RET
009A

```

END HEX_TO_ASCII

GLOBAL

009A

SNDMCZ PROCEDURE

```

!*****
*
*   SNDMCZ: OUTPUT CHAR TO SERIAL PORT
*           ONE (MCZ SYS).
*
*   REG USE: INPUT  RL0 = CHAR
*           RETURN Z IF CHAR = CR
*
*****!

```

ENTRY

```

009A 3A04    INB       RH0,PORTAC    ! GET STATUS !
009C FFDB
009E A600    BITB      RH0,#TXR      ! TRANSMIT RDY? !
00A0 F6FC    JR        Z,SNDMCZ      ! NOT YET..... !
00A2 3A86    OUTB      PORTAD,RL0    ! YES, SND CHR !

```

```

20A4 FFD9
20A6 0A29      CPB      RL0,#CR
20A8 2D0D
00AA 9E08      RET
00AC          END SNDMCZ

GLOBAL
SNDMSG PROCEDURE
!*****
*
*   SNDMSG: SEND MSG SPECIFIED TO CONS
*           (PORT2). FIRST BYTE OF MSG
*           IS THE DECIMAL LENGTH IN
*           WORDS.
*
*   REG USE: INPUT  P2 = MSG ADDR
*
*****!
ENTRY
00AC 34E1      LDA      R1,R14(#OUTBUF)
00AE 0080
00B0 8D08      CLR      P0
00B2 2028      LDB      RL0,QR2      ! GET BYTE COUNT !
00B4 8101      ADD      R1,R0
00B6 33E1      LD       R14(#OUTPTR),R1
00B8 0306
00BA A920      INC      R2      ! SETUP FOR TRANSFER !
00BC 34E1      LDA      R1,R14(#OUTBUF)
00BE 0080
00C0 BA21      LDIRB     QR1,QR2,R0  ! TRANSFER TO OUTBUF !
00C2 0010
00C4 34CA      LDA      R10,R12(#PBUFNC)
00C6 0000*
00C8 1EAB      JP       QR10      ! OUTPUT TO CONS !
00CA          END SNDMSG

```

```

GLOBAL
CCNINT PROCEDURE
*****
*
*   CCNINT: CONS (PORT2) INPUT INT HDLR *
*   ROUTINE, WHICH GETS REC CHR *
*   FROM USART. REC CHR IS CK *
*   FOR TXOFCH OR TXONCH, AND *
*   MFLAGS ADJUSTED ACCORDINGLY *
*   TO SIGNAL PROCEDURES. *
*
*****
ENTRY
00CA 93F0      PUSH      R15,R0
00CC 93F1      PUSH      R15,R1
00CE 93F2      PUSH      R15,R2      ! SAVE WORK REGS !
00D0 93FE      PUSH      R15,R14
00D2 7D15      LDCTL     R1,PSAPOFF  ! DATA_AREA ADR !
00D4 211E      LD        R14,R1

! GET CHAR AND CHECK FOR TXOFCH OR TXONCH !
00D6 3A94      INB       R1,PORTBD  ! GET USART DATA !
00D8 FFE1
00DA A297      RESB      R1,#PAR    ! CLR PARITY BIT !
00DC 67E0      BIT       MFLAGS(R14),#TRPMDE
00DE 031C

00E2 FE18      JR        NZ,PUTCHR   ! TRANSPARENT MODE !
00E2 0A09      CPB       R1,#TXONCH ! YES,.....!
00E4 1111      CPB       R1,#TXONCH ! NO, CK FOR TXONCH!
00E6 FE03      JR        NZ,AGAIN    ! NO,....!
00E8 63E2      RES       MFLAGS(R14),#OSTOP ! RESET TO, !
00EA 031C

! RESUME OUTPUT !
00EC E818      JR        FINISH
AGAIN:
00EE 0A09      CPB       R1,#TXOFCH  ! CK FOR TXOFCH !
00F0 1313
00F2 FE03      JR        NZ,AGAIN2   ! NO,....!
00F4 65E2      SET       MFLAGS(R14),#CSTOP ! STOP OUTPUT !
00F6 031C
00F8 E812      JR        FINISH

! CHECK FOR ESCAPE CHARACTER !
AGAIN2:
00FA 0A09      CPB       R1,#ESCAPE
00FC 1B1B
00FE FE09      JR        NZ,PUTCHR   ! NO,.....!
0100 67E3      BIT       MFLAGS(R14),#SNDMDE ! YES, CK SND MDE!
0102 031C

```

```

0104 FF03      JR      NZ,ESCP      ! YES,.....!
0106 67E4      BIT      MFLAGS(R14),#LDNDE ! NO, CK LD MDE !
0108 031C
010A E603      JR      Z,PUTCHR     ! NO !
ESCP:
010C 65E5      SET      MFLAGS(R14),#FSC ! SET ESCAPE BIT !
010E 031C
0110 E806      JR      FINISH

```

! PRIMARY SAVE CHARACTER ROUTINE !

```

PUTCHR:
0112 31E0      LD      R0,R14(#NXTPTR)
0114 730C
0116 DFF8      CALL     GETBUF      ! GET RNGBUF ADDR !
0118 33E0      LD      R14(#NXTPTR),R0
011A 030C
011C 2E29      LDB      GR2,R11     ! PUT CHR IN RNGBUF !

```

```

FINISH:
011E 97FE      POP      R14,GR15
0120 97F2      POP      R2,GR15
0122 97F1      POP      R1,GR15
0124 97F0      POP      R0,GR15     ! RESTORE WORK REGS !
0126 7E00      IRET
0128           END CONINT

```

```

GLOBAL
0128 GETBUF PROCEDURE
!*****!
*
* GETBUF: DETERMINES POSITION IN
* RINGBUFFER TO PUT OR GET
* NEXT CHAR.
*
* REG USE: INPUT R0 = CURRENT INDEX
* RETURN R0 = NEW INDEX
* R2 = ADR OF RNGBUF
*
*****!

```

```

ENTRY
0128 93FD      PUSH     GR15,R13
012A A102      LD      R2,R0
012C A900      INC      R0,#1      ! INC PTR !
012E 0B00      CP      R0,#RBSIZ  ! WRAP AROUND !
0130 0100
0132 EE01      JR      NZ,GB
0134 8D08      CLR      R0      ! RESET INDEX !
0136 34ED      GB:LDA    R13,R14(#RNGBUF) ! NEW ADR !
0138 0100
013A 81D2      ADD      R2,R13

```

```

013C 97FD      POP      R13,GR15
013E 9F28      RET
0140          END GETBUF

```

```

0140          GLOBAL
          MCZHND  PROCEDURE

```

```

!*****
*
*  MCZHND: MCZ (SERIAL PORT1) INPUT
*          INTERRUPT HANDLER ROUTINE
*          WHICH GETS RECEIVED CHAR
*          FROM USART. AND STORES IN
*          MCZBUF.
*
*****!

```

ENTRY

```

0140 93F0      PUSH     GR15,R0
0142 93F1      PUSH     GR15,R1
0144 93F2      PUSH     GR15,R2      ! SAVE WORK REGS !
0146 93FE      PUSH     GR15,R14
0148 7D15      LDCTL    R1,PSAPOFF
014A 211E      LD       R14,GR1      ! DATA_AREA ADR !
! GET CHAR FROM MCZ !
014C 3A94      INB      RL1,PORTAD    ! GET CHR !
014E FFD9
0150 A297      RESB     RL1,#PAR      ! RESET PARITY !
0152 31E0      LD       R0,R14(#MCZPUT)
0154 0310
0156 DFF8      CALR     GMCZAD        ! GET MCZBUF ADR !
0158 33E0      LD       R14(#MCZPUT),R0
015A 0310
015C 2E29      LDB      GR2,RL1      ! SAVE CHAR !

```

!RESTORE WORK REGS !

```

015E 97FE      PCP      R14,GR15
0160 97F2      POP      R2,GR15
0162 97F1      POP      R1,GR15
0164 97F0      PCP      R0,GR15
0166 7B00      IRET
0168          END MCZHND

```

0162

GLOBAL

GMCZAD PROCEDURE

```

!*****
*
* GMCZAD: GET NEXT ADR OF MCZ BUFFER
* TC STORE OR GET CHARACTER.
*
* REG USE: INPUT R0 = PTR IN MCZBUF
* RETURN R0 = NEW PTR IN BUF
* R2 = BGN OF MCZBUF
*
*****!

```

ENTRY

```

0168 93FD    PUSH    GR15,R13
016A A102    LD      R2,R0
016C A900    INC     R0,#1
016E 0B00    CP      R0,#RBSIZ    ! WRAP AROUND? !
0170 0100
0172 EE01    JR      NZ,GBZ
0174 8D08    CLR     R0            ! RESET OFFSET !
GBZ:
0176 34FD    LDA     R13,R14(#MCZBUF)    ! GET ADR !
0178 0200
017A 81D2    ADD     R2,R13
017C 97FD    POP     R13,GR15
017E 9E08    RET
0180
END GMCZAD

```

END SUPPORT2

AD-A109 552

NAVAL POSTGRADUATE SCHOOL MONTEREY CA
SASS HARDWARE ARCHITECTURE AND DEVELOPMENTAL MONITOR.(U)
JUN 81 8 5 BAKER
NPS52-81-016

F/B 9/2


UNCLASSIFIED

NL

3-3

END
DATE
FILMED
DTIC





5. SUPPORT3 MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 SUPPORT3 MODULE
\$LISTON \$TTY

```

!*****
*
* SUPPORT3 MODULE: MODULE THREE FOR
* SECONDARY STORAGE PRIMITIVES
* FUNCTIONS SUPPORT. STRICTLY
* HARDWARE DEPENDENT; SHOULD
* MEET STORAGE DEVICE REQUIRE-
* MENTS FOR INTERFACING.
*
* NOTE: DUPLICATE OF MONITOR LOAD_CMD
* MODULE.
*
*****!

```

CONSTANT

```

RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTBC   := %FFE3

IDPORT   := %FFCB
ICPORT   := %FFC9

TCMD     := %FFD2
TDTA     := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR    := % (2) 0001000000000000
VIBIT    := 12
ESCAPE   := %1B
BS       := %09
LINDEL   := %7F
CR       := %0D
LF       := %0A
TXOFCH   := %13

```

```

TXONCH      := %11
INSIZ       := 128      ! INIBUF SIZE !
OUTSIZ      := 128      ! OUTBUF SIZE !
RESIZ       := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE      := 0
ISTOP       := 1
OSTOP       := 2
SNDMDE      := 3
LDMDE       := 4
ESC         := 5
TXMSK       := %6

```

```
COMDS       := 12
```

EXTERNAL	PRNTBF	PROCEDURE
EXTERNAL	GETNXT	PROCEDURE
EXTERNAL	EROR	LABEL
EXTERNAL	SNDCHR	PROCEDURE
EXTERNAL	GETADP	PROCEDURE
EXTERNAL	GMCZAD	PROCEDURE
EXTERNAL	SNDMCZ	PROCEDURE
EXTERNAL	CONVEPT	PROCEDURE
EXTERNAL	PEUFNC	LABEL
EXTERNAL	SNDMSG	PROCEDURE
EXTERNAL	CONVW	PROCEDURE

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

0000	INIBUF	ARRAY [128 BYTE]
0080	OUTBUF	ARRAY [128 BYTE]
0100	RNGBUF	ARRAY [256 BYTE]
0200	MCZBUF	ARRAY [256 BYTE]
0300	BUFADR	WORD
0302	BUFSIZ	WORD
0304	INTPTR	WORD
0306	OUTPTR	WORD
0308	UNIMP	WORD
030A	BRKCNT	WORD
030C	NXTPTR	WORD
030E	GETOUT	WORD
0310	MCZPUT	WORD
0312	MCZGET	WORD
0314	BPKSTR	WORD

```

0316      BRKADR  WORD
0318      TMPSP   WORD
031A      TMPFCW  WORD

```

```

031C      MFLAGS  WORD

```

! USER REGISTER STORAGE !

```

031E      R0_     WORD
0320      R1_     WORD
0322      R2_     WORD
0324      R3_     WORD
0326      R4_     WORD
0328      R5_     WORD
032A      R6_     WORD
032C      R7_     WORD
032E      R8_     WORD
0330      R9_     WORD
0332      R10_    WORD
0334      R11_    WORD
0336      R12_    WORD
0338      R13_    WORD
033A      R14_    WORD
033C      R15_    WORD
033E      RPC_    WORD
0340      RFC_    WORD

```

```

0342      RETFY   WORD

```

```

0344      ADR_STR WORD

```

```

$SECTION LOAD_PROC
$REL 0

```

```

0000      GLOBAL
          FNAME PROCEDURE
          !*****
          *
          *      FNAME: RESETS TWO PTRS TO MCZBUF
          *      AND CHECKS FOR FILENAME.
          *
          !*****

```

```

          ENTRY
0000 4DE8      CLR      MCZGET(R14)
0002 0312
0004 4DE8      CLR      MCZPUT(R14)      ! RESET BUFFER !
0006 0310
0008 34CA      LDA      R10,R12(#GETNXT)

```

```

000A 0000*
000C 1FA0      CALL      GR10      ! SKIP CMD ARG !
000E 2A09      CPB        RL0,#'A'
0010 4141
0012 E711      JR         C,DUN
0014 0A09      CPB        RL0,#'Z'+1
0016 5B5B
0018 EF0E      JR         NC,DUN      ! 1ST CHR IN (A..Z) !
001A 76CA      LDA        R10,GETNXT(R12)
001C 0000*
001E 1FA0      CALL      GR10      ! SKIP TO NEXT ARG !
0020 F6F7      JR         Z,NO_ADR   ! NO NEXT ARG !
0022 76CA      LDA        R10,GETADR(R12)
0024 0000*
0026 1FA0      CALL      GR10      ! GET USER SPECIFIED !
                                ! ADDRESS !
0028 A13B      LD         R11,R3      ! SAVE USER ADR !
002A 6FE3      LD         ADR_STR(R14),R3
002C 0344
002E 9E08      RET

                                NO_ADR:
0030 210B      LD         R11,#%FFFE ! SIGNAL TO USE MCZ !
0032 FFFE
                                ! ADDRESS !
0034 9E08      RET

                                DUN:
0036 8D98      CLR        R9
0038 34CA      LDA        R10,R12(#EROR)
003A 0000*
003C 1EA8      JP         GR10      ! ERROR, RTN TO EXEC !
003E          END FNAME

```

```

GLOB^L
003F CMIPAS PROCEDURE
!*****
*
* CMIPAS: LOAD CMD PASSING MECHANISM
* SENDS 'B;' PLUS CONS CMD
* LINE TO MCZ AND CKS RESPONSES FOR
* GOOD Z80 PROGRAM LOAD.
*
* REG USE: RETURN NZ IF Z80 LOADED
* Z IF NOT
*
*****!
ENTRY
003E 67E5 BIT MFLAGS(R14),#ESC ! CK FOR ESCAPE !
0040 031C
0042 E602 JR Z,GCMD
0044 8D41 SETFLG Z
0046 9E08 RET

GCMD:
0048 C242 LDB RH2,#'B'
004A CA3B LDB RL2,#';'
004C 6FE2 LD OUTBUF(R14),R2 ! LOAD INIT 'B;' !
004E 0080
! FOR BRIEF MODE !
0050 76E2 LDA R2,OUTBUF(R14)
0052 0080
0054 A921 INC R2,#2
0056 76E1 LDA R1,INTBUF(R14)
0058 0000
005A 2100 LD R0,#%40 ! LD CMD IN OUTBUF !
005C 0040
005E BB11 LDIR @R2,@R1,R0
0060 0020

0062 76E1 LDA R1,OUTBUF(R14)
0064 0080
0066 0101 ADD R1,#%80
0068 0080
006A 6FE1 LD OUTPTR(R14),R1
006C 0306

006E DFB6 CALR OUTSTM ! OUTPUT BUFFER !
0070 DFE7 CALR SKIPLN ! SKIP MCZ ECHO !
0072 DFD4 CALR MCZCOM ! WAIT RESPONSE !
0074 0A09 CPB RL1,#'B'
0076 4242
0078 EE02 JR NZ,LDSTAT
007A DFE7 CALR SKIPLN ! SKIP MCZ ECHO !

```

```

007C DFD9      CALR      MCZCOM      ! WAIT RESPONSE !

! VERIFY LOAD STATUS !
LDSTAT:
007E 0A09      CPB      RL1,#'9'      ! TEST LEGAL !
0080 3939
0082 F60E      JR      Z,RECACK      ! ACKNOWLEDGEMENTS !
0084 0A09      CPB      RL1,#'0'
0086 3030
0088 F60B      JR      Z,RECACK      ! REC GOOD ACK !
008A 0A09      CPB      RL1,#'7'
008C 3737
008E F60B      JR      Z,RECACK

! NO ACKNOWLEDGEMENTS RECEIVED !
ERMSG:
0090 DFD9      CALR      RECMSG      ! GET MCZ MSG !
0092 34CA      LDA      R10,R12(#SNDCHR)
0094 0000*
0096 1FA0      CALL     QR10      ! SEND TO CONS !
0098 0A08      CPB      RL0,#LF
009A 0A0A
009C 9E06      RET      Z      ! DONE !
009E F6FB      JR      ERMSG

! ACKNOWLEDGE RECEIVED !
RECACK:
00A0 8D43      RESFLG    Z      ! RETURN NZ !
00A2 9E08      RET
00A4          END CMDPAS

GLOBAL
SKPB LABEL
SKIPLN PROCEDURE
00A4
!*****!
*
* SKIPLN: SKIP RECEIVED LINE FROM
* MCZ; RETURN FIRST CHAR OF
* NEXT LINE.
*
* REG USE: RETURN RL1 = 1ST CHR
* AND NZ IF ESC
*
*****!
ENTRY
00A4 DFE3      CALR      RECMSG      ! SKIP OVER LINE !
00A6 0A08      CPB      RL0,#CR      ! THRU CR,LF !
00A8 0D0D
00AA EF0C      JR      NZ,SKIPLN

```



```

SKPB:
00AC 2101      LD      R1,%3000      ! DELAY FACTOR !
00AF 3000

! MAIN LOOP FOR RECEIVING CHAR !
LOOP1:
00B0 61E0      LD      R0,MCZGET(R14)
00F2 0312
00B4 4BE0      CP      R0,MCZPUT(R14)      ! TEST FOR REC CHR !
00B6 0310
00F8 EE03      JR      NZ,RECHR      ! YES,..... !
00BA AB10      DFC      R1,#1      ! NO, WAIT AWHILE !
00BC FEF9      JR      NZ,LOOP1
00BE 9E06      RET      Z      ! FORCED EOL !

RECHR:
00C0 DFFB      CALR     MCZCOM
00C2 0A09      CPB      RL1,#'      ! CK 1ST=PRNT CHR !
00C4 2020
00C6 9E0D      RET      PL
00C8 DFF5      CALR     RECMMSG
00CA E8F0      JR      SKPB
00CC          END SKIPLN

00CC          MCZCOM PROCEDURE
!*****!
*
* MCZCOM: LOOPS WAITING FOR RECEIVE *
* CHAR FROM MCZ BY SEEING IF *
* MCZBUF GETS CHAR. DOES *
* ADVANCE POINTER. *
*
* REG USE: RETURN RL1 = CHR *
*
!*****!
ENTRY
00CC 61E0      LD      R0,MCZGET(R14)      ! CHECK MCZBUF !
00CE 0312
00D0 4BE0      CP      R0,MCZPUT(R14)      ! POINTERS !
00D2 0310
00D4 E6FB      JR      Z,MCZCOM      ! WAIT.....!
00D6 34CA      LDA      R10,R12(#GMCZAD)
00D8 0000*
00DA 1FA0      CALL     GR10      ! GET CHAR FROM BUF !
00DC 2029      LDB      RL1,GR2
00DE 9E06      RET
00E0          END MCZCOM

```

00E0

RECMSG PROCEDURE

```
!*****
*
*   RECMSG: LOOPS WAITING FOR REC CHR
*           FROM MCZ. GETS CHAR AND
*           DO NOT ADVANCE BUF PTR.
*
*   REG USE: RETURNS   RL0 = CHR
*
*****!
```

ENTRY

```
00E0 61E0      LD      R0,MCZGET(R14)
00E2 0312
00E4 4BE0      CP      R0,MCZPUT(R14)      ! CK FOR REC !
00E6 0310
00E8 F6FB      JR      Z, RECMSG      ! WAIT..... !
00EA 34CA      LDA      R10,R12(#GMCZAD)
00EC 0000*
00EE 1FA0      CALL     GR10      ! GET 1ST CHAR !
00F0 6FE0      LD      MCZGET(R14),R0      ! RESTORE PTR !
00F2 0312
00F4 2029      LDB      RL0,GR2      ! RTN CHAR !
00F6 9E08      RET
00F8          END RECMSG
```

GLOBAL

```
OUTSTM      LABEL
OUTLINE     PROCEDURE
```

00F8

```
!*****
*
*   OUTLINE: OUTPUTS A LINE OF CHAR FROM
*           OUTBUF TO MCZ WITH CR AT
*           END.
*
*   OUTSTM: OUTPUTS A LINE OF CHAR W/CR
*
*****!
```

ENTRY

```
00F8 61F2      LD      R2,OUTPTR(R14)
00FA 0306
00FC 2C25      LDB      GR2,#CR      !STORE CR IN BUF !
00FE 0D0D
0100 69E0      INC      OUTPTR(R14),#1      ! INC PTR !
0102 0306
```

! NO CR ENTRY POINT !

OUTSTM:

```
0104 76F1      LDA      R1,OUTBUF(R14)
2106 0082
```

! MAIN LOOP !

```

                                OVRAGN:
0108 2018      LDB      RL2,QR1
010A A913      INC      R1
010C 34CA      LDA      R10,R12(#SNDMCZ)
010E 0000*
0110 1FA0      CALL     QR10      ! SND CHR TO MCZ !
0112 F603      JR       Z,FINIS
0114 4BE1      CP       R1,OUTPTR(R14)
0116 0306
0118 E7F7      JR       C,OVRAGN      ! CK IF BUF EMPTY !

! FINISHED, RESET OUTPTR(R14) AND BLANK OUTBUF !
FINIS:
011A 76E2      LDA      R2,OUTBUF(R14) ! RESET POINTER !
011C 0080
011E 6FE2      LD       OUTPTR(R14),R2
0120 0306
0122 2100      LD       R0,#OUTSIZ/2
0124 0040
0126 AB00      DEC      R0,#1      ! SET COUNT !
0128 4DE5      LD       OUTBUF(R14),#      ! LOAD COUNT !
012A 0080
012C 2020
012E 76E2      LDA      R2,OUTBUF(R14)
0130 0080
0132 A121      LD       R1,R2
0134 A911      INC      R1,#2
0136 B321      LDIR     QR1,QR2,R0      ! CLR PUFFER !
0138 0010
013A 9E08      RET
013C          END OUTLINE

```

```

ABORTM LABEL
GODPAK LABEL
BADPAK PROCEDURE
013C
|*****|
*
* BADPAK: SENDS RESEND SIGNAL ('7')
* TO MCZ FOR BAD CKSUM OR REC
* NON-ASCII CHR.
*
* ABORTM: SENDS ABORT SIGNAL ('9')
* WHEN USER SELECTED.
*
* GODPAK: SENDS ACK SIGNAL ('0') FOR
* RECEIPT OF GOOD PACKET.
*
*****!
ENTRY
013C C837 LDB RL0,#'7' ! LD RESEND SIG !
013E E803 JR CUTALL
ABORTM:
0140 C839 LDB RL0,#'9' ! LD ABORT SIG !
0142 E801 JR CUTALL
GODPAK:
0144 C830 LDB RL2,#'0' ! LD REC OK SIG !
OUTALL:
0146 6FE8 LDB OUTBUF(R14),RL0
0148 00E0
014A 76ED LDA R13,OUTBUF(R14)
014C 0080
014E A9D0 INC R13,#1
0150 6FED LD OUTPTR(R14),R13
0152 0306
0154 D02F CALR OUTLNE ! SEND MCZ SYSTEM !
0156 D05A CALR SKIPLN ! SKIP ECHO !
0158 9E08 RET
015A END BADPAK

```

```

GLOBAL
GETACK  PROCEDURE
*****
*
*   GETACK: RECEIVE AND INTERPRET ACK
*           FROM MCZ. GOOD ACK = '0'
*           BAD   ACK = '7'
*           ABORT  = '9'
*
*   REG USE:  RETURN  Z,NC IF GOOD ACK
*               NZ,NC IF BAD ACK
*               NZ,C IF ABORT
*
*****
ENTRY
015A D048      CALR      MCZCOM      ! GET CHR !
015C 0A29      CPB       RL1,#'0'    ! CK FOR ACK !
015F 3030
0160 EE04      JR        NZ,NACK     ! NO..... !
0162 D060      CALR      SKIPLN      ! YES, REC ACK !
0164 9D41      SETFLG    Z
0166 8D83      RESFLG    C
0168 9E08      RET

! CK FOR '7' AND '9' NON-ACKNOWLEDGEMENTS !
NACK:
016A 0A29      CPB       RL1,#'7'    ! CK FOR RESEND !
016C 3030
016E EE04      JR        NZ,ABRT     ! NO.... !
0170 D067      CALR      SKIPLN
0172 9D43      RESFLG    Z
0174 8D83      RESFLG    C
0176 9E08      RET

! CHECK FOR ABORT !
ABRT:
0178 0A09      CPB       RL1,#'9'
017A 3030
017C F602      JR        Z,ENDIT     ! YES, ABORT... !
017E D050      CALR      RECMMSG     ! GET ANOTHER CHR !
0180 F8FC      JR        GETACK      ! TRY AGAIN.... !

ENDIT:
0182 D070      CALR      SKIPLN
0184 9D43      RESFLG    Z
0186 8D81      SETFLG    C
0188 9E08      RET
018A          END GETACK

```

018A

LINRCT PROCEDURE

```

*****
*
*   LINRCT: RECEIVES LINE OF CHAR FROM *
*           MCZ AFTER RECEIPT OF '/' *
*           AND STORES IN INTBUF, ADDING *
*           CR AT END AND FILTERING OUT *
*           CONTROL CHARACTERS. (<20H) *
*           (TRUNCATES AFTER 80 CHAR) *
*
*****

```

ENTRY

! WAIT FOR ASCII / !

018A D256
018C 0A08
018E 2F2F
0192 FEFC

CALR RECMSG
CPB RL0, # '/'

JR NZ, LINRCT ! WAIT !
! BEGIN STORING CHARACTERS !

0192 76E4
0194 0000
0196 CB50

LDA R4, INTBUF(R14)

LDB RL3, #80 !SET LINE LENGTH !
! STORE CHAR IN INTBUF !

LOPSTR:

0198 D05D
019A 2E48
019C 0A08
019E 0D0D
01A0 FE02
01A2 D07C
01A4 9E08

CALR RECMSG ! GET CHAR !
LDB GR4, RL0 ! STORE !
CPB RL0, #CR ! CK FOR END !
JR NZ, SKPSOM ! GOT CHAR.. !
CALR SKPB
RET

!CONTROL CHAR FILTERED AND DEC LINE COUNTER !
SKPSOM:

01A6 0A08
01A8 2020
01AA F7F6
01AC A940
01AE FB0C

CPB RL0, # '/'
JR C, LOPSTR
INC R4, #1 ! GOOD CHAR !
DBJNZ RL3, LOPSTR ! DEC COUNT !

!TRUNCATE, TOO MANY CHAR !

LOPOVR:

01B0 D069
01B2 0A08
01B4 0D0D
01B6 FEFC
01B8 76ED
01BA 0000
01BC 010D
01BE 0050
01C0 2ED8

CALR RECMSG
CPB RL0, #CR ! LOOK FOR CR !
JR NZ, LOPOVR
LDA R13, INTBUF(R14)
ADD R13, #80
LDB GR13, RL0

```

01C2 0F39      RET
01C4          END LIVRCT

01C4          UNPACK  PROCEDURE
!*****
*
*   UNPACK: UNPACKS RECEIVED PACKETS
*           FROM MCZ IN INTBUF AND
*           LOADS IN SPECIFIED MEMORY
*           AREA. ASCII CHAR ARE CON-
*           VERTED TO HEX VALUES.
*
*   FFG USE: INPUT  RH3 = #BYTE DATA
*****!

ENTRY
01C4 A03C      LDF      RL4,RH3      ! SAVE COUNT !
01C6 FFD6      CALR     CONVAD      ! CONV START ADR !

! CHECK FOR USER ENTERED ADDR FOR LOAD !
01C8 0B03      CP       R11,%FFFF
01CA FFFF
01CC F601      JR       Z,USE_MCZADR
01CF A1B1      LD       R1,R11      ! USER SPECIFIED !

USE_MCZADR:
01D0 76F2      LDA      R2,INTBUF(R14)
01D2 0000
01D4 A927      INC      R2,#8

CANDS:
01D6 DFF6      CALR     TRNHEX      ! CONVERT 2-ASCII CHR !
01D8 2E18      LDB      QP1,RL2    ! STORE IN MEM !
01DA A910      INC      R1,#1
01DC FC04      BRJNZ    RL4,CANDS   ! CONV AND STORE ALL !

! UPDATE USER SPECIFIED ADDRESS !
01DE 0B03      CP       R11,%FFFF
01F0 FFFF
01F2 F601      JR       Z,NO_UPDATE ! USE MCZ ADR !
01F4 A11B      LD       R11,R1     ! UPDATE USER ADR !

NO_UPDATE:
01F6 0F08      RET
01F8          END UNPACK

```

01F8

TRNHEX PROCEDURE

```

*****
*
*   TRNHEX: CONVERTS TWO ASCII CFAR FRM
*           INTBUF TO TWO 4-BIT HEX #
*           AND ADD TO CKSUM.
*
*   REG USE: INPUT  R2 = PTR TO 1ST CHR
*                   RL3= CKSUM ACCUM
*   RETURN  R2 = UPDATE PTR
*           RL3= UPATED ACCUM
*           RL0= HEX VALUE
*           AND C IF NON-ASCII
*           NC IF ALL GOOD
*
*****

```

ENTRY

```

01F8 DFF6 CALL ATOHEX      ! CONVERT 1ST CHR !
01FA 9F07 RET C
01FC 008B ADDB RL3,RL0     ! ADD TO CKSUM !
01FE B309 SLA R2,#12      ! MOVE TO H NIBBLE !
01F0 000C
01F2 DFFB CALR ATOHEX     ! CONVERT 2ND CHR !
01F4 9F07 RET C
01F6 808B ADDB RL3,RL0
01F8 8408 ORP RL0,RH0     ! COMBINE NIBBLES !
01FA 8D83 RESFLG C
01FC 9E08 RET
01FE      END TRNHEX

```

01FE

ATOHEX PROCEDURE

```

*****
*
*   ATOHEX: CONVERTS ONE ASCII CHAR TO
*           4-BIT HEX NIBBLE.
*
*   REG USE: INPUT  R2 = PTR TO CHR
*   RETURN  R2 = PTR + 1
*           RL0= HEX NIBBLE
*
*****

```

ENTRY

```

01FF 2028 LDB RL0,R2
0200 A920 INC R2,#1      ! INC PTR !
0202 34CA LDA R10,R12(#CONVERT)
0204 0000*
0206 1FA0 CALL @R10
0208 9E08 RET
020A      END ATOHEX

```


020A

CONVAD PROCEDURE

```

*****
*
* CONVAD: CONVERTS STARTING ADDRESS
* OF PACKET DATA TO HEX #.
*
* REG USE: RETURN R1 = ADDRESS(HEX)
*
*****

```

ENTRY

```

020A 76E2 LDA R2,INTBUF(R14)
020C 0000
020E D014 CALF TRNHEX
0210 A091 LDB RH1,RL0 ! STORE 1ST BYTE !
0212 D016 CALF TRNHEX
0214 A089 LDB RL1,RL0 ! STORE 2ND BYTE !
0216 9E08 RET
0218 END CONVAD

```

0218

CHKPAK PROCEDURE

```

*****
*
* CHKPAK: CK RECEIVED MCZ PAC CKSUM
* AGAINST ACCUMULATED HEX
* VALUE CKSUM AFTER ASCII-TO-
* HEX CONVERSION.
*
* REG USE: RETURN RH3 = BYTE COUNT
* AND C IF BAD OR
* NON-ASCII.
*
*****

```

ENTRY

```

0218 76E2 LDA R2,INTBUF(R14)
021A 0000
021C C303 LDB RH3,#3
021E DFF9 CALF CHKSUM ! CK 1ST CKSUM !
0220 9E07 RET C ! PAD CK !
0222 8C34 TESTB RH3
0224 9E06 RET Z ! NO DATA !
0226 93F3 PUSH QR15,R3 ! SAVE BYTE COUNT !
0228 DFFE CALF CHKSUM ! CK 2ND CKSUM !
022A 97F3 POP R3,QR15
022C 9E08 RET
022E END CHKPAK

```

022F

CHKSUM PROCEDURE

```

!*****
*
*   CHKSUM: CONVERTS ALL REC ASCII CHR
*           IN PAC TO HEX AND ACCUM NEW
*           CKSUM. COMPARE CKSUMS AND
*           REPORT DIFFERENCES.
*
*   REG USE: INPUT  R2 = PTR TO PAC
*                   PH3= # CHR PAIRS
*                   RETURN RE3= BYTE COUNT
*                   RL3= NEW CKSUM
*                   RH3= REC CKSUM
*                   AND C IF BAD OR
*                   NON-ASCII REC
*
*****!

```

ENTRY

022F	BCPS	CLRP	RL3	! RESET CKSUM !
0230	D025	AB:CALR	TRNHEX	! CONVERT PAIRS !
0232	9E07	RET	C	
0234	F303	DEJNZ	RH3,AB	! CONTINUE..... !
0236	A083	LDB	RH3,RL0	
0238	93F3	PUSE	QR15,R3	! SAVE BYTE CNT !
023A	D02A	CALR	TRNHEX	! CONVERT NEXT TWO !
023C	97F3	PCP	R3,QR15	
023E	9F07	RET	C	
0240	8AB8	CPF	RL0,RL3	! COMPARE CKSUMS !
0242	9E06	RET	Z	! GOOD CK... !
0244	8D81	SETFLG	C	! BAD CKSUM !
0246	9E08	RET		
0248		END CHKSUM		

0248

GLOBAL LOADFL PROCEDURE

```

!*****
*
*   LOADFL: RECEIVES PACKET FROM MCZ IN
*           FOLLOWING FORMAT:
*
*   <ADR><CNT><CKS1><DTA>...<DTA><CKS2>
*
*   ADR = START ASR IN 28000 MEM
*   CNT = # DATA WORDS
*   CKS1= CKSUM OF <ADR> + <CNT>
*   <DTA>...<DTA> = 30 DATA WORDS
*   CKS2= CKSUM OF DATA HEX VALUES
*
*   PROCEDURE VERIFIES CKSUMS BEFORE
*   STORING DATA IN 28000 MEM. PACKETS
*   ARE ACK FOR WITH: '0' = GOOD
*                   '7' = RESEND
*                   '9' = ABORT
*   IF REC '/' FROM MCZ, ECHOS WHAT
*   REC NEXT TO CONSOLE AND ABORT.
*
*****

```

ENTRY

0248 D125	CALR	FNAME	! CK FILENAME !
024A 65E4	SET	MFLAGS(R14),#LDMDE	!SIGNAL LOAD IN !
024C 031C			
024E D109	CALR	CMDPAS	!PROGRESS!
0250 9F76	RET	Z	! SND CMD TO MCZ !
			! 280 PROG NO LOAD !
	RECLOP:		
0252 D063	CALR	LINRCT	! GET PACKET !
0254 76F2	LD	R2,INTBUF(R14)	
0256 0000			
0258 2028	LDE	RL0,GR2	
025A 0408	CPB	RL0,#'/'	! CK FOR '/' !
025C 2F2F			
025E EE10	JR	NZ,CONTIN	!NO, CONTINUE...!
0260 76E1	LDA	R1,OUTBUF(R14)	!YES,!
0262 0080			
0264 2103	LD	R3,#%20	
0266 0020			
0268 BB21	LDIF	GR1,GR2,R3	!ERROR MSG SETUP !
026A 0310			
026C 76F1	LDA	R1,OUTBUF(R14)	
026E 0080			
0270 0101	ADD	R1,#%20	
0272 0020			

0274 6FE1 LD OUTPTR(R14),R1 !SET OUTPTR !
 0276 0306

0278 34C1 LDA R10,R12(=PBUFNC)
 027A 0000*
 027C 1FA0 CALL GR10
 027E 9F08 RET

CONTIN:

0280 67E5 BIT MFLAGS(R14),#ESC ! CK FOR ABORT !
 0282 031C
 0284 FE34 JR NZ,ABT ! YES, ABORT...!
 0286 D039 CALR CHKPAK ! CK CKSUMS !
 0288 FF02 JR NC,GDLD ! GOOD LOAD !
 028A D0A8 CALR BADPAK ! SEND NON-ACK !
 028C E8F2 JR RECLOP ! TRY AGAIN !

! CHECK FOR LAST PACKET AND PRINT <FNT ADR> !
 GDLD:

028E 8C88 CLRB RL3
 0290 8138 ADD R2,R3 ! ACCUM NUMBER BYTES !
 ! CF TRANSFER !

0292 8C34 TESTB RH3 ! CK COUNT=0 !
 0294 EE28 JR NZ,STOR ! OK, BEGIN STR !
 0296 D0AA CALR GODPAK ! SEND GOOD ACK !
 0298 54F0 LDL R0,INTBUF(R14)
 029A 0000
 029C 76FD LDA R13,OUTBUF(R14)
 029E 0080
 02A0 010D ADD R13,#%0C
 02A2 007C

! CHECK FOR USER SPECIFIED ADDR !

02A4 0B09 CP R9,#%AAAA
 02A6 0AAA
 02A8 E61D JP Z,END_LOAD ! NO ECHO TO CONS !
 02AA 0B09 CP R11,#%FFFE ! CK FOR LOAD ADR !
 02AC FFFE
 02AE F608 JR Z,SAME_ADR ! USE MCZ ADR !
 02B0 6FED LD OUTPTR(R14),R13 ! SET OUTBUF ADR !
 02B2 0306
 02B4 61E5 LD R5,ADR_STR(R14) ! GET USER ADR !
 02B6 0344
 02B8 76C1 LDA R10,CONVW(R12)
 02BA 0000*
 02BC 1FA0 CALL GR10 ! CONVERT TO ASCII AND !
 ! AND STORE IN OUTBUF !
 02BE E801 JR FIN_BUF
 SAME_ADR:

```

02C0 1DD0      LDL      0213.RR0

FIN_BUF:
02C2 3402      LDA      P2,ENTADR      !LOAD ENTRY LABEL!
02C4 0040
02C6 76F1      LDA      P1,OUTBUF(R14)
02C8 0060
02CA 2100      LD        R0,#6
02CC 0006
02CE BB21      LDIR      GR1,GR2,R0
02D0 0010
02D2 76ED      LDA      P13,OUTBUF(R14)
02D4 0080
02D6 0100      ADD      R13,#%10
02D8 0010
02DA 6FED      LD        OUTPTR(R14),R13
02DC 0306
02DE 34CA      LDA      P10,R12(#PRNTBF)
02E0 0000*
02E2 1FA0      CALL      GR10          ! PRINT MESSAGE !
END_LOAD:
02E4 9E08      RET

STOR:
02E6 D06F      CALR      CONVAD
02E8 D0D3      CALR      GODPAK      ! SEND ACK !
02EA D094      CALR      UNPACK      ! UNPACK AND STOPE !
02EC E8E2      JR        RECLOP      ! CONTINUE....!

ABT:
02EE 3402      LDAR      P2.EMSG
02F0 020A
02F2 34CA      LDA      R10,R12(#SNDMSG)
02F4 0000*
02F6 1FA0      CALL      GR10          ! SEND MESSAGE !
02F8 D0DD      CALR      ABORTM      ! SEND APORT !
02FA 9F08      RET

02FC          END_LOADFL

EMSG:
02FC 07        BVAL      7
02FE 2F41      WVAL      '/A'
0300 424F      WVAL      'BO'
0302 5254      WVAL      'ET'
0304 0D        BVAL      %0D
ENTADR:
0306 454E      WVAL      'FN'
0308 5452      WVAL      'TR'
030A 5920      WVAL      'Y'

```

0300	504F	WVAL	'PO'
030E	494E	WVAL	'IN'
0310	5420	WVAL	'T'

FND SUPPORT3

APPENDIX D - BOOTSTRAP Program Listing

A. BOOTSTRAP PROGRAM LISTING

1. BOOTSTRAP MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 BOOTSTRP MODULE
\$LISTON \$TTY

CONSTANT

RTR := 2
TXR := 3
PAR := 7
PORTAD := %FFD9
PORTBD := %FFE1
PORTAC := %FFDB
PORTBC := %FFE3

IDPORT := %FFCB
ICPCRT := %FFC9

TCMD := %FFD2
TDTA := %FFD0

BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR := %(2)0001000000000000
VIBIT := 12
ESCAPE := %1B
MAX_CPU := 8
BS := %08
LINDEL := %7F
CR := %0D
LF := %0A
TXOFCH := %13
TXONCH := %11

INSIZ := 128 ! INTBUF SIZE !
OUTSIZ := 128 ! OUTBUF SIZE !
RESIZ := 256 ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE := 7
ISTOP := 1
OSTOP := 2

```

SNDMDE := 3
LDMDE := 4
ESC := 5
TXMSK := %6

```

TYPE

```

MESSAGE ARRAY[3 WORD]
SWITCH ARRAY[2 WORD]
MEM_ARRAY ARRAY[32 WORD]
CPU_ENTRY RECORD [
    SIGNAL WORD
    CPU_ID WORD
    MSG_BLK MESSAGE
    MEM_MAP MEM_ARRAY]
ID_ARRAY ARRAY[MAX_CPU WORD]
ENTRY_ARRAY ARRAY[MAX_CPU CPU_ENTRY]

```

```

INTERNAL
$SECTION TABLE1_DATA
$ABS 0

```

```

0000 CONFIG_TABLE RECORD [
    RW_PATTERN WORD
    CPU_NUM WORD
    NORM_RW_PAT WORD
    NORM_CPU_CNT WORD
    TABLE_LOCK WORD
    CPU_CNT WORD
    CPU_LIST ENTRY_ARRAY]

```

```

$SECTION TABLE2_DATA
$ABS 2

```

```

0000 MIN_CONFIG_TBL RECORD [
    LOG_TO_PHYS ID_ARRAY
    CONF_MEM_MAP MEM_ARRAY]

```

```

$SECTION PSA_DATA
$ABS 0

```

```

0000 PSA RECORD [
    DATA_AREA WORD
    CODE_AREA WORD
    UNIMP_INST SWITCH
    PRIV_INST SWITCH
    SYS_CALL SWITCH
    SEG_TRAP SWITCH
    NMI_INT SWITCH
    NVI_INT SWITCH
    VEC_PCW WORD
    VEC_PC ARRAY [200 WORD]

```


INTERNAL
 \$SECTION DATA_DEC
 \$ABS 0

```

0000      INTBUF      AFRAY [128 BYTE]
0080      OUTBUF      ARRAY [128 BYTE]
0100      RGBBUF      ARRAY [256 BYTE]
0200      MCZBUF      AFRAY [256 BYTE]
0300      BUFADR      WORD
0302      BUFSIZ      WORD
0304      INTPTR      WORD
0306      OUTPTR      WORD
0308      NXTPTR      WORD
030A      GETOUT      WORD
030C      MCZPUT      WORD
030E      MCZGET      WORD
0310      MFL'GS      WORD
0312      RETRY      WORD
0314      ADP_STR      WORD
0316      DWN_ADP      WORD
0318      START_ADR    WORD

```

EXTERNAL
 LOAD_FILE PROCEDURE

\$SECTION BOOTSTRAP_PROC
 \$REL 0

GLOBAL
 0000 BOOTSTRAP PROCEDURE

```

!*****
*
*   INIT_TEST: INITIALIZES MULTIPRO-
*               CESSOR SYSTEM WITH A COMMON
*               MEMORY MAP AND SYSTEM WIDE
*               KNOWLEDGE OF EACH UNIQUE
*               CPU ID; LOADS LOCAL AND
*               GLOBAL PORTIONS OF O/S;
*               AND TRANSFERS CONTROL TO
*               LOCAL PORTION.
*
*****!

```

ENTRY

```

0000 34FC      LDAR      R12,BOOTSTRAP ! SET NEW CODE_AREA !
0002 FFFC

```

! INITIALIZE SYSTEM CALL HANDLER IN PSA !

```

0004 7DA5      LDCTL    R10,PSAPOFF
0006 340B      LDAR     R11,SYSTEM_CALL
0008 02A4
000A 76A1      LDA      R1,SYS_CALL(R10)
000C 000C
000E 0D15      LD       GR1,%4000      ! LOAD PCW FOR SC !
0010 4000
0012 331B      LD       R1(#2),R11      ! LOAD PC FOR SC !
0014 0002

0016 340B      LDAR     R11,MEM_INT
0018 0382
001A 76A1      LDA      R1,VEC_PC(R10)
001C 001E
001E 331B      LD       R1(#14),R11      ! LOAD MEM VIOLATION !
0020 000E
                                ! INT HANDLER IN PSA !

! INITIALIZE NORMAL STACK POINTER !
0022 210B      LD       R11,%4500
0024 4500
0026 7DFF      LDCTL    NSP,R11

! MOVE CODE TO COMMON NORMAL/SYSTEM AREA !
0028 2101      LD       R1,%4100      ! NEW CODE LOCATION !
002A 4100
002C 3404      LDAR     R4,NORM_SCRIBE ! START OF CODE !
002E 001E
0030 3402      LDAR     R2,GSB          ! END OF CODE !
0032 0072

DO
0034 214D      LD       R13,GR4
0036 2F1D      LD       GR1,R13
0038 8B42      CP       R2,R4          ! CK FOR END !
003A E603      JR       Z,NXT_SCB
003C A911      INC      R1,#2
003E A941      INC      R4,#2
0040 E8F9      OD
                                ! CODE TRANSFERRED !

NXT_SCB:
0042 2108      LD       R8,%4100
0044 4100
0046 2103      LD       R3,%411E      ! SET RTN ADR !
0048 411E
004A 1F80      CALL     GR8          ! SCRIBE MEMORY !
004C E82D      JR       TEST_LOCK

```

```

!*****
*
* NORM_SCRIBE: SCRIBES MEMORY IN THE
* NORMAL MODE USING SYSTEM CALL
* INSTRUCTION FOR BUS LOCKS AND
* MODE CHANGES. THIS CODE SECTION
* WILL BE EXECUTED FROM A COMMON
* (NORMAL/SYSTEM) AREA OF MEMORY.
*
*****

```

NORM_SCRIBE:

```

004F 2104      LD      R4,#%1000
0050 1000
0052 7D4A      LDCTL   FCW,R4      ! CHG TO NORMAL MODE !
0054 2171      LD      R1,#%AA55    ! NORMAL R/W PATTERN !
0056 AA55
0058 2104      LD      R4,#%F800    ! TOP BLOCK ADDR !
005A F800
005C 8D98      CLR     R9

```

!***** CLEAR MEMORY NORMAL MODE ***** !

```

DO
005E 6F41      LD      NORM_RW_PAT(R4),R1
0060 0004
0062 6F49      LD      NORM_CPU_CNT(R4),R9      ! CLEAR CPU_CNT !
0064 0006
0066 0374      SUB     R4,#%0800
0068 0800
006A F8F9      OD

```

! WAIT FOR OTHER CPU'S TO COMPLETE TASK !
WAIT3:

```

006C 2103      LD      R3,#%1000
006F 1000
0070 7D3A      LDCTL   FCW,R3
0072 2103      LD      R3,#50
0074 0032
DO
0076 1904      MULT    RR4,#1
0078 0001
007A 1B30      DFC     R3
007C E601      JP      Z,SCBE
007F F8FB      OD

```

!***** SCRIBE IN NORMAL MODE *****!

SCBE:

```

0080 2104      LD      R4,#%F800

```

```

0082 F600
                                DO
0084 6148      LD      R8,NORM_RW_PAT(R4)
0086 0004
0088 9B18      CP      R8,R1      ! CK FOR R/W !
008A FE07      JP      NZ,NO_RW    ! NO R/W !

' CPU IDENTIFIES ACCESS TO THIS BLOCK !
008C 7F01      SC      #1          ! LOCK MULTIBUS !
008E 6148      LD      R8,NORM_CPU_CNT(R4)      ! GET CPU_NUM !
0090 0006
0092 1987      INC     R8,#1        ! INCREMENT !
0094 6F48      LD      NORM_CPU_CNT(R4),R8
0096 0006
0098 7F02      SC      #2          ! UNLOCK MULTIBUS !

NO_RW:
009A 8BD4      CP      R4,R13      ! CK FOR LAST BLK !
009C E603      JR      Z,TERMN      ! FINISHED !
009E 0304      SUB     R4,#0000
00A0 0000
00A2 F6F0      CD

TERMN:
00A4 7F03      SC      #3          ! CHG TO SYSTEM MODE !

GSB:
00A6 9E08      RET

!*****
*
*   TEST_LOCK: ROUTINE TO GAIN ACCESS
*   TO CONFIG_TABLE.
*
*   REG USE: INPUT  R7 = LOW GLOBAL MEM
*
!*****!
TEST_LOCK:
00A8 7678      LDA     R8,TABLE_LOCK(R7) ! LOCK ADR !
00AA 0008

! MAIN LOCK TESTING LOOP !
DO
00AC DF8F      CALR    TEST_N_SET      ! ACCESS CONFIG_TABLE !
00AE FD03      JR      PL,TBL_ACCESS ! GOT EXCLU. ACCESS !

! DELAY BEFORE NEXT ATTEMPT !
00B0 1904      MULT    RR4,#1
00B2 0001
00B4 F6F0      OD

```

```

!*****
*
*   TEL_ACCESS: ROUTINE TO DETERMINE
*   DIRECTOR_CPU AND MEMBER_CPU'S.
*
*****!

TEL_ACCESS:
00B6 7673   LDA      R3,CPU_CNT(R7)
00B8 200A
00BA 213E   LD       R14,R3
00BC 8B4E   CP       R14,R4      ! CK IF OWN CPU NO. !
00BE F604   JR       Z,OWN_ID
00C0 4D75   LD       TABLE_LOCK(R7),#0
00C2 0000
00C4 0000
00C6 8B40   JR       TEST_LOCK

OWN_ID:
00C8 0F0E   CP       R14,#0      ! CHECK IF LOG_CPU 0? !
00CA 0000

00CC F601   JR       Z,BOOTLOAD_CPU ! YES !
00CE FB11   JR       MEMBER_CPU   ! NO !

! *****  BOOTLOAD_CPU  START  ***** !

!*****
*
*   BOOTLOAD_CPU: CPU ASSUMES ROLE AS
*   INITIALIZATION COORDINATOR.
*   CPU DETERMINES NUMBER OF CPU
*   IN SYSTEM AND INITIALIZES THE
*   CONFIG_TABLE ACCORDINGLY. IT
*   THEN IDENTIFIES ITSELF AND
*   WAITS FOR MEMBER CPU'S TO
*   IDENTIFY THEMSELVES; AND THEN
*   CONSOLIDATES CONFIG TABLE DATA
*   INTO SYSTEM TABLE (MIN_CONFIG_
*   TEL).
*
*   REG USE: INPUT  R5 = NUMBER CPU'S
*                   R6 = LOW LOCAL MEM
*                   R7 = LOW GLOBAL MEM
*                   R4 = LOG_CPU NO.
*
*****!

BOOTLOAD_CPU:
! LOAD CPU_CNT WITH NEXT LOG_CPU NUMBER !
20D0 4D75   LD       CPU_CNT(R7),#1      ! LOAD LOG_CPU 1 !

```

00D2 007A
00D4 0001

! COMPLETE OWN CONFIG_TABLE ENTRY !
00D6 7673 LDA R3,CPU_LIST(R7) ! LOG_CPU 2 !
00DE 000C
00DA 763E LDA R14,MEM_MAP(R3)
00DC 760A
00DE DF62 CAL MAP_MEMORY ! ENTER MEM MAP !

! UNLOCK CONFIG_TABLE !
00E0 7673 LDA R8,TABLE_LOCK(R7) ! LOCK ADR !
00E2 0008
00F4 0D85 LD GR8,#0 ! CLEAR LOCK !
00E6 0000

! WAIT FOR ALL CPU'S TO IDENTIFY THEMSELVES !
00E8 7678 LDA R8,CPU_CNT(R7) ! CPU_CNT ADR !
00EA 000A
00EC A159 LD R9,R5 ! GET TOTAL PHYS CPU !
00EE DF02 CALR WAIT_COMP ! WAIT FOR ALL !
00F0 F83A JR COMBIN

! ***** MEMBER CPU START ***** !
!*****
*
* MEMBER_CPU: IDENTIFIES ITSELF IN *
* CONFIG_TABLE AND ENTERS MEM *
* MAP. WAITS FOR DIRECTOR_CPU *
* TO SIGNAL TO CONTINUE. *
*
* REG USE: INPUT R4 = LOG_CPU NO. *
*
*****!

MEMBER_CPU:
00F2 A14E LD R14,R4 ! SAVE LOG_CPU NO. !
00F4 767A LDA R10,CPU_LIST(R7) ! BASE OF ENTRY !
00F6 000C
00F8 8D2E CLR R2
DO
00FA 0102 ADD R2,#74 ! DETERMINE BASE OF !
00FC 004A
00FF AB70 DEC R14 ! ENTRY !
0100 F601 JR Z,CONT
0102 B8FB OD

CONT:
0104 812A ADD R10,P2 ! COMPUTE BASE ADR !
0106 A1A3 LD R3,R10

```

! ENTER MEM_MAP IN TABLE ENTRY !
0108 76AE      LDA      R14, MEM_MAP(R10) ! MEM_MAP BASE !
010A 007A
010C DF79      CALL     MAP_MEMORY

! LOAD CPU_CNT WITH NEXT LOG_CPU NUMBER !
010E 7679      LDA      R8, CPU_CNT(R7)
0110 007A
0112 2189      LD       R9, GR8          ! CPU COUNT !
0114 A990      INC      R9              ! ADD ONE, !
0116 2F89      LD       GR8, R9         ! AND PUT BACK !

! UNLOCK CONF_TABLE FOR OTHER PROCESSORS !
0118 7678      LDA      R8, TABLE_LOCK(R7)
011A 0078
011C 0D85      LD       GR8, #0        ! CLEAR LOCK !
011E 0000

! WAIT FOR SIGNAL TO PROCEED WITH BOOTLOAD !
0120 76A8      LDA      R8, SIGNAL(R10) ! OWN SIGNAL ADR !
0122 0000

DO
0124 2182      LD       R2, GR8          ! TEST SIGNAL !
0126 0B02      CP       R2, #1
0128 0001
012A E601      JR       Z, DWN_LD
012C E8FB      OD

DWN_LD:
! DOWN-LOAD PLOC LOCAL INTO LOCAL MEMORY !
012E 76A1      LDA      R1, MSG_BLK(R10) ! OWN MSG_BLK !
0130 0004
0132 2112      LD       R2, GR1          ! CURRENT CODE ADR !
0134 3113      LD       R3, R1(#2)      ! LOCAL LOAD ADR !
0136 0002
0138 311E      LD       R14, R1(#4)     ! NUMBER OF BYTES !
013A 0004

013C BA21      LDIRB    GR3, GR2, R14   ! MOVE CODE !
013E 0F30

! CLEAR SIGNAL !
0140 0D85      LD       GR8, #0
0142 0000

! SIGNAL DIRECTOR_CPU THAT THIS CPU DONE !
0144 FED9      CALL     TEST_V_SET      ! ACCESS TO !
! CONFIG_TABLE !
0146 767E      LDA      R14, CPU_CNT(R7)
0148 000A

```

```

214A 2139      LD      R9,QR14      ! LOG_CPU NUMBER !
214C A990      INC     R9
214E 2FE9      LD      QR14,R9      ! INCREMENT !

2150 767E      LDA     R14,TABLE_LOCK R7)
2152 0778
2154 0DF5      LD      QR14,#0      ! CLEAR LOCK !
2156 0000

! WAIT FOR SIGNAL TO TRANSFER CONTROL !
DO
2158 2182      LD      R2,QR8      ! TEST SIGNAL !
215A 0B02      CP      R2,#1
215C 0001
215E F601      JR      Z,TRN_CNTL
2160 E8FB      OD

TRN_CNTL:
! TRANSFER CONTROL TO C/S !
2162 2112      LD      R2,QR1      ! OWN MSG_BLK !
2164 1E28      JP      QR2          ! START OF C/S !

! ***** END OF MEMBER_CPU ***** !

!*****
*
*      GLOBAL INITIALIZATION STAGE      *
*
*****!

COMBIN:

!*****
*      CONSOLIDATE CPU_ENTRY'S INTO TABLE      *
*****!

! CONSOLIDATE LOG_CPU TO PHYS_ID IN TABLE !
2166 A171      LD      R1,R7
2168 7671      LDA     R1,CPU_LIST(R7) ! TABLE ENTRY BASE !
216A 000C
216C A159      LD      R9,R5
DO
216E 0101      ADD     R1,#74      ! ADR OF NEXT ENTRY !
2170 004A
2172 1B90      DEC     R9
2174 E601      JR      Z,HAVE_ADR
2176 E8FB      OD
HAVE_ADR:
! ADDRESS !
2178 7679      LDA     R9,CPU_LIST(R7) ! GET START OF !

```



```

017A 0000
017C 7692      LDA      R2,CPU_ID(R9)      ! CPU_ENTRY'S !
017E 0002
0180 A154      LD       R4,R5

DO
0182 212D      LD       R13,R2          ! STORE PHYS_ID !
0184 2F1D      LD       R1,R13
0186 A911      INC      R1,#2
0188 0102      ADD      R2,#74
018A 004A
018C AB40      DEC      R4
018E 0B04      CP       R4,#0          ! CK IF FINISHED !
0190 0000
0192 E601      JR       Z,MEM_CONSOL
0194 E8F6      OD

! CONSOLIDATE MEM_MAP'S INTO MIN_CONFIG_TBL !
MEM_CONSOL:
0196 2104      LD       R4,#32
0198 0020
019A 7679      LDA      R9,CPU_LIST(R7)
019C 000C
019E 7692      LDA      R2,MEM_MAP(R9) ! LOG_CPU 0 !
01A0 000A

DO
01A2 212D      LD       R13,R2          ! COPY LOG_CPU 0 VALUES !
01A4 2F1D      LD       R1,R13
01A6 A911      INC      R1,#2
01A8 A921      INC      R2,#2
01AA AB40      DEC      R4
01AC E601      JR       Z,NXT_CPU ! GET NEXT LOG_CPU !
01AE E8F9      OD

NXT_CPU:
! MAIN LOOP FOR CONSOLIDATION OF REMAINING MAPS !
01B0 A15B      LD       R11,R5
01B2 ABB0      DEC      R11,#1
01B4 F619      JR       Z,LL          ! NO MORE MAPS TO DO !

DO
01B6 210D      LD       R13,#32
01B8 0020
01BA A129      LD       R9,R2
01BC 7692      LDA      R2,MEM_MAP(R9) ! NEXT LOG_CPU !
01BE 000A
01C0 0301      SUB      R1,#64 ! ADR NEW TBL MEM_MAP !
01C2 0040

```

```

DO
01C4 2123      LD      R3,GR2      ! NEW VALUES !
01C6 2114      LD      R4,GR1      ! ORIG VALUE !
01C8 8A34      CPB      RH4,RH3     ! COMPARE !
01CA FF21      JR       NC,COMP_LOW
01CC A034      LDB      RH4,RH3     ! SAVE NEW VALUE !
COMP_LOW:
01CF 8ABC      CPB      RL4,RL3
01D0 FF01      JR       NC,AGAIN
01D2 A0BC      LDB      RL4,RL3     ! SAVE NEW VALUE !
AGAIN:
01D4 2F14      LD      GR1,R4      ! SAVE MAP BLOCK !
01D6 A911      INC      R1,#2
01D8 A921      INC      R2,#2
01DA ABD0      DEC      R13
01DC F601      JR       Z,OVR       ! GET NEXT MEM_MAP!
01DF F8F2      OD

```

```

OVR:
01E0 ABB0      DEC      R11,#1
01E2 F601      JR       Z,LL       ! FINISHED !
01E4 F8E8      OD

```

```

!*****
*
*      OPERATING SYSTEM CORE IMAGE
*      LOAD STAGE
*
!*****

```

```

LL:
! SUPERVISE PROC_LOCAL LOADING !
01E6 3404      LDAR     R4,PROC_LOCAL ! LOAD KERNEL !
01E8 01BE
01EA DF6F      CALP     COORD_DWN_LD

! SAVE ENTRY ADDRESS TO KERNEL !
01EC 61E4      LD      R4,DWN_ADR(R14)
01EE 0316
01F0 6FE4      LD      START_ADR(R14),R4
01F2 0318

! LOAD PROC_GLOBAL OF O/S !
01F4 3404      LPAR     R4,PROC_GLOBAL ! LOAD SUPERVISOR !
01F6 01BF
01F8 DF76      CALP     COORD_DWN_LD

```

```

01FA 6100      ! SIGNAL ALL CPU TO TRANSFER CONTROL TO O/S !
                LD      R0,START_ADR
01FC 0318
01FE 6174      LD      R4,CPU_LIST(R7)  ! LIST BASE ADR !
0200 000C
0202 A153      LD      R3,P5              ! NO. CPU'S !
                DO
0204 6F40      LD      MSG_BLK(R4),R0    ! STORE START ADR !
0206 0004
0208 AB30      DFC     R3
020A E603      JR      Z,END_SIG
020C 0104      ADD     P4,#74            ! NEXT CPU ENTRY !
020E 004A
0210 E8F9      OD
END_SIG:
0212 DF52      CALR    SIGNAL_CPU
0214 2174      LD      R4,#0            ! SAVE LOG_CPU NO. !
0216 7000

! TRANSFER CONTROL TO START OF CODE !
0218 A102      LD      R2,R0
021A 1E28      JP      GR2

! ***** END DIRECTOR_CPU ***** !

021C          END BOOTSTRAP

021C          MAP MEMORY PROCEDURE
!*****
*
*   MAP_MEMORY: MAPS CPU MEMORY ACCESS
*   BY DOMAIN, AS TO LOCAL (1),
*   GLOBAL (2), DUAL_USE (3),
*   NON_USE (4), NON_ACCESS (5).
*
*   REG USE: INPUT  R14 = ADR MEM_MAP
*
*****!
ENTRY
! MOVE CODE TO LOCAL, NORMAL MEMORY AREA !
021C 2101      LD      R1,#34100        ! NEW LOCATION !
021E 4100
0220 3404      LDAR    R4,NORM_MAP      ! START OF CODE !
0222 0034
0224 3402      LDAR    R2,NORM_RTN      ! END OF CODE !
0226 0084

DO
0228 2149      LD      R9,GR4          ! MOVE CODE !

```

```

0221 2F19      LD      QF1,F9
0222 8B42      CP      R2,R4      ! CK FOR END !
0223 F603      JR      Z,BEGIN_MAP
0230 A911      INC     R1,#2
0232 A941      INC     R4,#2
0234 F8F9      OD

      ! BEGIN MAPPING NORMAL MODE MEM ACCESS !
BEGIN_MAP:
0236 1D04      LD      R4,R13      ! LOW BLK ACCESS !
0238 A1F1      LD      R1,R14
      DO
023A 8D44      TEST     R4
023C E604      JR      Z,FND_BLK
023E 0304      SUB      R4,#%0800
0240 0800
0242 A911      INC     R1,#2
0244 F8FA      OD
FND_BLK:
0246 A11E      LD      R14,R1
0248 A1D4      LD      R4,R13
      ! R1 = MAP END BLK.  R4 = ADR !
024A 2109      LD      R9,#%F804
024C F804
024E A943      INC     R4,#4

      ! MAP AND ENTER FROM NORMAL MODE !
0250 2108      LD      R8,#%4100
0252 4100
0254 1F80      CALL     QR8
0256 9E08      RET

0258      END MAP_MEMORY

0259      NORM MAP PROCEDURE
      !*****
      *
      *   NORM_MAP: MAPS MEMORY ACCESS IN THE *
      *   NORMAL MODE INTO CONFIG_TABLE *
      *   FOR CPU. *
      *
      * REG USE: INPUT  R1 = MEM_MAP ADR *
      *                  R4 = MEM_ADR *
      *                  R9 = STOP ADR *
      *
      !*****!
      ENTRY
0258 2102      LD      R2,#%AA55      ! NEW R/W PATTERN !
025A 1A55
025C 2110      LD      R0,QR1

```

```

025F 2104      DC      LD      R10, #X1F00
0260 1000
0262 7DAA      LDCTL  FCW, R10      ! CHG TO NORMAL MODE !

0264 2143      LD      R3, QP4
0266 8B23      CP      R3, R2      ! TEST FOR R/W !
0268 FE17      JR      NZ, NC_ACCESS ! NO R/W/ !
026A 1143      LD      R3, P4
026C A931      INC     R3, #2      ! CK FOR LOCAL !
026E 213B      LD      R11, QR3
0270 0B0B      CP      R11, #1    ! CPU_NUM = 1? !
0272 0001
0274 EF0B      JR      NZ, GLOB_ACC

! LOCAL ACCESS !
0276 1143      LD      R3, R4
0278 0303      SUB     R3, #4      ! CK FOR SYS MODE R/W !
027A 0004
027C 213B      LD      R11, QR3   ! GET PATTERN !
027E 0B01      CP      R1, #X55AA
0280 55AA
0282 F602      JR      Z, DUAL_MODE
0284 C901      LDB     RL0, #X01    ! ENTER LOCAL ID !
0286 F809      JR      CYCLE

DUAL_MODE:
0288 C903      LDB     RL0, #X03    ! ACCESS BY V/S MODES !
028A F807      JR      CYCLE

GLOB_ACC:
028C 8B5B      CP      R11, R5     ! CK FOR GLOBAL !
028E FF02      JR      NZ, NON_USE
0290 C802      LDB     RL0, #X02    ! ENTER GLOBAL ID !
0292 F803      JR      CYCLE

NON_USE:
0294 C804      LDB     RL0, #X04    ! ENTER NON_USE ID !
0296 F901      JR      CYCLE

NO_ACCESS:
0298 C805      LDB     RL0, #X05    ! ENTER NON_ACCESS ID !

CYCLE:
029A 7F03      SC      #3          ! CHG TO SYSTEM MODE !
029C 2F10      LD      QR1, R0
029E 8B94      CP      R4, R9      ! CK FOR COMPLETION !
02A0 F605      JR      Z, NORM_RTN
02A2 0104      ADD     R4, #X0800   ! NEXT MEM BLOCK !

```

```

02A4 0000
02A6 0911      INC    R1,#2
02A8 2110      LD      R0,R1      ! NEXT MAP BLOCK !

02AA EBD9      OD

02AC 9E08      NORM_RTN:
                    RFT

02AF          END NORM_MAP

02AE          SYSTEM CALL PROCEDURE
!*****
*
*   SYSTEM CALL: AFFECTS PRIVILEGED
*   INSTRUCTION EXECUTION IN THE
*   NORMAL MODE.
*
*           1 = BUS LOCK
*           2 = BUS UNLOCK
*           3 = CHG FCW
*
*****!
ENTRY
02AE 93F0      PUSH    R15,R0      ! SAVE WORK REG !
02B0 31F0      LD      R0,R15(#2) ! GET INSTRUCTION !
02B2 0002
02B4 8C08      CLRB    R0          ! GET EXECUT. CODE !
02B6 0B00      CP      R0,#1      ! CK FOR BUS LOCK !
02B8 0071
02BA FE04      JR      NZ,CK2
02BC 3B26      OUT     BUS_LOCK,R2 ! LOCK MULTIBUS !
02BE FFF9
02C0 97F0      POP     R0,R15      ! RESTORE WORK REG !
02C2 7B00      IRET

CK2:
02C4 0E00      CP      R0,#2      ! CK FOR UNLOCK BUS !
02C6 0002
02C8 FE04      JR      NZ,CK3
02CA 3B26      OUT     BUS_UNLOCK,R2 ! UNLOCK MULTIBUS !
02CC FFF8
02CE 97F0      POP     R0,R15      ! RESTORE WORK REG !
02D0 7E00      IRET

CK3:
02D2 0B00      CP      R0,#3      ! CK FOR MODE CHG !
02D4 0003
02D6 FE08      JR      NZ,NONE
02D8 93FB      PUSH    R15,R11
02DA 210B      LD      R11,#%5000

```

```

02DC 5000
02DF 33FB      LD      R15(#6),R11
02E0 0006
02E2 97FB      POP     R11,GR15
02E4 97F0      POP     R0,GR15      ! RESTORE WORK REG !
02E6 7F00      IRET

      NONE:
02E8 97FF      POP     R0,GR15      ! RESTORE WORK REG !
02EA 7B00      IRET

02EC          END SYSTEM_CALL

02EC          WAIT_COMP_PROCEDURE
!*****
*
*   WAIT_COMP: WAIT FOR SPECIFIED MEM
*   LOCATION (R8) TO CONTAIN THE
*   SPECIFIED VALUE (R9) BEFORE
*   RETURN.
*
*   REG USE: INPUT  R8 = ADDR
*               R9 = VALUE
*
*****!
ENTRY
DO
02EC 218D      LD      R13,GR8      ! GET VALUE !
02EE 8B9D      CP      R13,R9      ! CK FOR MATCH !
02F0 F603      JR      Z,GOT_SIG
02F2 1904      MULT    RR4,#1      ! DELAY !
02F4 0001
02F6 F8FA      OD

      GOT_SIG:
02F8 7D85      LD      GR8,#0      ! CLR MSG BLK !
02FA 0000
02FC 9E08      RET

02FE          END WAIT_COMP

```

```

GLOBAL
CPU WAIT PROCEDURE
*****
*
* CPU WAITS APPROX. 2MSEC FOR ALL
* CPU'S TO COMPLETE THE SAME TASK
* BEFORE CONTINUING.
*
*****!

ENTRY
02FF 2103      LD      R3,#50
0300 0032      DO
0302 1904      MULT    RR4,#1
0304 0001
0306 0B30      DEC     P3
0308 F601      JR      Z,RETRN
030A F8FB      OD
RETRN:
030C 9E08      RET
030E          END CPU_WAIT

030E          COORD DWN LD PROCEDURE
*****
*
* LOAD LOCAL: LOADS PROCESSOR LOCAL
* PORTION OF O/S INTO GLOBAL MEM
* AND SUPERVISES LOADING BY ALL
* CPU'S. SETS DOWN-LOAD INST. IN
* MSG_BLK OF EACH CPU.
*
*****!

ENTRY
030E A173      LD      R3,R7
0310 0103      ADD     R3,#0800      ! GLOBAL LOAD ADR !
0312 0800

0314 8088      CLR     P8          ! RESET BYTE COUNT !

! RESTORE PREVIOUS DATA AREA !
0316 7D15      LDCTL   R1,PSAPOFF
0318 611E      LD      R14,DATA_AREA(R1)
031A 0000

! LOAD FILE FROM MC2 !
031C 5FC0      CALL    LOAD_FILE(R12)
031E 0000*

! SET DOWN-LOAD INSTRUCTIONS FOR OTHER CPU !
0320 A173      LD      R3,R7

```



```

0322 0103    ADD      R3,#0800    ! GLOBAL LOAD ADR !
0324 0800
0326 7671    LDA      R1,CPU_LIST(R7)    ! BASE OF !
0328 0000
                                ! TABLE ENTRIES !
032A 7612    LDA      R2,MSG_BLK(R1) ! MSG_BLK LOG_CPU 2 !
032C 0004
032E 61E4    LD       R4,DWN_ADR(R14) ! PROC_LOAD DOWN- !
0330 0316
                                ! LOAD ADDRESS !
                                ! R8 = SIZE !
0332 A156    LD       R6,R5          ! TOTAL NO. CPU !
                                DO
0334 2F23    LD       R2,R3    ! LOAD GLOBAL ADR MSG1 !
0336 3324    LD       R2(#2),R4 ! LOCAL ADR MSG2 !
0338 0002
033A 3328    LD       R2(#4),R8 ! SIZE OF CODE MSG3 !
033C 0004
033E AF60    DEC      R6
0340 E603    JR       Z,DO_SELF
0342 0102    ADD      R2,#74    ! ADR NEXT LOG_CPU MSG_BLK !
0344 004A
0346 F8F6    CD
                                DO SELF:
                                ! LOAD PROCEDURE LOCAL CODE INTO OWN LOCAL MEM !
0348 7671    LDA      R1,CPU_LIST(R7)
034A 000C
034C 7612    LDA      R2,MSG_BLK(R1) ! OWN MSG_BLK ADR !
034E 0004
0350 2121    LD       R1,R2    ! SOURCE ADDRESS !
0352 3123    LD       R3,R2(#2) ! DESTINATION ADR !
0354 0002
0356 3124    LD       R4,R2(#4) ! NUMBER BYTES !
0358 0004
035A 2A11    LDIRB    R3,R1,R4    ! DOWN-LOAD CODE !
035C 0430
                                ! SET CONFIG_TABLE CPU_CNT TO LOG_CPU 1 !
035E 4F75    LD       CPU_CNT(R7),#1
0360 0001
0362 0001
                                ! SIGNAL ALL CPU TO PROCEED WITH DOWN-LOAD !
0364 DFFB    CALL     SIGNAL_CPU
                                ! WAIT FOR ALL CPU TO COMPLETE !
0366 7678    LDA      R8,CPU_CNT(R7)

```

```

036B 0001
036A A159 LD R9,R5 ! NUMBER CPU !
036C D041 CALL WAIT_COMP ! WAIT FOR COMPLETION !

036F 9E08 RET ! RETURN TO DIRECTOR_CPU !

0370 END COORD_IWN_LD

0371 SIGNAL_CPU PROCEDURE
*****
*
* SIGNAL_CPU: PLACES SIGNAL (#1) IN
* SIGNAL BLOCK FOR EACH CPU EN-
* TRY IN CONFIG_TABLE.
*
*****!
ENTRY
! SIGNAL ALL CPU TO DOWN-LOAD !
0370 7673 LDA R3,CPU_LIST(R7)
0372 0000
0374 0103 ADD R3,#74 ! LOG_CPU 1 ENTRY !
0376 004A
0378 A154 LD R4,R5 ! TOTAL NO. CPU !
037A AB40 DEC P4
037C E608 JR Z,ALL_SIG

DO
037E 4D35 LD SIGNAL(R3),#1 ! LOAD SIGNAL !
0380 0000
0382 0001
0384 AB40 DEC P4
0386 E603 JR Z,ALL_SIG
0388 0103 ADD R3,#74 ! NEXT LOG_CPU ADDR !
038A 004A
038C E9F8 CD

ALL_SIG:
038F 9E08 RET

0390 END SIGNAL_CPU

```

```

2390 TEST_N_SET PROCEDURE
!*****
*
* TEST_N_SET: ROUTINE UTILIZING HDWP
* TSET INSTRUCTION AND
* BUS LOCKING ABILITY TO
* AFFECT MUTUAL EXCLUSION
* ON ACCESS TO COMMON
* DATA STRUCTURES LOCK.
*
* REG USE: INPUT R8 = ADR OF LOCK
*
*****!
ENTRY
0390 3B26 OUT BUS_LOCK,R2 ! LOCK SYSTEM BUS !
0392 FFF9
0394 0D86 TSET QRB ! TEST TABLE LOCK !
0396 3B26 OUT BUS_UNLOCK,R2 ! UNLOCK SYSTEM BUS !
0398 FFF8
039A 9E08 RET
039C END TEST_N_SET

GLOBAL
239C MEM_INT PROCEDURE
!*****
*
* MEM_INT: INTERRUPT HANDLER FOR AN
* ILLEGAL LOCAL MEMORY
* ACCESS IN THE NORMAL MODE
* SAVES MEMORY ADDRESS OF
* NEXT BLOCK.
*
* REG USE: INPUT R3 = RTN POINT
* R4 = FAULT ADR
*
*****!
ENTRY
039C 0104 ADD R4,%0800 ! RESTORE BLOCK ADR !
039E 0800
03A0 A14C LD R13,R4 ! SAVE ADR !
03A2 010F ADD R15,#6 ! RESTORE STACK !
03A4 0006
03A6 1E38 JP QRB ! RTN TO SYS CODE !
03A8 END MEM_INT

PROC_LOCAL:
03AB 0D BVAL %0D
03AD 4C4F WVAL 'LO'
03AC 4144 WVAL 'AD'
03AE 204B WVAL 'K'

```

03B0	4552	WVAL	'ER'
03B2	4F15	WVAL	'NE'
03B4	4C20	WVAL	'L'
03B6	20	BVAL	

PROC GLOEAL:

03B7	11	BVAL	%11
03B8	4C4F	WVAL	'LO'
03BA	4144	WVAL	'AD'
03BC	2053	WVAL	'S'
03BE	5550	WVAL	'UP'
03C0	4552	WVAL	'ER'
03C2	5649	WVAL	'VI'
03C4	534F	WVAL	'SO'
03C6	5220	WVAL	'R'
03C8	20	BVAL	

END BOOTSTRP

2. SUPPORT1 MODULE (same as Appendix C)

3. SUPPORT2 MODULE (same as Appendix C)

4. SUPPORT3A MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 SUPPORT3A MODULE
\$LISTON \$TTY

```
!*****
*
* SUPPORT3A MODULE: MODULE THREE FOR
* SECONDARY STORAGE PRIMITIVES
* FUNCTIONS SUPPORT. STRICTLY
* HARDWARE DEPENDENT; SHOULD
* MEET STORAGE DEVICE REQUIRE-
* MENTS FOR INTERFACING.
*
* NOTE: DUPLICATE OF MONITOR LOAD_CMD
* MODULE.
*
*****!
```

CONSTANT

```
RXR      := 2
TXR      := 0
PAR      := 7
PORTAD   := %FFD9
PORTBD   := %FFE1
PORTAC   := %FFDB
PORTEC   := %FFE3
```

```
IDPORT   := %FFCB
ICPORT   := %FFC9
```

```
TCMD     := %FFD2
TDTA     := %FFD0
```

```
BUS_LOCK := %FFF9
BUS_UNLOCK := %FFF8
VINTR     := %(2)0001000000000000
VIBIT     := 12
```

```

ESCAPE      := %1B
BS          := %08
LINDL       := %7F
CR          := %0D
LF          := %0A
TXOFCH      := %13
TXONCH      := %11
INSIZ       := 128      ! INTBUF SIZE !
OUTSIZ      := 128      ! OUTBUF SIZE !
RBSIZ       := 256      ! RING BUFFER SIZE !
! BIT POSITIONS IN MONITOR FLAG WORD !
TRPMDE      := 0
ISTOP       := 1
OSTOP       := 2
SNDMDE      := 3
LDMDE       := 4
ESC         := 5
TXMSK       := %6

```

EXTERNAL	PRNTBF	PROCEDURE
EXTERNAL	GETNXT	PROCEDURE
EXTERNAL	ERROR	LABEL
EXTERNAL	SNDCHR	PROCEDURE
EXTERNAL	GETADR	PROCEDURE
EXTERNAL	GMCZAD	PROCEDURE
EXTERNAL	SNDMCZ	PROCEDURE
EXTERNAL	CONVERT	PROCEDURE
EXTERNAL	PBUFNC	LABEL
EXTERNAL	SNDMSG	PROCEDURE
EXTERNAL	CCNVW	PROCEDURE

```

INTERNAL
$SECTION DATA_DEC
$ABS 0

```

0000	INTBUF	ARRAY	[128 BYTE]
0080	OUTBUF	ARRAY	[128 BYTE]
0100	RNGBUF	ARRAY	[256 BYTE]
0200	MCZBUF	ARRAY	[256 BYTE]
0300	BUFADR	WORD	
0302	BUFSIZ	WORD	
0304	INTPTR	WORD	
0306	OUTPTR	WORD	
0308	NXTPTR	WORD	
030A	GETOUT	WORD	
030C	MCZPUT	WORD	
030E	MCZGET	WORD	
0310	MFLAGS	WORD	
0312	RETRY	WORD	
0314	ADR_STR	WORD	

```

0316      DWN_ADR  WORD
0318      START_ADR WORD

```

```

$SECTION LOAD_PROG
$REL 0

```

```

0000      GLOBAL
          FNAME PROCEDURE
          !*****
          *
          *      FNAME: RESETS TWO PTRS TO MCZBUF
          *      AND CHECKS FOR FILENAME.
          *
          !*****

```

ENTRY

```

0000 4DF8      CLR      MCZGET(R14)
0002 030E
0004 4DF8      CLR      MCZPUT(R14)      ! RESET BUFFER !
0006 030C
0008 34CA      LDA      R10,R12(#GETNXT)
000A 0000*
000C 1FA0      CALL     GF10      ! SKIP CMD ARG !
000E 0A08      CPB      R10,#'A'
0010 4141
0012 E711      JR       C,DUN
0014 0A08      CPB      R10,#'Z'+1
0016 5B5B
0018 EF03      JR       NC,DUN      ! 1ST CHR IN (A..Z) !
001A 76CA      LDA      R10,GETNXT(R12)
001C 0000*
001E 1FA0      CALL     GF10      ! SKIP TO NEXT ARG !
0020 E607      JR       Z,NO_ADR      ! NO NEXT ARG !
0022 76CA      LDA      R10,GETADR(R12)
0024 0000*
0026 1FA0      CALL     GR10      ! GET USER SPECIFIED !
                                ! ADDRESS !
0028 A13B      LD       R11,R3      ! SAVE USER ADR !
002A 6FE3      LD       ADR_STR(R14),R3
002C 0314
002E 9E08      RET

```

NO_ADR:

```

0030 210B      LD       R11,#%FFFE      ! SIGNAL TO USE MCZ !
0032 FFFF
                                ! ADDRESS !
0034 9E08      RET

```

DUN:

```

0036 9D9F      CLR      R9

```

```

0038 34CA      LDA      R12,R12(=ERROR)
003A 0000*
003C 1EAS      JP       GR12      ! ERROR, RTN TO EXEC !
003E      END FN'ME

```

```

003F      GLOBAL
      CMDPAS PROCEDURE

```

```

!*****
*
*  CMDPAS: LOAD CMD PASSING MECHANISM
*          SENDS 'B;' PLUS CONS CMD
*  LINE TO MCZ AND CKS RESPONSES FOR
*  GOOD Z80 PROGRAM LOAD.
*
*  REG USE:  RETURN      NZ IF Z80 LOADED
*              Z  IF NOT
*
*****!

```

ENTRY

```

003F 67E5      BIT      MFLAGS(R14),#ESC ! CK FOR ESCAPE !
0040 0310
0042 3602      JR       Z,GCMD
0044 8D41      SETFLG   Z
0046 9E08      RET

```

GCMD:

```

0048 C242      LDB      R2,#'B'
004A CA3B      LDB      R12,#';'
004C 6FE2      LD       OUTBUF(R14),R2      ! LOAD INIT 'B;' !
004E 0080

```

! FOR BRIEF MODE !

```

0050 76F2      LDA      R2,OUTBUF(R14)
0052 0080
0054 A921      INC      R2,#2
0056 76E1      LDA      R1,INTBUF(R14)
0058 0000
005A 2100      LD       R0,#%40      ! LD CMD IN OUTBUF !
005C 0040
005E BB11      LDIR     @R2,@R1.R0
0060 0020

```

```

0062 76F1      LDA      R1,OUTBUF(R14)
0064 0080
0066 0101      ADD      R1,#%80
0068 0080
006A 6FE1      LD       OUTPTR(R14),R1
006C 0306

```

```

006E DFB6      CALR     OUTSTM      ! OUTPUT BUFFER !
0070 DFE7      CALL     SKIPLN     ! SKIP MCZ ECHO !

```


0072	DFD4	CALR	MCZCOM	! WAIT RESPONSE !
0074	0109	CPE	RL1,#'B'	
0076	4242			
0078	EE02	JR	NZ,LDSTAT	
007A	DF3C	CALR	SKIPLN	! SKIP MCZ ECHO !
007C	DFD9	CALR	MCZCOM	! WAIT RESPONSE !

! VERIFY LOAD STATUS !
LDSTAT:

007E	0A09	CPE	RL1,#'9'	! TEST LEGAL !
0080	3939			
0082	E60E	JR	Z,REACK	! ACKNOWLEDGEMENTS !
0084	0A09	CPE	RL1,#'0'	
0086	3030			
0088	E60B	JR	Z,REACK	! REC GOOD ACK !
008A	0A09	CPE	RL1,#'7'	
008C	3737			
008E	E60B	JR	Z,REACK	

! NO ACKNOWLEDGEMENTS RECEIVED !

ERMSG:

0090	DFD9	CALR	RECMSG	! GET MCZ MSG !
0092	34CA	LDA	R10,R12(#SNDCHR)	
0094	0000*			
0096	1FA0	CALL	3R10	! SEND TO CONS !
0098	0A08	CPE	FL0,#LF	
009A	0A0A			
009C	9E06	RET	Z	! DONE !
009E	F8F8	JR	ERMSG	

! ACKNOWLEDGE RECEIVED !

REACK:

00A0	8D43	RESFLG	Z	! RETURN NZ !
00A2	9E08	RET		
00A4		END CMDPAS		

```

GLOBAL
SKPB LABEL
SKIPLN PROCEDURE
00A4
!*****
*
* SKIPLN: SKIP RECEIVED LINE FROM
* MCZ; RETURN FIRST CHAR OF
* NEXT LINE.
*
* REG USE: RETURN RL1 = 1ST CHR
* AND NZ IF ESC
*
*****!
ENTRY
00A4 DFF3 CALR RECMSG ! SKIP OVER LINE !
00A6 0A08 CPB RL0,#CR ! THRU CR,LF !
00A8 0D0D
00AA EFEC JR NZ,SKIPLN

SKPB:
00AC 2101 LD R1,#3000 ! DELAY FACTOR !
00AE 3000

! MAIN LOOP FOR RECEIVING CHAR !
LOOP1:
00B0 61E0 LD R0,MCZGET(R14)
00B2 030E
00B4 4BE0 CP R0,MCZPUT(P14) ! TEST FOR REC CHR !
00B6 030C
00B8 EE03 JR NZ,RECHR ! YES,..... !
00BA AB10 DEC R1,#1 ! NO, WAIT AWHILE !
00BC EEF9 JR NZ,LOOP1
00BE 9E06 RET Z ! FORCED EOL !

RECHR:
00C0 DFFB CALR MCZCOM
00C2 0A09 CPB RL1,#' ! CK 1ST=PRNT CHR !
00C4 2020
00C6 9E0D RET PL
00C8 DFF5 CALR RECMSG
00CA E8F0 JR SKPB
00CC
END SKIPLN

```

3000

MCZCOM PROCEDURE

```

!*****
*
* MCZCOM: LOOPS WAITING FOR RECEIVE
* CHAR FROM MCZ BY SEEING IF
* MCZBUF GETS CHAR. DOES
* ADVANCE POINTER.
*
* REG USE: RETURN  RL1 = CHR
*
*****!

```

ENTRY

```

00CC 61F0      LD      R0,MCZGET(R14)      ! CHECK MCZBUF !
00CE 030E      CP      R0,MCZPUT(R14)      ! POINTERS !
00D0 4BE0      JR      Z,MCZCOM            ! WAIT.....!
00D2 030C      LDA     R10,R12(#GMCZAD)
00D4 E6F0      CALL    GR10                ! GET CHAR FROM BUF !
00D6 34CA      LDB     RL1,GR2
00D8 0000*     RET
00DA 1FA0      CALL    GR10                ! GET CHAR FROM BUF !
00DC 2029      LDB     RL1,GR2
00DE 9E08      RET
00E0          END MCZCOM

```

00F0

RECMSG PROCEDURE

```

!*****
*
* RECMSG: LOOPS WAITING FOR REC CHR
* FROM MCZ. GETS CHAR AND
* DO NOT ADVANCE BUF PTR.
*
* REG USE: RETURNS  RL0 = CHR
*
*****!

```

ENTRY

```

00F0 61E0      LD      R0,MCZGET(R14)
00F2 030E      CP      R0,MCZPUT(R14)      ! CK FOR REC !
00F4 4BE0      JR      Z,RECMSG            ! WAIT.....!
00F6 030C      LDA     R10,R12(#GMCZAD)
00F8 E6F0      CALL    GR10                ! GET 1ST CHAR !
00FA 34CA      LDB     RL0,GR2              ! GETOPE PTR !
00FC 0000*     RET
00FE 1FA0      CALL    GR10                ! GET 1ST CHAR !
0100 6F10      LD      MCZGET(R14),R0      ! DESTOPE PTR !
0102 030E      CP      R0,MCZPUT(R14)
0104 2028      LDB     RL0,GR2              ! RTN CHAR !
0106 9E08      RET
010F          END RECMSG

```

```

GLOBAL
OUTSTM LABEL
OUTLNE PROCEDURE
2078 *****
*
* OUTLNE: OUTPUTS A LINE OF CHAR FROM
* OUTBUF TO MCZ WITH CR AT
* END.
*
* OUTSTM: OUTPUTS A LINE OF CHAR W/CR
*
*****!
ENTRY
00F8 6152 LD R2,OUTPTR(R14)
00FA 0306
00FC 0C25 LDB GR2,#CR !STORE CR IN BUF !
00FE 0D0D
0100 69E0 INC OUTPTR(R14),#1 ! INC PTR !
0102 0306

! NO CF ENTRY POINT !
OUTSTM:
0104 76F1 LDA R1,OUTBUF(R14)
0106 2080

! MAIN LOOP !
OVRAGN:
0108 2018 LDB RL0,GR1
010A A910 INC R1
010C 34CA LDA R10,R12( #SNDMCZ )
010E 0000*
0110 1FA0 CALL GR10 ! SND CHR TO MCZ !
0112 E603 JR Z,FINIS
0114 4BE1 CP R1,OUTPTR(R14)
0116 0306
0118 E7F7 JR C,OVRAGN ! CK IF BUF EMPTY !

! FINISHED, RESET OUTPTR(R14) AND BLANK OUTBUF !
FINIS:
011A 76E2 LDA R2,OUTBUF(R14) ! RESET POINTER !
011C 0080
011E 6FE2 LD OUTPTR(R14),R2
0120 0306
0122 2102 LD R0,#OUTSIZ/2
0124 0040
0126 AB00 DEC R0,#1 ! SET COUNT !
0128 4DF5 LD OUTBUF(R14),# ' ' ! LOAD COUNT !
012A 0080
012C 2020
012E 76F2 LDA R2,OUTBUF(R14)
0130 0080

```

```

2132 0121      LD      R1,R2
2134 A911      INC     R1,#2
2136 B821      LDI     @R1,@R2,P0      ! CLR BUFFER !
2138 0010
213A 9F08      RET
213C          END OUTLINE

          APORTM LABEL
          GODPAK LABEL
213C      BADPAK PROCEDURE
          !*****!
          *
          *   BADPAK: SENDS RESEND SIGNAL ('7')
          *           TO MCZ FOR BAD CKSUM OF REC
          *           NON-ASCII CHR.
          *
          *   ABORTM: SENDS ABORT SIGNAL ('9')
          *           WHEN USER SELECTED.
          *
          *   GODPAK: SENDS ACK SIGNAL ('0') FOR
          *           RECEIPT OF GOOD PACKET.
          *
          *
          !*****!
          ENTRY
213C 0837      LDB      RL0,#'7'      ! LD RESEND SIG !
213E F803      JR       OUTALL
          ABORTM:
2140 0839      LDB      RL0,#'9'      ! LD ABORT SIG !
2142 F801      JR       OUTALL
          GODPAK:
2144 0830      LDB      RL0,#'0'      ! LD REC OK SIG !
          OUTALL:
2146 6E38      LDB      OUTBUF(R14),RL0
2148 7780
214A 76ED      LDA      R13,OUTBUF(R14)
214C 2090
214E 19D0      INC     R13,#1
2150 6FED      LD       OUTPTR(R14),R13
2152 0306
2154 D02F      CALR     OUTLINE      ! SEND MCZ SYSTEM !
2156 D05A      CALR     SKIPLN      ! SKIP ECHO !
2158 9E08      RET
215A          END BADPAK

```

```

GLOBAL
215A GETACK PROCEDURE
!*****!
*
* GETACK: RECEIVE AND INTERPRET ACK *
* FROM MCZ. GOOD ACK = '2' *
* BAD ACK = '7' *
* ABORT = '9' *
*
* REG USE: RETURN Z,NC IF GOOD ACK *
* NZ,NC IF BAD ACK *
* NZ,C IF ABORT *
*
*****!
ENTRY
015A D048 CALR MCZCOM ! GET CHR !
015C 0A09 CPB RL1,#'0' ! CK FOR ACK !
015E 3030
0160 EE04 JR NZ,NACK ! NO.....!
0162 D060 CALR SKIPLN ! YES, REC ACK !
0164 8D41 SETFLG Z
0166 8D83 RESFLG C
0168 9E08 RET

! CK FOR '7' AND '9' NON-ACKNOWLEDGEMENTS !
NACK:
016A 0A09 CPB RL1,#'7' ! CK FOR RESEND !
016C 3737
016E EE04 JR NZ,ABRT ! NO....!
0170 D067 CALR SKIPLN
0172 8D43 RESFLG Z
0174 8D83 RESFLG C
0176 9E08 RET

! CHECK FOR ABORT !
ABRT:
0178 0A09 CPB RL1,#'9'
017A 3939
017C E602 JR Z,ENDIT ! YES, ABORT...!
017E D050 CALR RECMSG ! GET ANOTHER CHR !
0180 E8EC JR GETACK ! TRY AGAIN....!

ENDIT:
0182 D070 CALR SKIPLN
0184 8D43 RESFLG Z
0186 8D81 SETFLG C
0188 9E08 RET
018A END GETACK

```

018A

LINRCT PROCEDURE

```

*****
*
*   LINRCT: RECEIVES LINE OF CHAR FROM *
*           MCZ AFTER RECEIPT OF '//, *
*           AND STORES IN INTBUF, ADDING *
*           CR AT END AND FILTERING OUT *
*           CONTROL CHARACTERS. (<20H) *
*           (TRUNCATES AFTER 80 CHAR) *
*
*****!

```

ENTRY

! WAIT FOR ASCII / !

```

018A D056      CALR      RECMSG
018C 0A08      CPB       RL0,#'/'
019E 2F2F
0190 EFEC      JR        NZ,LINRCT      ! WAIT !
! BEGIN STORING CHARACTERS !
0192 76F4      LDA       R4,INTBUF(R14)
0194 0000
0196 CB50      LDB       RL3,#80      !SET LINE LENGTH !
! STORE CHAR IN INTBUF !
LOPSTR:
0198 D25D      CALR      RECMSG      ! GET CHAR !
019A 2E48      LDB       R4,RL0      ! STORE !
019C 0A08      CPB       RL0,#CR      ! CK FOR END !
019E 0D0D
01A0 FE02      JR        NZ,SKPSOM     ! GOT CHAR.. !
01A2 D07C      CALR      SKPB
01A4 9E09      RET

```

!CONTROL CHAR FILTERED AND DEC LINE COUNTER !

SKPSOM:

```

01A6 0A08      CPB       RL0,#' '
01A8 2020
01AA E7F6      JR        C,LOPSTR
01AC A940      INC       R4,#1      ! GOOD CHAR !
01AE FB0C      DBJNZ     RL3,LOPSTR  ! DEC COUNT !

```

!TRUNCATE, TOO MANY CHAR !

LOPOVR:

```

01B0 D769      CALP      RECMSG
01B2 0A08      CPE       RL0,#CR      ! LOOK FOR CR !
01B4 0D0D
01B6 FEFC      JR        NZ,LOPOVR
01B8 76ED      LDA       R13,INTBUF(R14)
01BA 0000
01BC 0100      ADD       R13,#80
01BE 0050
01C0 2ED8      LTB       @R13,RL0

```

```

0102 9308      RET
0104      END LINECT

```

```

0104      UNPACK  PROCEDURE

```

```

!*****
*
*   UNPACK: UNPACKS RECEIVED PACKETS
*           FROM MCZ IN INTBUF AND
*           LOADS IN SPECIFIED MEMORY
*           AREA. ASCII CHAR ARE CON-
*           VERTED TO HEX VALUES.
*
*   REG USE: INPUT  RH3 = #BYTE DATA
*****!

```

```
ENTRY
```

```

0104 A03C      LDB      RL4,RH3      ! SAVE COUNT !
0106 DFD9      CAL     CONVAD      ! CONV START ADR !

```

```

0108 61F2      LD       R2,DWN_ADR(R14)
010A 0316
010C 8D24      TEST     R2
010E FE02      JR       NZ,NOT_FIRST
01D0 6FE1      LD       DWN_ADR(R14),R1
01D2 0316

```

```
NOT_FIRST:
```

```

! CHECK FOR USER ENTERED ADDR FOR LOAD !
01D4 2B0B      CP       R11,%FFFE
01D6 FFFE
01D8 F601      JR       Z,USE_MCZADR
01DA 11B1      LD       R1,R11      ! USER SPECIFIED !

```

```
USE_MCZADR:
```

```

01DC 76F2      LDA      R2,INTBUF(R14)
01DE C000
01E0 A927      INC      R2,#8

```

```
CANDS:
```

```

01F2 DFFB      CAL     TENHEX      ! CONVERT 2-ASCII CHR !
01E4 2F18      LDB     GR1,RL0      ! STORE IN MEM !
01E6 A910      INC     R1,#1
01F8 FC04      DBJNZ   RL4,CANDS    ! CONV AND STORE ALL !

```

```
! UPDATE USER SPECIFIED ADDRESS !
```

```

01EA 0B0B      CP       R11,%FFFE
01EC FFFE
01EE E601      JR       Z,NO_UPDATE ! USE MCZ ADR !
01F0 111B      LD       R11,R1      ! UPDATE USER ADR !

```



```

NO_UPDATE:
01F2 9E08    RET

```

```

01F4    END UNPACK

```

```

01F4    TRNHEX PROCEDURE

```

```

!*****
*
*   TRNHEX: CONVERTS TWO ASCII CHAR FROM
*           INTBUF TO TWO 4-BIT HEX #
*           AND ADD TO CKSUM.
*
*   REG USE: INPUT  R2 = PTR TO 1ST CHR
*                 RL3= CKSUM ACCUM
*   RETURN  R2 = UPDATE PTR
*           RL3= UPDATED ACCUM
*           RL0= HEX VALUE
*           AND C IF NON-ASCII
*           NC IF ALL GOOD
*
*****!

```

```

ENTRY

```

```

01F4 DFF6    CALR    ATOHEX    ! CONVERT 1ST CHR !
01F6 9E07    RET      C
01F8 808B    ADDB    RL3,RL0    ! ADD TO CKSUM !
01FA B309    SLA     R0,#12     ! MOVE TO H NIBBLE !
01FC 000C
01FE DFFB    CALR    ATOHEX    ! CONVERT 2ND CHR !
0200 9E07    RET      C
0202 808B    ADDB    RL3,RL0
0204 8408    ORB     RL0,RH0    ! COMBINE NIBBLES !
0206 8D83    RESFLG  C
0208 9E08    RET
020A    END TRNHEX

```

```

020A    ATOHEX PROCEDURE

```

```

!*****
*
*   ATOHEX: CONVERTS ONE ASCII CHAR TO
*           4-BIT HEX NIBBLE.
*
*   REG USE: INPUT  R2 = PTR TO CHR
*                 RETURN R2 = PTR + 1
*                 RL0= HEX NIBBLE
*
*****!

```

```

ENTRY

```

```

020A 2028    LDB     RL0,R2
020C A920    INC     R2,#1      ! INC PTR !
020E 34CA    LDA     R10,R12(#CONVERT)

```

0210 0000*
 0212 1F00
 0214 9E08
 0216

CALL GR10
 RET
 END ATCFEX

0216

CONVAD PROCEDURE

!*****!
 *
 * CONVAD: CONVERTS STARTING ADDRESS *
 * OF PACKET DATA TO HEX #. *
 *
 * REG USE: RETURN R1 = ADDRESS(HEX) *
 *
 !*****!

ENTRY

0216 76E2
 0218 0000
 021A D014
 021C A081
 021F D016
 0220 A089
 0222 9E08
 0224

LDA R2,INTBUF(R14)
 CALP TRNHEX
 LDB RH1,RL0 ! STORE 1ST BYTE !
 CALR TRNHEX
 LDB RL1,RL0 ! STORE 2ND BYTE !
 RET
 END CONVAD

0224

CHKPAK PROCEDURE

!*****!
 *
 * CHKPAK: CK RECEIVED MCZ PAC CKSUM *
 * AGAINST ACCUMULATED HEX *
 * VALUE CKSUM AFTER ASCII-TO- *
 * HEX CONVERSION. *
 *
 * REG USE: RETURN RH3 = BYTE COUNT *
 * AND C IF BAD OR *
 * NON-ASCII. *
 *
 !*****!

ENTRY

0224 76E2
 0226 0000
 0228 C303
 022A DFF9
 022C 9E07
 022E 2C34
 0230 9E06
 0232 93F3
 0234 DFFE
 0236 97F3
 0238 9E08
 023A

LDA R2,INTBUF(R14)
 LDB RH3,#3
 CALR CHKSUM ! CK 1ST CKSUM !
 RET C ! BAD CK !
 TESTB RH3
 RET Z ! NO DATA !
 PUSH GR15,R3 ! SAVE BYTE COUNT !
 CALR CHKSUM ! CK 2ND CKSUM !
 POP R3,GR15
 RET
 END CHKPAK

023A

CHKSUM PROCEDURE

!*****

```

*
*  CHKSUM:  CONVERTS ALL REC ASCII CHR
*           IN PAC TO HEX AND ACCUM NEW
*           CKSUM.  COMPARE CKSUMS AND
*           REPORT DIFFERENCES.
*
*  REG USE:  INPUT  R2 = PTR TO PAC
*                RH3= # CHR PAIRS
*           RETURN  RH3= BYTE COUNT
*                RL3= NEW CKSUM
*                RH3= REC CKSUM
*                AND C IF BAD OR
*                NON-ASCII REC
*
*

```

*****!

ENTRY

023A	8CB8	CLRB	RL3	! RESET CKSUM !
023C	D025	AB:CALR	TRNHEX	! CONVERT PAIRS !
023E	9E07	RET	C	
0240	F303	DBJNZ	RH3,AB	! CONTINUE..... !
0242	A083	LDB	RH3,RL0	
0244	93F3	PUSH	QR15,R3	! SAVE BYTE CNT !
0246	D02A	CALR	TRNHEX	! CONVERT NEXT TWO !
0248	97F3	POP	R3,QR15	
024A	9E07	RET	C	
024C	8AB8	CPE	RL0,RL3	! COMPARE CKSUMS !
024E	9F06	RET	Z	! GOOD CK... !
0250	9DS1	SETFLG	C	! BAD CKSUM !
0252	9E08	RET		
0254		END CHKSUM		

0254

GLOBAL

LOADFL PROCEDURE

```

!*****
*
*   LOADFL: RECEIVES PACKET FROM MCZ IN
*   FOLLOWING FORMAT:
*
*   <ADR><CNT><CKS1><DTA>...<DTA><CKS2>
*
*   ADR = START ASR IN 28000 MEM
*   CNT = # DATA WORDS
*   CKS1= CKSUM OF <ADR> + <CNT>
*   <DTA>...<DTA> = 32 DATA WORDS
*   CKS2= CKSUM OF DATA HEX VALUES
*
*   PROCEDURE VERIFIES CKSUMS BEFORE
*   STORING DATA IN 28000 MEM. PACKETS
*   ARE ACK FOR WITE: '0' = GOOD
*                   '7' = RESEND
*                   '9' = ABORT
*   IF REC '/' FROM MCZ, ECHOS WHAT
*   REC NEXT TO CONSOLE AND ABORT.
*
*****!

```

ENTRY

```

0254 4DF8   CLR      DWN_ADR(R14)    ! SET ENTRY ADR BLOCK !
0256 0316
0258 D12D   CALR     FNAME           ! CK FILENAME !
025A 65E4   SET      MFLAGS(R14),#LDMDE !SIGNAL LOAD IN !
025C 0310
                                !PROGRESS!
025E D111   CALR     CMDPAS          ! SND CMD TO MCZ !
0260 9E06   RET      Z              ! Z80 PROG NO LOAD !
PECLOP:
0262 D06D   CALR     LINRCT          ! GET PACKET !
0264 76E2   LDA      R2,INTBUF(R14)
0266 0000
0268 2028   LDB      RLO,QR2
026A 0A08   CPB      RLO,#'/'      ! CK FOR '/' !
026C 2F2F
026E FE10   JR       NZ,CONTIN      !NO, CONTINUE...!
0270 76F1   LDA      R1,OUTBUF(R14) !YES,!
0272 0080
0274 2103   LD       R3,#%20
0276 0020
0278 B321   LDI      QR1,QR2,R3     !ERROR MSG SETUP !
027A 0310
027C 76E1   LDA      R1,OUTBUF(R14)
027E 0080

```

```

0280 0101      ADD      R1,#%20
0282 0020
0284 6FE1      LF       OUTPTR(R14),R1 !SET OUTPTR !
0286 0306

0288 34CA      LDA      R10,R12(#PBUFNC)
028A 0000*
028C 1FA0      CALL     GR10
028E 9E08      RET

CONTIN:
0290 67E5      BIT      MFLAGS(R14),#ESC      ! CK FOR ABORT !
0292 0310
0294 EE34      JR       NZ,ABT              ! YES, ABORT...!
0296 D03A      CALP     CHKPAK              ! CK CKSUMS !
0298 EF02      JR       NC,GDLD              ! GOOD LOAD !
029A D0B0      CALP     BADPAK              ! SEND NON-ACK !
029C F8E2      JR       RECLOP              ! TRY AGAIN !

! CHECK FOR LAST PACKET AND PRINT <ENT ADR> !
GDLD:
029E 80B8      CLRB     RL3
02A0 8139      ADD      R8,R3      ! ACCUM NUMBER BYTES !
                                ! OF TRANSFER !

02A2 8C34      TESTB    RH3              ! CK COUNT=0 !
02A4 EE28      JR       NZ,STOR              ! OK, BEGIN STR !
02A6 D0B2      CALR     GODPAK              ! SEND GOOD ACK !
02A8 54E0      LDL      R0,INTBUF(R14)
02AA 0000
02AC 76ED      LDA      R13,OUTBUF(R14)
02AE 0780
02B0 0100      ADD      R13,#%0C
02B2 000C

! CHECK FOR USER SPECIFIED ADDR !
02B4 0B09      CP       R9,#%AAAA
02B6 AAAA
02B8 F61D      JR       Z,END_LOAD          ! NO ECHO TO CONS !
02BA 0B0B      CP       R11,#%FFFE          ! CK FOR LOAD ADR !
02BC FFFE
02BE F608      JR       Z,SAME_ADR          ! USE MCZ ADR !
02C0 6FED      LD       OUTPTR(R14),R13      ! SET OUTBUF ADR !
02C2 0306
02C4 61F5      LD       R5,ADR_STR(R14) ! GET USER ADR !
02C6 0314
02C8 76C4      LDA      R10,CONVW(R12)
02CA 0000*
02CC 1FA0      CALL     GR10              ! CONVERT TO ASCII AND !
                                ! AND STORE IN OUTBUF !

```

```

02C7 E801      JR      FIN_BUF
02D0 1DD0      SAME ADR:
                LDL      @R13,RR0

                FIN_BUF:
02D2 3402      LDAB     R2,ENTADR      !LOAD ENTRY LABEL!
02D4 0040
02D6 76E1      LDA      R1,OUTBUF(R14)
02D8 0080
02DA 2100      LD       R0,#6
02DC 0006
02DE 0B21      LDIR     @R1,@R2,R0
02E0 0010
02E2 76ED      LDA      R13,OUTBUF(R14)
02E4 0080
02E6 010D      ADD      R13,#%10
02E8 0010
02FA 6FFD      LD       OUTPTR(R14),R13
02FC 0306
02EE 34CA      LDA      R10,R12(#PRNTBF)
02F0 0000*
02F2 1FA0      CALL     @R13          ! PRINT MESSAGE !
                END_LOAD:
02F4 9F08      RET

                STOR:
02F6 D071      CALR     CCNVAD
02F8 D0DB      CALR     GODPAK          ! SEND ACK !
02FA D09C      CALR     UNPACK          ! UNPACK AND STORE !
02FC E8B2      JR       RECLOP          ! CONTINUE....!

                ABT:
02FE 3402      LDAR     R2,EMSG
0300 000A
0302 34CA      LDA      R10,R12(#SNDMSG)
0304 0000*
0306 1FA0      CALL     @R10          ! SEND MESSAGE !
0308 D0E5      CALR     ABCRTM          ! SEND ABORT !
030A 9E08      RET

030C          END_LOADFL

                EMSG:
030C 07        BVAL     7
030E 2F41      WVAL     '/A'
0310 424F      WVAL     '30'
0312 5254      WVAL     'RT'
0314 0D        BVAL     %0D
                ENTADR:
0316 454E      WVAL     'EN'

```

331F	5452	WVAL	'TR'
031A	5920	WVAL	'Y'
331C	504F	WVAL	'PO'
031F	494E	WVAL	'IN'
3320	5420	WVAL	'T'

END SUPPORT3A

APPENDIX E - Support Programs

A. TEXT FILE TRANSFERS

To transfer test files from the MCZ microcomputer RIO system, use the following procedures.

1. Bootup SASS monitor program as described in Appendix C.
2. Bootup INTEL MDS system with CP/M disk having ZEXFER program.
3. Connect cable to MDS system TTY port and to the SASS 'B' connector (to replace line printer).
4. Enter 'transparent' mode of SASS monitor operation to operate within the MCZ RIO operating system, by the following action:

TYPE "Q <CR>"
(displays RIO prompt '%')
5. Setup to transfer text file by:

TYPE "PRINT <Filename>"
(Note: no <CR>)
6. On the MDS system, execute ZEXFER program selecting text file transfer ('T').
7. On SASS (RIO) system, type <CR> to start transfer.

After the entire file has been displayed on SASS terminal, depress any key on MDS terminal to end transfer.

28000/CPM TRANSFER MODULE

Z8XFER:

```

PROCEDURE OPTIONS(MAIN);
%INCLUDE 'DIOMOD.DCL';
%REPLACE
    TRUE      BY      '1'B,
    BUFBYT    BY      8,
    FALSE     BY      '0'B;

```

DCL

```

ANSWER      CHAR(1),
FN          CHAR(11) VAR,
I           FIXED,
WAIT        BIT(1),
MEM         FIXED(15),
NUMBUF      FIXED(15),
REPLY       CHAR(1),
CMDBUF      CHAR(80) VAR,
C           CHAR(1),
CPCNT       FIXED(15),
TMP         FIXED(15),
ACCUM       EXT,
CH1         EXT,
CH2         EXT,
PT1         FIXED(15),
PT2         FIXED(15),
DEX         FIXED(15),
ODDEVN     BIT(1),
ANSR        EXT,
HEXVAL      EXT,
CBJXFR      ENTRY   EXT,
TXTXFR      ENTRY   EXT;

```

```

/*****
*   PROGRAM INTERACTIVE HEADER SECTION   *
*****/

```

```

PUT SKIP LIST('Z8XFER: SASS TO CPM ASCII-HEX TRANSFER PROGRAM');
PUT SKIP LIST('*** NOTE:');
PUT SKIP LIST('    CABLE CONNECTIONS BETWEEN THE');
PUT SKIP LIST('    SYSTEMS VARY AS TO TYPE OF');
PUT SKIP LIST('    FILE BEING TRANSFERED');
PUT SKIP(2) LIST('    TYPE <CR> TO CONTINUE..');

```

```

/*****
*      DETERMINE TRANSFER TYPE      *
*****/

PUT SKIP(2) LIST('IS FILE A TEXT OR CODE FILE? (T/C)');
WAIT=TRUE;
DO WHILE (WAIT=TRUE);
    GET LIST(ANSWER);
    IF (ANSWER = 'T') THEN
        CALL TXTXFR;
    ELSE
        IF (ANSWER = 'C') THEN
            CALL OBJXFR;
        ELSE
            PUT SKIP LIST('INVALID ENTRY');
END;
END Z8XFR;

```

2. TTXFR MODULE

TTXFR:

```
PROC;
%INCLUDE 'DIOMOD.DCL';
%REPLACE
    TRUE    BY    '1'B.
    BUFBYT  BY    6,
    FALSE   BY    '0'B;
```

DCL

```
ANSWER  CHAR(1) EXT.
FN      CHAR(11) VAR EXT.
I       FIXED EXT.
WAIT    BIT(1) EXT.
MEM      FIXED(15) EXT.
NUMBUF  FIXED(15) EXT.
REPLY   CHAR(1) EXT.
CMDBUF  CHAR(80) VAR EXT.
C       CHAR(1) EXT.
CRCNT   FIXED(15) EXT.
TMP     FIXED(15) EXT.
ACCUM   EXT.
CH1     CHAR(1) EXT.
CH2     CHAR(1) EXT.
PT1     FIXED(15) EXT.
PT2     FIXED(15) EXT.
DEX     FIXED(15) EXT.
HEXVAL  BIT(8) EXT.
ODDEVN  BIT(1) EXT.
RECTTY  ENTRY EXT;
```

/* TERMINATE TRANSFER AND SAVE THE FILE */
 TERMINATE:

```
PROC;
NUMBUF = DIVIDE(MEM,BUFBYT,15);

/* WRITE BUFFERS TO DISK FILE */
IF MEM=0 THEN
  DO;
    PUT SKIP LIST('NO DATA TRANSFERED');
    CALL DELETE(ADDR(DESTFILE));
    CALL REBOOT();
  END;

MEM=0;
DO I=0 TO NUMBUF-1;
  CALL SETDMA(ADDR(MEMORY(MEM)));
```

```

MEM=MEM + BUFBYT;
IF WRSFO ADDR(DESTFILE) ^=0 THEN
    DO;
        PUT SKIP LIST('DISK FULL');
        CALL REBOOT();
    END;
PUT SKIP LIST('TRANSFER COMPLETE. ');
CALL REBOOT();
END;
/*****
*      TTXFR: PROCEDURE FOR TRANSFERRING A TEXT      *
*      FILE FROM SASS TO CPM VIA A CABLE FROM      *
*      THE SASS 'B' CONNECTOR TO THE INTEL TTY      *
*      PORT. CPM WILL INTERCEPT SASS CRT TEXT      *
*      DISPLAY FROM THE MCZ EDITOR.                  *
*****/

DCL
    1 DESTFILE BASED(DFCB0()),
%INCLUDE 'FCB.DCL';
DCL    MEMORY (0:0)    BIT(16) BASED(MEMPTR());

/*****
*      TFILE: PROC TO DETERMINE NAME OF FILE      *
*****/

TFILE:
PROC;
/* READ FILE NAME */
PUT SKIP LIST('WHAT IS THE FILENAME? ');
GET LIST(FN);

/* PROCESS OPTIONAL DRIVE PREFIX */
I = INDEX(FN, '.');
IF I=0 THEN
    DESTFILE.DRIVE=0;
ELSE
    DO;
        DESTFILE.DRIVE=1;
        FN = SUBSTR(FN, I+1);
    END;

/* GET FILENAME AND TYPE */
I = INDEX(FN, '.');
IF I=0 THEN
    DO;
        /* NO FILE SPECIFIED, USE '.TXT' */
        DESTFILE.FNAME = FN;
        DESTFILE.FTYPE = 'TXT';
    END;

```

```

ELSE
    DO;
    DFSTFILE.FNAME = SUBSTR(FN,1,I-1);
    DESTFILE.PTYPE = SUBSTR(FN,I+1);
    END;
END TFILE;

/* INIT FCB */
DFSTFILE.FEXT = 0;
DESTFILE.CREC = 0;

/* OBTAIN FILENAME AND CHECK FOR EXISTING FILE */
CALL TFILE;
IF SEAR(ADDR(DESTFILE)) = -1 THEN
    DO;
    PUT SKIP LIST('DELETE OLD FILE? (Y/N)');
    GET LIST(ANSWER);
    IF (ANSWER = 'Y') THEN
        CALL DELETE(ADDR(DESTFILE));
    ELSE
        CALL REBOOT();
    END;

/* OPEN NEW FILE */
IF MAKE(ADDR(DESTFILE)) = -1 THEN
    DO;
    PUT SKIP LIST('NO DIRECTORY SPACE');
    CALL REBOOT();
    END;

/* COMPUTE BUFFER SPACE */
NUMBUF = DIVIDE(MEMSIZ(),BUFBYT,15);
IF NUMBUF=0 THEN
    DO;
    PUT SKIP LIST('NO BUFFER SPACE');
    CALL REBOOT();
    END;

/* MAIN LOOP CHECKING FOR KB ENTRY OR TTY RECEIVE */
MEM=0;
WAIT=TRUE;
DO WHILE (WAIT=TRUE);
    IF BREAK() = TRUE THEN
        CALL TERMINATE;
    IF RECTTY = TRUE THEN
        DO;
        IF MEM < NUMBUF THEN
            DO;
            MEMORY(MEM)=RDRDR();

```

```

MEM = MEM + 1;
END;
ELSE
DO;
PUT SKIP LIST('FILE TOO LARGE');
CALL REBOOT();
END;
END;
END;
END TXTR;

```

3. OBJXFF MODULE

```

OBJXFF:
PROC;
%INCLUDE 'DIOMOD.DCL';
*REPLACE
      TRUE      BY      '1'B.
      BUFPYT    BY      129.
      FALSE     BY      'Z'B;

DCL
ANSWER  CHAR(1) EXT.
FM      CHAR(11) VAR EXT.
I       FIXED EXT.
WAIT    BIT(1) EXT.
MEM      FIXED(15) EXT.
NUMBUF  FIXED(15) EXT.
REPLY    CHAR(1) EXT.
CMDBUF  (1:80) CHAR(1) EXT.
C        CHAR(1) EXT.
CR       CHAR(1).
CRCNT    FIXED(15) EXT.
TMP      FIXED(15) EXT.
ACCUM    EXT.
HEXVAL   BIT(8) EXT.
CH1      CHAR(1) EXT.
CH2      CHAR(1) EXT.
PT1      FIXED(15) EXT.
PT2      FIXED(15) EXT.
DFX      FIXED(15) EXT.
ODDFVN   BIT(1) EXT.
RECTTY   ENTRY    EXT.
ATOHX    ENTRY    EXT;

```

```

/*****
*      OBJXFR: PROCEDURE TO TRANSFER CODE FROM      *
*      72000 MEMORY TO CPM FILES BY USING THE      *
*      TECTRONIX FORMAT. CONNECTION IS FROM        *
*      INTEL TTY PORT TO SASS CABLE 'A'. CPM        *
*      WILL ASSUME THE ROLE OF MCZ-RIO SYSTEM.      *
*****/

DCL
    1 HIFILE BASED(DFCB0()),
%INCLUDE 'FCB.DCL';
DCL
    1 LOFILE BASED(DFCB1()),
%INCLUDE 'FCB.DCL';
DCL
    EVNBUF (2000) BIT(8),
    ODDBUF (2000) BIT(8),
    RECEUF (1:80) CHAR(1),
    FLAG BIT(1);

/* SASS TO CPM CODE FILE TRANSFER BY TECTRONIX FROMAT */
PUT SKIP LIST('CPM WILL ASSUME THE MCZ-RIO ROLE FOR TRANSFER');
PUT SKIP LIST('      SETUP: CONNECT CABLE TO SASS "A" CONNECT-');
PUT SKIP LIST('      TOR AND TO INTEL TTY PORT. ');
PUT SKIP LIST('      ENTER <CR> WHEN READY...');
GET LIST(PFPLY);
CR=
';

/*****
*      CFILF: PROCEDURE TO DETERMINE THE          *
*      FILENAME OF THE OBJECT FILES              *
*****/

CFILF:
PROCEDURE;
/* READ FILE NAME */
PUT SKIP LIST('WHAT IS THE FILENAME?');
GET LIST(FN);

/* PROCESS OPTIONAL DRIVE PREFIX */
I = INDEX(FN, ':');
IF I=0 THEN
    DO;
        HIFILE.DRIVE = 0;
        LOFILE.DRIVE = 0;
    END;
ELSE
    DO;
        HIFILE.DRIVE = 1;
    END;

```



```

        LOFILE.DRIVE = 1;
        FN = SUBSTR(FN,I+1);
        END;

/* SET FNAMES AND FTYPES */
I = INDEX(FN,'.'):
IF ~(I=0) THEN
    FN = SUBSTR(FN,1,I-1);
HIFILE.FNAME = FN;
LOFILE.FNAME = FN;
HIFILE.FTYPE = 'OBJ';
LOFILE.FTYPE = 'OBJ';
RETURN;
END CFILE;

/*****
*          ECHO: PROC TO ECHO CMD LINE BACK          *
*          TO Z8000 MONITOR.                          *
*****/

ECHO:
PROC;
DCL
    NMBR FIXED(S),
    EXTRA FIXED(S);

/* INIT BUFFER PTR */
NMBR=3;
EXTRA=1;

/* GET CMD LINE FROM MONITOR */
WAIT=TRUE;
DO WHILE (WAIT=TRUE);
    C=RDADR();
    CMDBUF(NMBR)=C;
    NMBR=NMBR+1;
    /* ECHO BACK */
    IF (C=C?) THEN
        DO WHILE (EXTRA=NMBR);
            C=CMDBUF EXTRA;
            CALL WFPUN(C);
            WAIT=FALSE;
        END;
    ELSE
        WAIT=TRUE;
    END;
END;
RETURN;
END ECHO;

```

```

*****
*          GETREC: PROC TO GET ONE TECTRONIX          *
*          FORMATED RECORD.                          *
*****

```

```

GETREC:
PROC;
CRCNT=1;
WAIT=TRUE;
/* CHECK FOR RECEIVE CHAR FROM CON OR TTY */
DO WHILE (FLAG=TRUE);
    IF BREAK()=TRUE THEN
        DO;
            FLAG=FALSE;
            WAIT=FALSE;
            END;
    IF RECTTY=TRUE THEN
        DO;
            C=RDRTD();
            RECBUF(CRCNT)=C;
            IF C=CR THEN
                FLAG=FALSE;
            CRCNT=CRCNT+1;
        END;
    END; /* DO WHILE */
RETURN;
END GETREC;

```

```

/*****
*          DOLAST: PROC TO SEND FINAL ACK          *
*          TO Z8000 AND SAVE FILES.              *
*****

```

```

DOLAST:
PROC;
/* CHECK <CKSUM> FOR DATA FIELD */
TMP=ACCUM;
ACCUM=0;
CH1 = RECBUF(7);
CH2 = RECBUF(8);
CALL ATORTEX;
IF (TMP=ACCUM) THEN
    DO;
        C='7';
        CALL WRPN(C);
        RETURN;
    END;

```

```

/* SEND ACK '0' CHAR TO ZP000 */
C='0';
CALL WRPUV(C);

/* SAVE EVEN PROM FILE (HIFILE) */
NUMBUF = DIVIDE(PT1,BUFBYT,15);
IF PT1=0 THEN
    DO;
        PUT SKIP LIST('NO DATA TRANSFERED');
        CALL DELETE(ADDR(HIFILE));
        CALL DELETE(ADDR(LOFILE));
        CALL PERCOT();
    END;

PT1=0;
DO I = 0 TO NUMBUF-1;
    CALL SETDMA(ADDR(EVENBUF(PT1)));
    PT1=PT1 + BUFBYT;
    IF WRSEQ(ADDR(HIFILE))^=0 THEN
        DO;
            PUT SKIP LIST('DISKFULL');
            CALL PERCOT();
        END;

END;

/* SAVE ODD PROM FILE (LOFILE) */
NUMBUF = DIVIDE(PT2,BUFBYT,15);
PT2=0;
DO I = 0 TO NUMBUF-1;
    CALL SETDMA(ADDR(ODDBUF(PT2)));
    PT2 = PT2 + BUFBYT;
    IF WRSEQ(ADDR(LOFILE))^=0 THEN
        DO;
            PUT SKIP LIST('DISK FULL');
            CALL PERCOT();
        END;

END;

WAIT=FALSE;
PUT SKIP LIST('TRANSFER COMPLETE. ');
RETURN;
END DCLAST;

```

```

/*****
*          STREC: PROC TO STORE THE RECEIVED          *
*          RECORD IN FILE BUFFERS.                    *
*****/

```

```

STRREC:
PRCC:
IF CRCNT=9 THEN
    CALL TOLAST;
ELSE IF CRCNT=41 THEN
    CALL DASSEM;
ELSE
    DO;
        C='7';
        CALL WRPUN(C);
    END;
RETURN;
END;

```

```

/*****
*          DASSEM: PROC TO DISASSEMBLE ONE RECORD    *
*          AND STORE IN PROPER BUFFER.                *
*****/

```

```

DASSEM:
PRCC:
DEX=1;
ACCUM=0;
PT1=1;
PT2=1;

```

```

/* OBTAIN <ADDR><COUNT> CKSUM */
DO I=0 TO 2;
    CH1 = RFBUFF(DEX);
    CH2 = RFBUFF(DEX+1);
    DEX = DEX + 2;
    CALL ATOHFX;
END;

```

```

/* OBTAIN <CKSUM> */
TMP=ACCUM;
ACCUM=0;
CH1 = RFBUFF(DEX);
CH2 = RFBUFF(DEX+1);
DEX = DEX + 2;
CALL ATOHEX;

```

```

/* COMPARE CKSUMS AND REPORT ERROR */
IF (TMP=ACCUM) THEN
    DO;

```

```

C='7';
CALL WRPUN(C);
RETURN;
END;

/* DISASSEMBLE 32-BYTE PACKAGE AND STORE */
ACCUM = 0;
DO I=1 TO 15;
  CH1 = RECBUF(DEX);
  CH2 = RECBUF(DEX+1);
  DEX = DEX + 2;
  CALL ATOHX;
  /* STORE IN PROPER BUFFER */
  IF ODDEVN=TRUE THEN
    DO;
      EVNBUF(PT1)=HEXVAL;
      HEXVAL=0;
      PT1=PT1-1;
      ODDEVN=FALSE;
    END;
  ELSE
    DO;
      ODDBUF(PT2)=HEXVAL;
      HEXVAL=0;
      PT2=PT2-1;
      ODDEVN=TRUE;
    END;
  END;
END;

/* COMPARE CKSUMS AND REPORT ERRORS */
TMP=ACCUM;
ACCUM=0;
CH1 = RECBUF(DEX);
CH2 = RECBUF(DEX+1);
CALL ATOHX;
IF (TMP=ACCUM) THEN
  DO;
    C='7';
    CALL WRPUN(C);
    RETURN;
  END;
ELSE
  DO;
    C='0';
    CALL WRPUN(C);
    WAIT=FALSE;
    RETURN;
  END;
END DASSEM;

```

```

/* INIT FCB'S */
HIFILE.FEXT = 0;
LOFILE.FEXT = 0;
HIFILE.CREC = 0;
LOFILE.CREC = 0;

```

```

/* OBTAIN FILENAME AND CHECK FOR EXISTING FILES */
CALL CFILE;
IF (SEAR(ADDR(HIFILE))^=-1 ! SEAR(ADDR(LOFILE))^=-1) THEN
DO;
PUT SKIP LIST ('DELETE OLD FILES? (Y/N)');
GET LIST(ANSWER);
IF (ANSWER ^= 'Y') THEN
DO;
CALL DELETE(ADDR(HIFILE));
CALL DELETE(ADDR(LOFILE));
END;
ELSE
CALL REBOOT();
END;

```

```

/* OPEN NEW FILES */
IF (MAKE(ADDR(HIFILE))=-1 ! MAKE(ADDR(LOFILE))=-1) THEN
DO;
PUT SKIP LIST('NO DIRECTORY SPACE');
CALL REBOOT();
END;

```

```

/*****
*          MAIN CODE SEG: LOOK FOR 'B;', ECHO          *
*          ALL BACK THRU PUN PORT; SEND '9',          *
*          SEND '0', AND BEGIN STORING-DISASSEM-      *
*          BLING TECTRONIX FORMAT TO THE TWO          *
*          OBJECT FILES.                               *
*****/

```

```

CDEEVN = TRUE;
WAIT = TRUE;

```

```

/* WAIT FOR 'B;' */
DO WHILE (WAIT=TRUE);
IF BREAK( )=TRUE THEN
CALL DOLAST;
IF PECTTY = TRUE THEN
DO;
C=RDRDR();
IF(C='B') THEN
DO;

```

```

C=PDPRD);
IF (C=';') THEN
    DC;
    CMDBUF 1)='B';
    CMDBUF 2)=';';
    CALL ECHO;
    WAIT=FALSE;
    END;
ELSE
    WAIT=TRUE;
END;
END;
END; /* DO WHILE */

/* RECEIVE RECORDS AND CONVERT FOR STORAGE */
WAIT=TRUE;
DO WHILE(WAIT=TRUE);
    CALL GETREC;
    CALL STORFC;
END;
END OBJXFR;

```

4. Z8LIB MODULE

```

NAME      'Z8LIB'
TITLE     'ASM ROUTINE LIB FOR Z8XFER'
; /*****
; *
; *      DECLARATIONS
; *
; *****/

PUBLIC RECTTY      ;RETURNS '1' FOR RFC CHAR
PUBLIC ATOHEX      ;CONVERTS TWO ASCII BYTES TO ONE
PUBLIC POST        ;ERROR SIGNAL
PUBLIC ACCUM       ;ACCUMULATOR FOR CKSUM
PUBLIC HEXVAL      ;RETURN OF HEX BYTE
PUBLIC ANSR        ;MAILBOX FOR PL/I RETURN
PUBLIC CH1         ;FIRST ASCII CHAR
PUBLIC CH2         ;SECOND ASCII CHAR

;
; *****/
; *
; *      EQUATES
; *
; *****/

TPORT     FCU      0F6H    ;TTY (RDR) CMD PORT ADDR
POST       DB       1      ;ERROR FLAG FOR Z8XFER FOR BAD CH
ACCUM      DB       2      ;ACCUM VALUE FORR CHECK SUMS
HEXVAL     DB       1      ;RETURNED HEX BYTE FROM 2-ASCII
ANSR       DB       1
CH1        DB       1      ;PASSED CHAR FROM BUFFERS
CH2        DB       1      ;SAME

;
; *****/
; *
; *      RECTTY: ROUTINE TO FACILITATE DIRECT
; *      I/O STATUS READ TO TTY PORT.
; *
; *****/

RECTTY: ANI        0        ;CLEAR REG A
        IN         TPORT    ;READ TTY CMD PORT STATUS
        ANI        01H     ;CHECK FOR RECEIVE CHAR
        JZ         FINI     ;NO CHAR RECEIVED
        MVI        A,01H    ;YES, CHAR RECEIVED

;
FINI:    MOV        L,A      ;LOAD ANSWER
        MVI        H,0      ;STORE IN MAILBOX
        SHLD       ANSR
        RET
;
;

```


C. CPMXFR PROGRAM LISTING

1. 28000 TRANSFER MODULE

Z8000ASM 2.02

LOC OBJ CODE STMT SOURCE STATEMENT

1 TRANSFER MODULE
\$LISTON \$TTY

CONSTANT

PORTAD := %FFD9
PORTAC := %FFDB
PROM_SIZ := %1005
MEM_START := %6000
TXR := 0
FYEC := %00EC

\$REL 0
GLOBAL

2000

TRANS PROCEDURE

!*****!
*
* TRANS: TRANSFERS OBJECT CODE IN *
* Z8000 MEMORY TO INTEL CP/M *
* OBJECT FILE ON DISK. *
*
!*****!

ENTRY

2000 2101 LD R1,#PROM_SIZ ! SET TRANS LIMIT !
0002 1005
0004 2102 LD R2,#MEM_START ! SET MEMORY START !
0006 6000
0008 8D38 CLR R3 ! ADDRESS !

! *** MAIN LOOP SENDING BYTES *** !

DO

000A 2029 LDB R10,R2 ! GET BYTE FROM MEM !
000C DFF8 CALF SMDCHR ! SEND CHAR TO CPM !
000E A920 INC R2,#1 ! ADVANCE ADR 1 BYTE !
0010 A930 INC R3,#1 ! INCREMENT COUNTER !
0012 8B13 CP R3,R1 ! DONE?.... !
0014 F601 JR Z.FINI ! YES, DONE !
0016 EBF9 OD

FINI:

```

0018 2101      LD      R1,#EXEC
001A 00FC
001C 1F19      JP      CR1

001E          END TRANS

001F          SNDCHR  PROCEDURE
!*****
*
*   SNDCHR: SENDS SINGLE BYTE TO INTEL
*           CP/M AFTER STATUS CHECK.
*
*****!
ENTRY
001F 3A04      INE      R00,PORTAC      ! GET STATUS !
0020 FFDB
0022 A6C0      BITB     R00,#TXR      ! CK IF TRANSMIT RDY !
0024 F6FC      JR       Z,SNDCHI
0026 3A96      OUTB     PORTAD,R00     ! SEND BYTE !
0028 FFD9
002A 9E08      PRT
002C          END SNDCHR

          END TRANSFER

```

2 errors
 Assembly complete

LIST OF REFERENCES

1. O'Connell, J. S., and Richardson, L. D., Distributed Secure Design for a Multi-Microprocessor Operating System, MS Thesis, Naval Postgraduate School, June 1979.
2. Parks, E. J., The Design of a Secure File Storage System, MS Thesis, Naval Postgraduate School, December 1979.
3. Coleman, A. P., Security Kernel Design for a Microprocessor-Based, Multilevel, Archival Storage System, MS Thesis, Naval Postgraduate School, December 1979.
4. Moore, E. F. and Gary, A. V., The Design and Implementation of the Memory Manager for a Secure Archival Storage System, MS Thesis, Naval Postgraduate School, June 1980.
5. Reitz, S. L., An Implementation of Multiprogramming and Process Management for a Security Kernel Operating System, MS Thesis, Naval Postgraduate School, June 1980.
6. Wells, J. T., Implementation of Segment Management for a Secure Archival Storage System, MS Thesis, Naval Postgraduate School, September 1980.
7. Strickler, A. R., Implementation of Process Management for a Secure Archival Storage System, M.S. Thesis, Naval Postgraduate School, March 1981.
8. Organick, E. J., The Multics System: An Examination of Its Structure, MIT Press, 1972.
9. Madnick, S. E., and Donovan, J. J., Operating Systems, McGraw Hill, 1974.
10. Reed, P. D., Processor Multiplexing In a Layered Operating System, MS Thesis, Massachusetts Institute of Technology, MIT LCS/TR-167, 1979.
11. Schell, R. R., Dynamic Reconfiguration in a Modular Computer System, Ph.D. Thesis, Massachusetts Institute of Technology, May 1971.

12. Schell, Lt.Col. P. P., "Security kernels: A Methodical Design of System Security," USE Technical Papers Spring Conference, 1979). p. 245-250, March 1979.
13. Denning, D. F., "A Lattice Model of Secure Information Flow," Communications of the ACM, v. 19, p. 236-242, May 1976.
14. Schroeder, M. D., "A Hardware Architecture for Implementing Protection Rings," Communications of the ACM, v. 15, no. 3, p. 157-170, March 1972.
15. Dijkstra, E.W., "The Structure of the 'THE' Multiprogramming System", Communications of the ACM, v. 11, p. 341-346, May 1968.
16. Reed, P. D., and Kanodia, R. K., "Synchronization With Eventcounts and Sequencers," Communications of the ACM, v. 22, no. 2, p. 115-124, February 1979.
17. Luniewski, A., A Simple and Flexible System Initialization Mechanism, M.S. Thesis, Massachusetts Institute of Technology, May 1977.
18. Boss, J.I., Design of a System Initialization Mechanism for a Multiple Microcomputer, M.S. Thesis, Naval Postgraduate School, June 1980.
19. Anderson, E.L., Automatic Recovery in a Real-Time, Distributed Multiple Microprocessor Computer System, M.S. Thesis, Naval Postgraduate School, December 1980.
20. Advance Micro Devices, Am9513 System Timing Controller, Product Specification Sheet, 1980.
21. Zilog, Inc., Z8001 CPU Z8002 CPU, Preliminary Product Specification, March 1979.
22. Zilog, Inc., Z8010 MMU Memory Management Unit, Preliminary Product Specification, October 1979.
23. Advanced Micro Computers, AM96/4116 AmZ8000 16-Bit MonoBoard Computer, User's Manual, 1980.
24. Zilog, Inc., Z8070 PLZ/ASM Assembly Language Programming Manual, 03-3055-01, Revision A, April 1979.
25. Schell, P. P. and Cox, L. A., Secure Archival Storage System, Part I - Design, Naval Postgraduate School, NPS52-80-002, March 1980.

26. Schell, R. F. and Cox, L. A., Secure Archival Storage System. Part II - Segment and Process Management Implementation, Naval Postgraduate School, NPS52-81-001, March 1981.
27. Baker, G. S., Secure Archival Storage System - Hardware Architecture and Developmental Monitor, Naval Postgraduate School, NPS__-81-____, June 1981.

INITIAL DISTRIBUTION LIST

	No. Copies
1. Defense Documentation Center ATTN:DDC-TC Cameron Station Alexandria, Virginia 22314	2
2. Library, Code 2142 Naval Postgraduate School Monterey, California 93940	2
3. Department Chairman, Code 52 Department of Computer Science Naval Postgraduate School Monterey, California 93940	2
4. LTCOL Roger R. Schell, Code 52Sj Department of Computer Science Naval Postgraduate School Monterey, California 93940	2
5. Lyle A. Cox, Jr., Code 52C1 Department of Computer Science Naval Postgraduate School Monterey, California 93940	6
6. Joel Trimble, Code 221 Office of Naval Research 800 North Quincy Arlington, Virginia 22217	1
7. Department Chairman Department of Computer Science United States Military Academy West Point, New York 10996	1
8. INTEL Corporation Attn: Mr. Robert Childs Mail Code: SC 4-490 3065 Bowers Avenue Santa Clara, California 95051	1
9. John P.L. Woodward The MITRE Corporation P.O. Box 208 Bedford, Massachusetts 01730	1

10. Digital Equipment Corporation 1
Attn: Mr. Donald Gaubatz
146 Main Street
ML 3-2/E41
Maynard, Massachusetts 01754
11. Joe Urban 1
University of Southwestern Louisiana
P.O. Box 44330
Lafayette, Louisiana 70504
12. LCDR Gary Baker, Code 37 3
COMRESPATWINGPAC
NAS Moffett Field
Moffett Field, California 90031
13. CPT Anthony R. Strickler 1
Route #12
West Shipley Ferry Road
Kingsport, Tennessee 37663
14. Professor T.F. Tao, Code 62Tv 1
Department of Electrical Engineering
Naval Postgraduate School
Monterey California 93940

FILMED
2-8